
SERVICE MANUAL

MODEL	DEST.	CHASSIS NO.	MODEL	DEST.	CHASSIS NO.
PVM-20M2U	US Canadian	SCC-G61H-A	PVM-20M4E	AEP	SCC-G62E-A
PVM-20M4U	US Canadian	SCC-G61F-A	PVM-20M4A	Australian	SCC-N17C-A
PVM-20M2E	AEP	SCC-G62GA			
				1	





TrinitronPVM-20M2U/20M2E

TRINITRON® COLOR VIDEO MONITOR

SONY.

SPECIFICATIONS

Video signal

For PVM-14M4U/14M4E/20M4U/20M4E:

Color system

NTSC, PAL, SECAM, NTSC4.43

Resolution

800 TV lines

Aperture correction 0 dB to +6 dB

Frequency response

LINE

10 MHz ± 3 dB (Y signal)

RGB

 $10 \text{ MHz} \pm 3 \text{ dB}$

Synchronization

AFC time constant 1.0 msec.

For PVM-14M2U/14M2E/20M2U/20M2E:

Color system Resolution

NTSC, PAL, SECAM, NTSC4.43

600 TV lines

Aperture correction 0 dB to +6 dB

Frequency response

LINE

10 MHz ± 3 dB (Y signal)

RGB

 $10 \text{ MHz} \pm 3 \text{ dB}$

Synchronization

AFC time constant 1.0 msec.

Picture performance

For PVM-14M4U/14M4E/14M2U/14M2E:

Normal scan

7 % over scan of CRT effective screen

Under scan

5 % underscan of CRT effective screen

area

H. linearity

Less than 4.0 % (typical)

V. linearity

Convergence

Less than 4.0 % (typical)

Central area: Peripheral area:

0.4 mm (typical) 0.5 mm (typical)

Raster size stability H: 1.0%, V: 1.5%

High voltage regulation

3.5 %

Color temperature

D65/D93, selectable

USER (3,200K-10,000K, factory

setting is D65)

For PVM-20M4U/20M4E:

Normal scan

7 % over scan of CRT effective screen

area

Under scan

5 % underscan of CRT effective screen

area

H. linearity

Less than 5.0 % (typical)

Less than 5.0 % (typical)

V. linearity Convergence

Central area:

0.5 mm (typical)

Peripheral area: 0.7 mm (typical)

Raster size stability H: 1.0%, V: 1.5%

High voltage regulation

4.0 %

Color temperature

D65/D93, selectable

USER (3,200K-10,000K, factory

setting is D65)

For PVM-20M2U/20M2E

Normal scan

7 % over scan of CRT effective screen

area

Under scan

5 % underscan of CRT effective screen

H. linearity

Less than 5.0 % (typical)

V. linearity

Less than 5.0 % (typical)

Convergence

Central area:

0.6 mm (typical)

Peripheral area: 1.0 mm (typical)

Raster size stability H: 1.0%, V: 1.5%

High voltage regulation

4.0 %

Color temperature

D65/D93, selectable

USER (3,200K-10,000K, factory

setting is D65)

Inputs

For PVM-14M4U/14M4E/20M4U/20M4E:

LINE A/B

VIDEO IN

AUDIO IN

BNC connector (×2), 1Vp-p ±6 dB,

sync negative

Automatic 75 ohms termination

Phono jack (×2), -5 dBua), more than

47 kilo-ohms

LINE C

Y/C IN

4-pin mini-DIN (×1) See the pin assignment on page 19.

Phono jack ($\times 1$), -5 dBu^{a} , more than

47 kilo-ohms

RGB/COMPONENT

AUDIO IN

R/R-Y,G/Y,B/B-Y IN: BNC connector (×3)

R, G, B channels: 0.7 Vp-p, ±6 dB

Sync on green: 0.3 Vp-p, negative

R-Y, B-Y channels: 0.7 Vp-p, ±6 dB

Y channel: 0.7 Vp-p, ±6 dB

(Standard color bar signal of 75%

See the pin assignment on page 19.

chrominance)

Automatic 75 ohms termination

Phono jack ($\times 1$), -5 dBu^{a} , more than **AUDIO IN**

47 kilo-ohms

EXT SYNC IN BNC connector (x1)

4 Vp-p, ±6 dB, sync negative

20-pin connector (×1)

a) 0 dBu = 0.775 Vr.m.s.

REMOTE

For PVM-14M2U/14M2E/20M2U/20M2E: LINE A/B BNC connector (x2), 1 Vp-p VIDEO IN ± 6dB, sync negative Automatic 75 ohms termination Phono jack (×2), -5 dBua), more than **AUDIO IN** 47 kilo-ohms LINE C Y/C IN 4-pin mini-DIN (×1) See the pin assignment on page 19. Phono jack ($\times 1$), -5 dBu^{a} , more than **AUDIO IN** 47 kilo-ohms RGB/COMPONENT R/R-Y,G/Y,B/B-Y IN: BNC connector (×3) R, G, B channels: 0.7 Vp-p ± 6dB Sync on green: 0.3 Vp-p negative R-Y, B-Y channel: 0.7 Vp-p ± 6dB Y channel: 0.7 Vp-p ± 6dB (Standard color bar signal of 75% chrominance) Automatic 75 ohms termination Phono jack (×1), -5 dBua), more than **AUDIO IN** 47 kilo-ohms **EXT SYNC IN** BNC connector $(\times 1)$

a) 0 dBu = 0.775 Vr.m.s.

Outputs (common to all models)

LINE A/B

REMOTE

BNC connector (×2) loop-through, VIDEO OUT

Automatic 75 ohms termination

4 Vp-p, ±6 dB, sync negative

See the pin assignment on page 19.

20-pin connector (×1)

AUDIO OUT Phono jack (×2) loop-through

LINE C

Y/C OUT 4-pin mini-DIN (×1) loop-through,

Automatic 75 ohms termination

AUDIO OUT Phono jack (×1) loop-through

RGB/COMPONENT

R/R-Y,G/Y,B/B-Y OUT: BNC connector (×3)

loop-through

Automatic 75 ohms termination Phono jack (×1) loop-through

AUDIO OUT

BNC connector $(\times 1)$ EXT SYNC OUT

Automatic 75 ohms termination

Speaker output

Output level: 0.8 W

General

For PVM-14M4U:

SMPTE-C phosphor CRT

Power consumption 90 Wh (with SDI: 99 Wh)

Power requirements 120 V AC, 50/60Hz

Operating temperature

0 to $+35^{\circ}$ C (32 to 95° F)

Storage temperature -10 to +40°C (14 to 104°F)

Operating humidity 35 to 85% (no condensation)

Storage humidity 0 to 90%

Dimensions (w/h/d) Approx. $346 \times 340 \times 431$ mm

 $(13\frac{5}{8} \times 13\frac{1}{2} \times 17 \text{ inches})$

not incl. projecting parts and controls

Approx. 16.7kg (36 lb 13 oz) Mass

Accessory supplied AC power cord (1)

AC plug holder (1) Tally label (1)

Cable with a 20-pin connector (1)

For PVM-14M4E:

CRT EBU phosphor

Power consumption 90 Wh (with SDI: 99 Wh) Power requirements 100 to 240 V AC, 50/60Hz

Operating temperature

0 to $+35^{\circ}$ C (32 to 95° F)

Storage temperature -10 to +40°C (14 to 104°F) Operating humidity 35 to 85% (no condensation)

0 to 90% Storage humidity

Dimensions (w/h/d) Approx. $346 \times 340 \times 431$ mm

 $(13\frac{5}{8} \times 13\frac{1}{2} \times 17 \text{ inches})$

not incl. projecting parts and controls

Approx. 16.7kg (36 lb 13 oz) Mass

AC power cord (1) Accessory supplied

AC plug holder (1)

Tally label (1)

Cable with a 20-pin connector (1)

For PVM-14M2U:

CRT P-22 phosphor

Power consumption 90 Wh (with SDI: 99 Wh)

Power requirements 120 V AC, 50/60Hz

Operating temperature

0 to +35°C (32 to 95°F)

Storage temperature -10 to +40°C (14 to 104°F) Operating humidity 35 to 85% (no condensation)

0 to 90% Storage humidity

Dimensions (w/h/d) Approx. $346 \times 340 \times 431$ mm

 $(13\frac{5}{8} \times 13\frac{1}{2} \times 17 \text{ inches})$

not incl. projecting parts and controls

Mass Approx. 16.7kg (36 lb 13 oz)

Accessory supplied AC power cord (1)

AC plug holder (1) Tally label (1)

Cable with a 20-pin connector (1)

For PVM-14M2E:

CRT P-22 phosphor

Power consumption 90 Wh (with SDI: 99 Wh) Power requirements 100 to 240 V AC, 50/60Hz

Operating temperature

0 to +35°C (32 to 95°F)

Storage temperature -10 to +40°C (14 to 104°F) Operating humidity 35 to 85% (no condensation)

Storage humidity 0 to 90%

Dimensions (w/h/d) Approx. $346 \times 340 \times 431$ mm

 $(13\frac{5}{8} \times 13\frac{1}{2} \times 17 \text{ inches})$

not incl. projecting parts and controls

Mass Approx. 16.7kg (36 lb 13 oz)

Accessory supplied AC power cord (1)

AC plug holder (1) Taily label (1)

Cable with a 20-pin connector (1)

For PVM-20M4U:

CRT SMPTE-C phosphor

Power consumption 125 Wh (with SDI: 135 Wh)

Power requirements 120 V AC, 50/60Hz

Operating temperature

0 to +35°C (32 to 95°F)

Storage temperature -10 to +40°C (14 to 104°F) Operating humidity 35 to 85% (no condensation)

Storage humidity 0 to 90%

Dimensions (w/h/d) Approx. $450 \times 458 \times 503$ mm

 $(17^{3}/4 \times 18^{1}/8 \times 19^{7}/8 \text{ inches})$

not incl. projecting parts and controls

Mass Approx. 30.0 kg (66 lb 2 oz)

Accessory supplied AC power cord (1)

AC plug holder (1) Tally label (1)

Cable with a 20-pin connector (1)

For PVM-20M4E:

CRT EBU phosphor

Power consumption 130 Wh (with SDI: 140 Wh) Power requirements 100 to 240 V AC, 50/60Hz

Operating temperature

0 to +35°C (32 to 95°F)

Storage temperature -10 to +40°C (14 to 104°F) Operating humidity 35 to 85% (no condensation)

Storage humidity 0 to 90%

Dimensions (w/h/d) Approx. $450 \times 458 \times 503$ mm

 $(17^{3}/4 \times 18^{1}/8 \times 19^{7}/8 \text{ inches})$

not incl. projecting parts and controls

Mass Approx. 30.0 kg (66 lb 2 oz)

Accessory supplied AC power cord (1)

AC plug holder (1) Tally label (1)

Cable with a 20-pin connector (1)

For PVM-20M2U:

CRT P-22 phosphor

Power consumption 115 Wh (with SDI: 125 Wh)

Power requirements 120 V AC, 50/60Hz

Operating temperature

0 to +35°C (32 to 95°F)

Storage temperature -10 to +40°C (14 to 104°F) Operating humidity 35 to 85% (no condensation)

Storage humidity 0 to 90%

Dimensions (w/h/d) Approx. $450 \times 458 \times 503$ mm

 $(17^{3}/4 \times 18^{1}/8 \times 19^{7}/8 \text{ inches})$

not incl. projecting parts and controls

Mass Approx. 30.0 kg (66 lb 2 oz)

Accessory supplied AC power cord (1)

AC plug holder (1) Tally label (1)

Cable with a 20-pin connector (1)

For PVM-20M2E:

CRT P-22 phosphor

Power consumption 120 Wh (with SDI: 130 Wh) Power requirements 100 to 240 V AC, 50/60Hz

Operating temperature

 $0 \text{ to } +35^{\circ}\text{C} (32 \text{ to } 95^{\circ}\text{F})$

Storage temperature -10 to +40°C (14 to 104°F)

Operating humidity 35 to 85% (no condensation)

Storage humidity 0 to 90%

Dimensions (w/h/d) Approx. $450 \times 458 \times 503$ mm

 $(17^{3}/4 \times 18^{1}/8 \times 19^{7}/8 \text{ inches})$

not incl. projecting parts and controls

Mass Approx. 30.0 kg (66 lb 2 oz)

Accessory supplied AC power cord (1)

AC plug holder (1)

Tally label (1)


Cable with a 20-pin connector (1)

Design and specifications are subject to change

without notice.


Pin assignment

Y/C IN connector (4-pin mini-DIN)



Pin No.	Signal	Description
1	Y-input	1 Vp-p, sync negative, 75 ohms
2	CHROMA subcarrier-input	300m Vp-p, burst Delay time between Y and C: within 0 ± 100 nsec., 75 ohms
3	GND for Y-input	GND
4	GND for CHROMA-input	GND

REMOTE connector (20-pin)



Pin No.	Signal	Wire color
1	Blue only	Brown
2	H/V DELAY	Red
3	MAIN/SUB*	Orange
4	EXT SYNC	Yellow
5	DEGAUSS	Green
6	R ch ON/OFF*	Blue
7	TALLY	Purple
8	LINE B	Grey
9	GND	White
10	GND	Black
11	GND	Pink
12 ·	GND	Light Blue
13	LINE A	Spiral Orange
14	LINE/RGB	Spiral Yellow
15	GND	Spiral Green
16	L ch ON/OFF*	Spiral Blue
17	REMOTE	Spiral Purple
18	LINE C	Spiral Grey
19	UNDER SCAN	Spiral Pink
20	16:9	Spiral Light Blue

(* For digital audio control)

How to connect a remote control unit Connect No.17 pin to one of the GND pins (No.9 – 12, and 15), then connect pins for the functions you want to use to other GND pins (No.9 – 12, and 15).

How to light the tally lamp Connect No.7 pin to one of the GND pins (No.9 - 12, and 15).

SAFETY CHECK-OUT

(US Model only)

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

- Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
- Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
- Check that all control knobs, shields, covers, ground straps, and mounting hardware have been replaced. Be absolutely certain that you have replaced all the insulators.
- Look for unauthorized replacement parts, particularly transistors, that were installed during
 a previous repair. Point them out to the customer and recommend their replacement.
- Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
- Check the line cords for cracks and abrasion.
 Recommend the replacement of any such line cord to the customer.
- Check the B+ and HV to see if they are at the values specified. Make sure your instruments are accurate; be suspicious of your HV meter if sets always have low HV.
- Check the metal trim, metallized knobs, screws, and all other exposed metal parts for AC leakage.

Check leakage as described below.


LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5mA (500 microampers). Leakage current can be measured by any one of three methods.

- A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufactures' instructions to use these instruments.
- A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
- 3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)

HOW TO FIND A GOOD EARTH GROUND

A cold-water pipe is guaranteed earth ground; the cover-plate retaining screw on most AC outlet boxes is also at earth ground. If the retaining screw is to be used as your earth-ground, verify that it is at ground by measuring the resistance between it and a cold-water pipe with an ohmmeter. The reading should be zero ohms. If a cold-water pipe is not accessible, connect a 60-100 watts trouble light (not a neon lamp) between the hot side of the receptacle and the retaining screw. Try both slots, if necessary, to locate the hot side of the line, the lamp should light at normal brilliance if the screw is at ground potential. (See Fig. B)






TABLE OF CONTENTS

Sect	tion	<u>Title</u>	Page	Se	ction	<u>Title</u> <u>I</u>	Page
1.	GEN	ERAL		5.	CIR	CUIT ADJUSTMENTS	
	Featur	res	8		5-1.	A Board Adjustments	. 2
	Locati	ion and Function of Parts and Controls	9			•	
1	Using	On-screen Menus	11	6.	DIA	GRAMS	
(Conne	ections	13		6-1.	Block Diagrams (1)	. 3
						Block Diagrams (2)	
2.	DISA	ASSEMBLY			6-2.	Frame Schematic Diagram	
	2-1.	Top Cover and Rear Cover Removal	14		6-3.	Circuit Boards Location	
	2-2.	Terminal Board Removal			6-4.	Printed Wiring Boards and Schematic Diagrams	
	2-3.	J and H Boards Removal				• A Board (1/3)	
:	2-4.	Picture Tube Removal	14			• A Board (2/3)	
:	2-5.	Service Position	15			• A Board (3/3)	
						• Q Board	7
3.	SET-	UP ADJUSTMENTS				• G Board	
	3-1.	Preparations (1)	16			• J Board	7
	3-2.	Preparations (2) Initialization				• X Board	7
	3-3.	Writing Model Data				• H Board	7
	3-4.	Picture Output				• S Board	7
	3-5.	Landing Adjustment				• C Board	8:
	3-6.	Convergence Adjustment (1)			6-5.	Semiconductors	8
(3-7.	Deflection Yoke Neck Rotation Adjustment					
3	3-8.	Convergence Adjustment (2)	22	7.	EXP	LODED VIEWS	
3	3-9.	G2 Adjustment	23		7-1.	Chassis	8
3	3-10.	White Balance Adjustment			7-2.	Picture Tube	90
3	3-11.	Blue-Only White Balance Adjustment	24				
3	3-12.	Sub Brt Adjustment	24	8.	ELE	CTRICAL PARTS LIST	91
3	3-13.	Focus Adjustment	24				
4. \$	SAFE	ETY RELATED ADJUSTMENT	. 25				

(CAUTION)

SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT, AFTER REMOVING THE ANODE.

WARNING!!

AN ISOLATION TRANSFORMER SHOULD BE USED DURING ANY SERVICE TO AVOID POSSIBLE SHOCK HAZARD, BECAUSE OF LIVE CHASSIS.

THE CHASSIS OF THIS RECEIVER IS DIRECTLY CONNECTED TO THE AC POWER LINE.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK A ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL FOR SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL FOR SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

(ATTENTION)

APRES AVOIR DECONNÈCTE LE CAP DE L'ANODE, COURT-CIRCUITER L'ANODE DU TUBE CATHODIQUE ET CELUI DE L'ANODE DU CAP AU CHASSIS METALLIQUE DE L'APPAREIL, OU AU COUCHE DE CARBONE PEINTE SUR LE TUBE CATHODIQUE OU AU BLINDAGE DU TUBE CATHODIQUE.

ATTENTION!!

AFIN D'EVITER TOUT RESQUE D'ELECTROCUTION PROVENANT D'UN CHÁSSIS SOUS TENSION, UN TRANSFORMATEUR D'ISOLEMENT DOIT ETRE UTILISÉ LORS DE TOUT DÉPANNAGE. LE CHÁSSIS DE CE RÉCEPTEUR EST DIRECTEMENT RACCORDÉ À L'ALIMENTATION SECTEUR.

ATTENTION AUX COMPOSANTS RELATIFS À LA SÉCURITÉ!!

LES COMPOSANTS IDENTIFIÈS PAR UNE TRAME ET PAR UNE MARQUE À SUR LES SCHÉMAS DE PRINCIPE, LES VUES EXPLOSÉES ET LES LISTES DE PIECES SONT D'UNE IMPORTANCE CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT. NE LES REMPLACER QUE PAR DES COMPOSANTS SONY DONT LE NUMÉRO DE PIÉCE EST INDIQUÉ DANS LE PRÉSENT MANUEL OU DANS DES SUPPLÉMENTS PUBLIÉS PAR SONY. LES RÉGLAGES DE CIRCUIT DONT L'IMPORTANCE EST CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT SONT IDENTIFIES DANS LE PRÉSENT MANUEL. SUIVRE CES PROCÉDURES LORS DE CHAQUE REMPLACEMENT DE COMPOSANTS CRITIQUES, OU LORSQU'UN MAUVAIS FONCTIONNEMENT EST SUSPECTÉ.

SECTION 1 GENERAL

the Operating Instruction Manual. The page numbers of the The operating instructions mentioned here are partial abstracts from Operating Instruction Manual remain as in the manual.

Features

Picture

Horizontal resolution is more than 800 TV lines at the HR Trinitron tube provides a high resolution picture. HR (High Resolution) Trinitron " picture tube for PVM-14M4U/14M4E/20M4U/20M4E center of the picture.

Horizontal resolution is more than 600 TV lines at the Trinitron tube provides a high resolution picture. for PVM-14M2U/14M2E/20M2U/20M2E Trinitron¹⁾ picture tube center of the picture.

activates to make more accurate Y/C separation. This When NTSC video signals are received, a comb filter contributes to less of a decrease in resolution, cross color and cross luminance phenomena. Comb filter

The built-in beam current feedback circuit assures Beam current feedback circuit stable white balance.

when no cable is connected to the loop-through output The input connector is terminated at 75 ohms inside connector, the 75-ohm termination is automatically connector. When a cable is connected to an output (connector with -\\rangle mark only) Automatic termination released.

display is obtained with all three cathodes driven with

In the blue only mode, an apparent monochrome

Blue only mode

a blue signal. This facilitates color saturation and phase adjustments and observation of VCR noise.

The monitor can display NTSC, PAL, SECAM and NTSC4432) signals. The appropriate color system is

selected automatically.

Four color system available

Functions

The signal normally scanned outside of the screen can be monitored in the underscan mode. Underscan mode

Analog RGB or component (Y, R-Y and B-Y) signals

Analog RGB/component input connectors from video equipment can be input through these

Input

RGB scanning lines may appear on the top edge of the When the monitor is in the underscan mode, the dark screen. These are caused by an internal test signal, rather than the input signal.

> and the luminance signal (Y), can be input through this two signals, which tends to occur in a composite video

connector, eliminating the interference between the

signal, ensuring video quality.

When the EXT SYNC selector is in the on position,

External sync input

the monitor can be operated on the sync signal supplied from an external sync generator.

The video signal, split into the chrominance signal (C)

Y/C input connectors

connectors.

checked simultaneously in the H/V delay mode. The horizontal and vertical sync signals can be Horizontal/vertical delay mode

automatically when the power is turned on, or manually by pressing the DEGAUSS button. Degaussing of the screen can be performed Auto/manual degaussing

On-screen menus

connect is less than 2,010,000, an optional connecting namess (part no. 1-900-230-35) will be required. Serial Remote Interface Kit You can set color temperature, CHROMA SET UP, and other settings by using the on-screen menus.

You can select the menu language from among five Five menu languages languages on the menu.

By using an MB-502B mounting bracket (for a 14-inch monitor, not supplied) or SLR-103A slide rail (for a 20-inch monitor, not supplied), the monitor can be EIA standard 19-inch rack mounting mounted in an EIA standard 19-inch rack.

For details on mounting, refer to the instruction manuals supplied with the mounting bracket kit or slide rail kit.

SDI (Serial Digital Interface) Kit


When the serial number of the BKM-101C you want to By using the following optional SDI Kits, the monitor can display SMPTE 259M 4:2:2 serial digital signal - BKM-101C: Component SDI Kit (for video) - BKM-102: Component SDI Kit (for audio) from a digital VCR. (ex. Sony 4:2:2 VCR)

personal computers via the RS-422A serial interface. Interface Kit, the monitor can be controlled from By using the optional BKM-103 Serial Remote

^{1) &}quot;Trinitron" is a registered trademark of Sony Corporation.

The NTSC.4.0 system refers to an NTSC color system in which the subcarrier frequency is modified to 4.43MHz. When
all NTSC (EURIGE) VICE) program is played back with a Trident (PAL/SECAMNTSC.4.3) VTR, the NTSC.4.3 signal is

Location and Function of Parts and Controls



Lights up when the video camera connected to this monitor is selected, indicating that the picture is being

For details on how to light the tally lamp, see page 19.

recorded

POWER switch and indicator

Depress to turn on the monitor. The indicator will light

© REMOTE indicator

menu (see page 13), or when you connect a supplied cable to the REMOTE connector. The controls on the Lights up when you select ON on the USER PRESET front panel do not work when this indicator lights up. For details on how to connect the cable, see page 19.

ium this control clockwise or counterclockwise to obtain the desired volume **O VOLUME** control

furn this control clockwise to make the contrast higher **©** CONTRAST control

or counterclockwise to make it lower.

NTSCAM color systems. Turn it clockwise to make the skin tones greenish or counterclockwise to make them This control is effective only for the NTSC and D PHASE control

CHROMA control

Turn this control clockwise to increase the brightness Turn this control clockwise to increase the color intensity or counterclockwise to decrease it. BRIGHT (brightness) control

Turn this control clockwise to increase sharpness or APERTURE control

or counterclockwise to decrease it.

counterclockwise to decrease sharpness.

The PHASE (6), CHROMA (4) and APERTURE (19) controls have no effect on the pictures of RGB ignals.

MENU (EXIT) button

When a menu is on the display, you can return to the Press this button to display the main menu.

previous menu by pressing this button.

Press the button to confirm a selected item on the **D** ENTER (SELECT) button

(+)/ (-) buttons

Press the buttons to move the cursor (*) or adjust selected item on the menu.

Press this selector (light on) to monitor the signals of ■ 16:9 selector

H/V DELAY selector 16:9 picture.

Press this selector (light on) to observe the horizontal The horizontal sync signal is displayed in the left quarter of the screen; the vertical sync signal is and vertical sync signals at the same time. displayed near the center of the screen. **©** UNDER SCAN selector

The display size is reduced by approximately 5% so Press this selector (light on) for underscanning. that four corners of the raster are visible.

BLUE ONLY selector RESET button

"chroma" and "phase" adjustments and observation "Phase" adjustment is effective only for the NTSC monochrome picture on the screen. This facilitates As the BLUE ONLY selector, press this selector (light on) to eliminate the red and green signals. Only blue signal is displayed as an apparent of VCR noise.

settings by pressing this button when a menu is on · As the RESET button, you can reset the menu

DEGAUSS button

Press this button momentarily. The screen will be demagnetized. Wait for 10 minutes or more before using this button again.

EXT SYNC (external sync) selector

Set this selector to the off position (light off) to operate the monitor on the sync signal from the displayed video signal.

Principle of the Control of the Cont

· Set this selector to the on position (light on) to operate the monitor on an external sync signal through the EXT SYNC connector.

LINE/RGB input selector

Press this selector to select the input to be monitored. monitor the signal through the LINE A, LINE B or · Set this selector to the off position (light off) to LINE C connectors.

monitor the signal through the RGB/COMPONENT Set this selector to the on position (light on) to connectors.

C/SDI selector

LINE position (light off), press this selector (light on) to monitor the signal through the LINE C · When the LINE/RGB input selector is set to the connectors.

RGB position (light on), press this selector (light on) to monitor the SDI signal (optional kits are required). When the LINE/RGB input selector is set to the

B/COMPONENT selector

LINE position (light off), press this selector (light · When the LINE/RGB input selector is set to the on) to monitor the signal through the LINE B connectors

RGB position (light on), press this selector (light on) to monitor the component signal through the RGB/ When the LINE/RGB input selector is set to the COMPONENT connectors.

A√HGB selector

LINE position (light off), press this selector (light When the LINE/RGB input selector is set to the on) to monitor the signal through the LINE A

RGB position (light on), press this selector (light on) When the LINE/RGB input selector is set to the to monitor the RGB signal through the RGB/ COMPONENT connectors.

Location and Function of Parts and Controls



(The -\\\r mark indicates automatic termination.) 30 EXT SYNC 0 0 Rear Panel Y-W **Z** A Outro LINE B **Z**0 30 LINE A AUDIO 0 Ô

AC IN socket

Connect the supplied AC power cord to this socket and to a wall outlet.

DLINE A, LINE B connectors

Two groups (A and B) of line input connectors for the composite video and audio signals and their loopthrough output connectors.

set the LINE/RGB selector to the LINE position (light off) and press the A/RGB or B/COMPONENT selector To monitor the input signal through these connectors, (light on).

VIDEO IN (BNC)

Connect to the video output of video equipment, such For a loop-through connection, connect to the video as a VCR or a color video camera. output of another monitor.

VIDEO OUT (BNC)

Loop-through output of the VIDEO IN connector. Connect to the video input of a VCR or another When the cable is connected to this connector, the 75-ohm termination of the input is automatically released, and the signal input to the VIDEO IN connector is output from this connector.

AUDIO IN (phono jack)

For a loop-through connection, connect to the audio microphone via a suitable microphone amplifier. Connect to the audio output of a VCR or to a AUDIO OUT (phono jack) output of another monitor.

Connect to the audio input of a VCR or another monitor.

Loop-through output of the AUDIO IN connector.

Connect to the Y/C separate output of a video camera. For a loop-through connection, connect to the Y/C VCR or other video equipment. Y/C IN (4-pin mini-DIN) **© LINE C connectors**

separate output of a VCR or another monitor.

Connect to the Y/C separate input of a VCR or another Loop-through output of the Y/C IN connector. Y/C OUT (4-pin mini-DIN) monitor.

When the cable is connected to this connector, the 75-ohm termination of the input is automatically released, and the signal input to the Y/C IN connector is output rom this connector,

Connect to the audio output of a VCR or a microphone (via a suitable microphone amplifier). AUDIO IN (phono jack)

Loop-through output of the AUDIO IN connector. Connect to the audio input of a VCR or another AUDIO OUT (phono jack) monitor.

special-effect generator, etc. The tally lamp on the Connect to the tally output of a control console, ① REMOTE connector (20-pin)

front panel will be turned on and off by the connected equipment. This connector can also be used for connecting a remote control unit.

For details on the pin assignment of this connector, see page 19.

RGB signal or component signal input connectors and B RGB/COMPONENT connectors

To monitor the input signal through these connectors, set the LINE/RGB selector to the RGB position (light on), and press the A/RGB or B/COMPONENT their loop-through output connectors. selector (light on).

When the EXT SYNC selector is set to the off position (light off), the monitor operates on the sync signal R/R-Y IN, G/Y IN, B/B-Y IN (BNC) from the G/Y channel.

Connect to the analog RGB signal outputs of a video To monitor the RGB signal camera, etc.

Connect to the R-Y/Y/B-Y component signal outputs of a Sony Betacam video camera, etc. To monitor the component signal

R/R-Y OUT, G/Y OUT, B/B-Y OUT (BNC)

When the cables are connected to these connectors, the Loop-through outputs of the R/R-Y IN, G/Y IN, B/Breleased, and the signal inputs to the R/R-Y IN, G/Y 75-ohm termination of the inputs is automatically IN, B/B-Y IN connectors are output from these Y IN connectors.

Connect to the analog RGB signal inputs of a video To output the RGB signal printer or another monitor.

Connect to the R-Y/Y/B-Y component signal inputs of To output the component signal a Betacam video recorder, etc.

Connect to the audio output of video equipment when AUDIO IN (phono jack)

the analog RGB or component signal is input.

Loop-through outputs of the AUDIO IN connector AUDIO OUT (phono jack)

Press the EXT SYNC selector (light on) to use the sync signal through this connector. **©** EXT SYNC (external sync) connectors

When this monitor operates on an external sync signal, connect the reference signal from a sync generator to this connector. IN (BNC)

When the cable is connected to this connector, the 75-ohm termination of the input is automatically released, Loop-through output of the IN connector. Connect to the external sync input of video equipment to be synchronized with this monitor. OUT (BNC)

and the signal input to the IN connector is output from


this connector.

Using On-Screen Menus

ou can make various settings and adjustments of the monitor using the on-screen menus.

On-Screen Menu Configuration


On-screen menu tree-chart



Operation through On-Screen Menus

Menu operation buttons


There are five menu operation buttons on the front panel of the monitor.



The following table shows how these five buttons function when using the menus.

	To select menu hem	1
	To adjust the lien selected	
MENU	return to the previous menu	C.
EXIT	return to the previous menu)
ENTER	decide a selected item	
-	select an adjustment item	
+	move the cursor (>) upwards	4
	increase selected value	
+	move the cursor (>) downwards	L
	decrease selected value	ဂ
6 RESET	reset current settings to the factory	
	Sumae	

adjustment screens are displayed at the bottom of the screen. You can perform menu operation using the displayed buttons. The buttons that can be used on the menus and



Display of the usable menu operation buttons

Operating procedures

To display the menu, follow this procedure.

1 Press the MENU/EXIT (10) button.

MENU (11 : main menu) appears.

Move the cursor (\blacktriangleright) to the desired setting menu by pressing the \blacklozenge /- or \P /+ (\P , Θ) button. C

Press the ENTER/SELECT (2) button.

The setting menu selected in step 2 appears.

Move the cursor (\triangleright) to the desired item by pressing the \checkmark /- or \uparrow /+ (\bigcirc , \bigcirc) button.

Press the ENTER/SELECT (2) button.


The adjustment screen or setting menu selected in step 4 appears.

For detailed information of menus, see \(\textit{Functions of On-Screen Menust on page 12.} \)

¹⁾ ⑤ CAPTION VISION mean is provided with PVM-14M4U/14M2U/20M4U/20M2U only.
2) ❷ LANDING screen is provided with PVM-20M4U/20M4E only.

Using On-Screen Menus

To display the next (or previous) page of the Select NEXT PAGE on the menu to display the next page and PREVIOUS PAGE on the menu to display the previous page.



How to display the next or the previous page

Each time you press the MENU/EXIT () button, the To close the menu (to return to the regular displayed. Press the MENU/EXIT (1) button on-screen menu returns to the one previously repeatedly until the regular screen appears. screen)

For PVM-14M4E/14M2E/20M4E/20M2E: For the first time when the monitor is turned on, the LANGUAGE menu (23) will appear on the screen. So, select the language you want to use.



Move the cursor (▶) to the desired language by pressing the 4/- or 4/+ (0, 0) button.

Press the MENU/EXIT (1) button.

N

Unless you press the MENU/EXIT (1) button in the procedure above, the LANGUAGE menu will always appear whenever you turn on the monitor.

Functions of On-Screen Menus

There are four types of on-screen menus.

select NEXT PAGE.

You can enter another menu such as status menu or Main menu

6b USER CONFIG 2 menu Select an item to adjust on the menus and screens (20

through [24]). To go to the USER CONFIG I menu

select PREVIOUS PAGE.

setting menu.

Status menu
You can confirm the current settings.

screen on this menu by using the **†**/+, **↓**/- and You can select an item or enter an adjustment ENTER/SELECT buttons. Setting menu

adjustments you made remain unchanged until next You can make adjustments on this screen. The change even if you turn off the power. Adjustment screen

([] indicates the factory setting.)

[] Main menu Select another menu and press ENTER/SELECT to go to the menu.

2a STATUS 1 menu Shows the current settings.

2b STATUS 2 menu Shows what optional kit is installed in the monitor.

"phase" (NTSC signal only) adjustments done on the AUTO ADJUST screen ([7]). 3CHROMA SET UP menu Select ON on this menu to activate "chroma" and

[D65] and USER. USER is set to D65 as the factory setting. Select the color temperature from among D65, D93 You can adjust or change the color temperature in USER mode (a measuring instrument is required). 4 COLOR TEMP/BAL menu

[5]CAPTION VISION menu This menu is provided only for PVM-14M4U/14M2U/ 20M4U/20M2U. Vision. To display it, select the caption type in this The monitor can display the signal with Caption

[OFF]

Finely adjust the selected item on the SUB CONTROL menu (14). Each control (CONTRAST, BRIGHT, CHROMA and PHASE control) has a click position at SSUB CONTROL screen Select an item to adjust on the menus and screens ([12] through [19]). To go to the USER CONFIG 2 menu,

if you select ON on this menu, the REMOTE indicator the center of its adjustment range. You can adjust the lights up and the controls on the front panel do not work. The monitor operates with the user preset setting of the click position with this feature. 16 USER PRESET menu

CONTRAST, VOLUME, and APERTURE controls to a desired level and can use these settings by selecting ON on the USER PRESET menu ([16]). (ou can preset the BRIGHT, CHROMA, PHASE, 17 PRESET ADJUST menu

[OFF]

To adjust the user preset settings, select the PRESET ADJUST menu (①).

settings.

press ENTER/SELECT to start automatic "chroma"

To activate these adjustments, select ON on the CHROMA SET UP menu (3). and "phase" (NTSC signal only) adjustments.

8ADJUST GAIN screen Adjust GAIN in USER mode. 9 ADJUST BIAS screen Adjust BIAS in USER mode.

Select the color bar signal (full, SMPTE, EIA) and

7 AUTO ADJUST screen

PHASE, CONTRAST, VOLUME, and APERTURE control) on the PRESET ADJUST menu ([17]). Adjust the selected item (BRIGHT, CHROMA, 18 PRESET ADJUST screen

When you cannot read the display, select the input that Adjust the vertical hold if the picture rolls vertically. 19 V HOLD screen is not connected.

Store the factory setting of D65 or D93 as the value for

USER mode.

11]USER COPY menu

12 COLOR SYSTEM DISPLAY menu

each time you change the signal input.

[5000K-10000K]

Select the color temperature range in USER mode.

10 COLOR TEMP RANGE menu

Select the component level from among three modes. For PVM-14M4U/14M2U/20M4U/20M2U for 100/7.5/75/7.5 signal N10/SMPTE for 100/0/100/0 signal for 100/0/75/0 signal 20 COMPONENT LEVEL menu **BETA 7.5** BETA 0 the color system type being used appears on the screen Select the color system type. When AUTO is selected,

[N10/SMPTE] Sor PVM-14M4E/14M2E/20M4E/20M2E

[OFF]

Color spill or color noise may be eliminated if you select ON (NTSC signal only).

13358 TRAP FILTER menu

Select an item (CONTRAST, BRIGHT, CHROMA

14SUB CONTROL menu

Normally select OFF.

and PHASE controls on the front panel) to finely

adjust on the SUB CONTROL screen ([15])

Using On-Screen Menus-

For PVM-14M4E/14M2E/20M4E/20M2E

Select the NTSC setup level from two modes. 21NTSC SETUP LEVEL menu

[7.5] [0] The 7.5 setup level is mainly used in north America. For PVM-14M4U/14M2U/20M4U/20M2U The 0 setup level is mainly used in Europe.

22ACC menu

Set ACC (Auto Color Control) circuit on or off. When the fine adjustment is necessary, select OFF on the ACC menu. <u>N</u>0

Normally select ON.

23LANGUAGE menu You can select the menu language from among five languages (English, German, French, Italian, Spanish). [ENGLISH]

24LANDING screen

If the color is not uniform even after you press the DEGAUSS button, you can adjust the landing so as to This menu is provided only for PVM-20M4U/20M4E. The following two methods are available to adjust the obtain color uniformity on this screen.

When the signals of the horizontal lines are input

landing.

Press the \$\int \- or \$\frac{1}{4} + button until the lines are and displayed:

When the signals of the white color are input and displayed on the screen as horizontally as possible.

Press the \$\int-\ or \$\epsilon \tau \text{button until the white color on} the screen become at uniform as possible.

To reset the setting to standard (00), press the RESET button.

Connections


How to Connect the AC Power Cord

Pull out the AC plug holder while pressing the lock


To remove the AC power cord

Connect the AC power cord (supplied) to the AC IN socket and to a wall outlet. How to Connect a Cable to a BNC Connector






To connect an AC power cord securely with an AC plug holder



connector on the rear panel, matching the slit and pin, and turn the BNC plug clockwise to secure the connection.

Insert the BNC plug into the

Plug the power cord into the AC IN socket. Then, attach the AC plug holder (supplied) on top of the AC power




Slide the AC plug holder over the cord until it locks.


4

SECTION 2 DISASSEMBLY


2-1. TOP COVER AND REAR COVER REMOVAL



2-2. TERMINAL BOARD REMOVAL




2-3. J AND H BOARDS REMOVAL




2-4. PICTURE TUBE REMOVAL

When exchange the Picture tube of PVM-20M4 series and if the magnet had stuck on the neck of the Picture tube, peel it.




2-5. SERVICE POSITION




• REMOVAL OF ANODE-CAP


NOTE: Short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT shield or carbon paint on the CRT, after removing the anode.



• REMOVING PROCEDURES



① Turn up one side of the rubber cap in the direction indicated by the arrow ②.



- 2 Using a thumb pull up the rubber cap firmly in the direction indicated by the arrow 6.
- When one side of the rubber cap is separated from the anode button, the anode-cap can be removed by turning up the rubber cap and pulling up it in the direction of the arrow ①.

• HOW TO HANDLE AN ANODE-CAP

- ① Don't hurt the surface of anode-caps with sharp shaped material!
- ② Don't press the rubber hardly not to hurt inside of anodecaps! A material fitting called as shatter-hock terminal is built in the rubber.
- 3 Don't turn the foot of rubber over hardly! The shatter-hook terminal will stick out or hurt the rubber.





SECTION 3 SET-UP ADJUSTMENTS

3-1. PREPARATIONS (1)

Service Mode

This set is provided with a switch for service on the front panel that can be used to make various adjustments. The operation method of this switch is explained in detail below.

1. Entering the service mode

Simultaneously press the [ENTER] key and the [DEGAUSS] key shown on the display of the menu.

2. Service mode display

(1)	(5)	(4)	(3)	(6)
(2)				

Range of Service Mode Display

- The service items are largely classified into 16 types displayed by titles.
- (2) The names of the service items or READ/WRITE guidance, etc., are displayed. The names are displayed to the left and the guidance to the right.
- (3) This is the serial number for each of the service items. 1-120.
- (4) This is the adjustment data for the service items that are now stored in the RAM. Adjustments can be made by changing these values, but as long as nothing is written to the ROM the adjustment values will be erased by turning off the power or by reading, so please be careful.
- (5) When the adjustment data that is now displayed is identical with the data in the ROM, the cursor (►) is displayed.
- (6) The present status is displayed.
 - [*]: Writing to the ROM. Make sure not to turn off the power while this display is on.
 - [?]: ROM reading error. In this case, an image is output with the standard adjustment data that the microcomputer itself possesses. [¿]: Problem in the I2C bus.

3. Finishing the service mode

Simultaneously press the [ENTER] key and the [DEGAUSS] key shown on the display of the menu.

4. Easy ON/OFF of the service mode

If once entering the service mode after having turned on the power, easy ON/OFF is possible by once more pressing the A, B or C switch on the front panel (the LED lights) as long as the power is not turned off or as long as the service mode is not finished.

5. Change of position of the service mode display

If the switch is continuously pressed when turning on in the above easy mode, the display position moves in the V direction. This method is used when the display is outside of the effective screen area.

6. Change of service items

The items are returned with the [MENU] key and forwarded with the [ENTER] key. When a key is continuously pressed, the operation will be repeated.

7. Change of service data

The service data is made larger with the [†] key and smaller with the [‡] key. When continuously pressing the keys, the operation will be repeated.

8. Reading of service data

When reading data from the ROM to the RAM, press the [B / O] key once and check than the READ display is shown in the guidance, and then press the [B/O] key once again. The adjustment data that is written will return to its previous state, so please be careful.

9. Writing of service data

When writing data from the RAM to the ROM, press the [DE-GAUSS] key once and check that the WRITE display shown in the guidance, and then press the [DEGAUSS] key once again. Not only the displayed data will be written, but all data, so please be careful.

10. Carrying out FACTORY RESETTING

In case the adjustment data has been destroyed for some reason, and you keep pressing the [B/O] key at the beginning of the above reading, the READ guidance will change to FACTORY RESET guidance in approximately 3 seconds so that the factory resetting can be carried out. By once again pressing the [B/O] key after this, resetting will be carried out ([*] will be displayed as status) and factory resetting will be executed. However, in case the data available at the time of shipment from the factory has been destroyed, or if the ROM has been replaced, etc., or if factory setting mentioned later on has been carried out, factory resetting is executed.

11. Carrying out FACTORY SETTING

Make sure to make possible the above factory resetting by making a copy of the adjustment data when replacing the ROM. If you keep pressing the [DEGAUSS] key at the beginning of the above writing, the WRITE guidance will change into FACTORY RESET guidance after approximately 3 seconds. By once again pressing the [DEGAUSS] key after this, setting will be carried out ([*] will be displayed as status) and the data will be copied. By carrying out this operation, the selection items of the menu and the adjustment values will be reset to the standard conditions, so please be careful. If this operation is carried out once, it cannot be carried out again, but the FACTORY SET FLAG (No. 120) in the service mode can be set to 1.

** Signify (The setting is vary with the destination.)
Refer to the "Table 3-1 Table map (2)."

No.	SERVICE ITEM	T The state of the	MAX	STD	No.	SERVICE ITEM		MAX	STD
1	NOR 50 DEF	H FREQUENCY	255	85	61	C/T1 D??	BIAS <red></red>	1023	376
2		VIDEO PHASE	255	139	62		BIAS <green></green>	1023	512
3		V SIZE	255	139	63		BIAS <blue></blue>	1023	396
4	NOR 60 DEF	H FREQUENCY	255	96	64		GAIN <red></red>	1023	660
5	NOTT GO DEF	VIDEO PHASE	255	115	65		GAIN < GREEN>	1023	620
6		V SIZE	255	137	66		GAIN <blue></blue>	1023	602
7	NORDEF	V CENTER	255	103	67		B/O <red></red>	255	115
	NONDEL			_	-				
8		HSIZE	255	108	68	C/T2 D??	B/O <green></green>	255	115
9		PIN PHASE	255	128	69	C/12 D??	3200K SW	1	0
10		PIN AMP	255	128	70		BIAS <red></red>	1023	256
11		LOWER PIN AMP	255	128	71		BIAS <green></green>	1023	512
12		UPPER PIN AMP	255	128	72		BIAS <blue></blue>	1023	512
13		SEXY	255	128	73		GAIN <red></red>	1023	602
14		V LINEARITY	255	120	74		GAIN <green></green>	1023	700
15		V BOW	63	32	75		GAIN <blue></blue>	1023	672
16		LOWER BOW	63	32	76		B/O <red></red>	255	95
17		V ANGLE	63	32	77		B/O <green></green>	255	108
18	U/S DEF	V SIZE <50>	255	100	78	W/B	SUB CON <4 :3,NORMAL>	255	178
19	0/0 0 2 1	V SIZE <60>	255	100	79	,0	SUB CON <4:3,HN/ DELAY>	255	97
		HSIZE	255	118	80		SUB CON <16 : 9,NORMAL>	255	150
20		PIN PHASE	255	_	_	· · · · · · · · · · · · · · · · · · ·	SUB CON <16 : 9,H/V DELAY>	255	78
21				128	81				_
22		PIN AMP	255	100	82		SUB BRIGHT	255	69
23	16 : 9 NOR DEF	V SIZE <50>	255	72	83		USER B/O <red></red>	255	115
24		V SIZE <60>	255	60	84		USER B/O <green></green>	255	115
25		PIN PHASE	255	135	85	OTHER	LANDING	255	64
26		PIN AMP	255	90	86		VHOLD	255	128
27	16:9 U/S DEF	V SIZE <50>	255	ଶ	87		H BLANKING	255	73
28		V SIZE <60>	255	39	88		V BLANKING <50>	255	82
29		PIN PHASE	255	135	89		16:9 BLANKING START <50>	255	32
30		PIN AMP	255	65	90		16:9 BLANKING END <50>	255	176
31	COMPONENT	SUB PHASE	255	130	91		V BLANKING <60>	255	161
32		SUB CHROMA <normal></normal>	255	182	92		16:9 BLANKING START <50>	255	42
33		SUB CHROMA <smpte></smpte>	255	170	93		16 : 9 BLANKING END <50>	255	226
34		R-Y LEVEL	255	163	94		H DELAY	255	142
35	NTSC	BURST GATE PULSE WID TH	255	52	95		V DELAY	255	104
	11130	CRYSTAL	255	59	96		HP POSITION	255	145
36							HP WIDTH <normal></normal>	255	
37		PHASE <normal></normal>	255	80	97				148
38		PHASE <acc off=""></acc>	255	96	98	O. IOTEL .	HP WIDTH <h delay="" v=""></h>	255	62
39		B-Y PHASE	255	162	99	SYSTEM	SDI AUDIO	7	5
40		CHROMA < NORMAL>	255		100		358 TRAP FILTER	1	0
41		CHROMA <acc off=""></acc>	255	27	101		ACC	1	0
42		R-Y LEVEL	255	98	102		CAPTION VISION	7	0
43	NTSC 443	CRYSTAL	255	82	103		COMPONENT LEVEL	3	*
44		PHASE <normal></normal>	255	62	104		NTSC SETUP LEVEL	1	*
45		PHASE <acc off=""></acc>	255	64	105		CHROMA SET UP	1	0
46		B-Y PHASE	255	181	106		COLOR SYSTEM DISPLAY	3	0
47		CHROMA <normal></normal>	255	104	107		COLOR TEMPERATURE	3	0
48		CHROMA <acc off=""></acc>	255	36	108		USER PRESET	1	0
49		R-Y LEVEL	255	100	109		LANGUAGE	7	- 0
50	PAL	PHASE <normal></normal>	255	110	110		RGB SYNC	_	
	IAL	PHASE < ACC OFF>	255	105	111		OPTION BOARD	1	0
51								7	
52		B-Y PHASE	255	122	112		AGING MODE	1	0
53		CHROMA < NORMAL>	255	109	113		PAL-M	1	0
54		CHROMA <acc off=""></acc>	255	41	114		MODEL	31	*
55		R-Y LEVEL	255	121	115		COLOR TEMP DISP 1	127	*
	SECAM	CHROMA	255	93	116		COLOR TEMP DISP 2	127	*
56	O-0. 411				447		REMOTE ADDRESS	63	0
	020, 411	R-Y LEVEL	255	181	117		NEWIOTE ADDRESS	တ၂	-
56	020/111	R-Y LEVEL COLOR BALANCE <r-y></r-y>	255 255	181	117		RESERVED 1	1	0
56 57	220.411								

Table 3-1 Table map (2)

Model Name	Component level	NTSC Set-up level	Model	Color temp disp 1	Color temp disp 2
PVM-20M4U	1	1	0	65	93
PVM-20M2U	1	1	1	65	93
PVM-20M4J	2	0	2	93	65
PVM-20M4E	2	0	3	65	93
PVM-20M2E	2	0	4	65	93
PVM-14M4U	1	1	5	65	93
PVM-14M2U	1	1	6	65	93
PVM-14M4J	2	0	7	93	65
PVM-14M1J	2	0	8	93	65
PVM-14M4E	2	0	9	65	93
PVM-14M2E	2	0	10	65	93
PVM-20M4A	2	0	11	65	93
PVM-14M4A	2	0	12	65	93
PVM-14M2A	2	0	13	65	93
PVM-14M4B	1	1	14	65	93
BVM-14M4DJ	2	0	15	93	65
BVM-14M4DE	2	0	16	65	93
PVM-20M4T	2	0	17	93	65
PVM-14M4T	1	0	18	93	65

3-2. Preparation (2). Initialization

Supply composite video or component signals as shown in Table 3-2.

Table 3-2

Signal		Details of signal	Standard level P-W
Composite	358NT)	100% white	0.714V
video	443NT }	75% white	0.536V
	PALM	100% white	0.7V
	SECAM	75% white	0.525V
		100% white Y	0.7V
	BETA0	75% white Y	0.525V
		75%color B-Y, R-Y	
Component		(P-P for this item only)	0.7V
·		100% white Y	0.7V
	SMPTE	75% white Y	0.525V
		75%color B-Y, R-Y (P-P for this item only)	0.525V
Voice	/sound	-5dBs	0.436Vrms

^{*} Refer to Table 3-3 for groups of models.

Table 3-3

Group of models		Models	
1	PVM-14M4U PVM-14M4A	PVM-14M4J	PVM-14M4E
2	PVM-14M2U	PVM-14M2E	PVM-14M2A
3	PVM-14M1J		
4	PVM-20M4U PVM-20M4A	PVM-20M4J	PVM-20M4E
5	PVM-20M2U	PVM-20M2E	

^{*} In this chapter, indicates the control items in the service

Example: 60 H-FREQ

3-3. Writing model data

1. Write model data on respective models in the service mode at the location of No.114 MODEL in accordance with Table 3-4.

Table 3-4

Model	Model data
PVM-20M4U	0
PVM-20M2U	1
PVM-20M4J	2
PVM-20M4E	3
PVM-20M2E	4
PVM-14M4U	5 .
PVM-14M2U	6
PVM-14M4J	7
PVM-14M1J	8
PVM-14M4E	9
PVM-14M2E	10
PVM-20M4A	11
PVM-14M4A	12
PVM-14M2A	13

2. Write the following data in the service mode at the location of No.115 COLOR TEMP DISP 1.

COLOR TEMP DISP 1

U/C, AEP

<u>65</u> 93

3. Write the following data in the service mode at the location of No.116 COLOR TEMP DISP 2.

COLOR TEMP DISP 2

U/C, AEP

65

Standard inspection state Unless otherwise specified in this manual, make adjustment under the following conditions:

APERTURE	MIN	(Turn FLAT fully counterclockwise.)
BRIGHT	50%	(Center click)
CHROMA	50%	(Center click)
PHASE	50%	(Center click)
CONTRAST	80%	(Center click)
VOLUME	50%	

^{*} Before turning off the power after adjustment in the service mode, write the adjustment data. When the power is turned off before writing, adjusted data will all be lost.

3-4. Picture output

1. AC input voltage setting


- 1. Input VIDEO signals and AUDIO signals to respective terminals on the connector panel.
- 2. Set the sliduck AC voltage as shown in Table 3-5.

Table 3-5

Group o	Voltage	
PVM-14M4J(J) PVM-14M1J(J)	PVM-20M4J(J)	AC 100±3V (Distortion factor:3% max.)
PVM-14M4U(U/C) PVM-20M2U(U/C)	PVM-14M2U(U/C) PVM-20M4U(U/C)	AC 120±3V (Same as above)
PVM-14M4E(AEP) PVM-14M2A(AUS) PVM-20M4E(AEP) PVM-20M4A(AUS)	PVM-14M2E(AEP) PVM-14M4A(AUS) PVM-20M2E(AEP)	AC 220±3V (Same as above)

3-5. Landing adjustment

- 1. CONT ... MAX
 BRT ... Conspicuous position
 - Roughly adjust the white balance, G2, and convergence.
- Switch the rotary SW of the single color switch to change the color into green only.
- 4. Adjust the purity knob so that the green will come to the center of the screen. Make R and B almost identical. (Fig. 3-1)
- 5. Switch to B only, R only, and G only and verify each. (Figs.3-1, 3-2, and 3-3)
- Bring the deflection yoke gradually forward and adjust the deflection yoke so that R and B on both sides of the screen will be green. (Fig.3-2 → Fig. 3-3)
- If the deflection yoke comes forward too much, the pattern shown in Fig.3-4 will appear. If so, move the deflection yoke backward. (Fig.3-4 → Fig.3-3)
- 8. Switch the single color switch to B and verify the single color. (Fig.3-6)
- 9. Switch the single color switch to R and verify the single color. (Fig.3-9)
- 10. When two colors are mixed, set the mixed color as the standard, and repeat operations 6 and 7.
- 11. Switch to an all-white signal and check the uniformity.
- 12. When the deflection yoke position is determined, fasten it with the fixture.






Fig.3-11




Fig.3-12

Note: Attach NTC magnets for 20M4 to the locations shown in Fig.3-13.




Fig. 3-13

3-6. Convergence adjustment (1)

1. Input a dot pattern signal.

CONT ... Conspicuous position

BRT ... MIN

- 2. Align the horizontal R, G, and B dots at the center of the screen with the H-START VR.
- * When H-CENT is changed after H-STAT adjustment, readjust H-STAT. (H-STAT will change by means of H-CENT VR.)
- 3. Align the vertical location of R, G, and B in the center of the screen with the V-STAT Mg. (Fig.3-14, 3-15)
- * After V-STAT adjustment, paint-lock the knob.

V-STAT Mg knob

While keeping the angles A and B equal (I = I'), align the vertical convergence.




Fig. 3-14 Good example

If the A and B knobs are not symmetrical $(I \neq I')$, the focus may deteriorate, beam striking or other adverse effects may occur.




Fig. 3-15 Bad example

 For HMC, use the BMC Mg to adjust the R and B dots so that they will be symmetrical horizontally with respect to the G dot.




Fig. 3-16

5. For VMC, use the MBC Mg to adjust the R and B dots so that they will be symmetrical vertically with respect to the G dot.




Fig. 3-17

6. Repeat adjustments 2. to 5.


- * The above adjustment may affect the landing, so after adjustment, check the landing again.
- 7. Paint-lock the knobs after adjustment.

3-7. Deflection yoke neck rotation adjustment

- If there is nonconvergence on both sides of the X or Y axis of the screen, turn the neck of the deflection yoke in the direction of the arrow to hold the nonconvergence for the entire CRT screen within the tolerance.
- * Applicable only to groups of models 1, 2, 3, and 5.
- (1) Reverse cross (2) Regular cross misconvergence misconvergence pattern pattern Move the deflection yoke Move the deflection yoke downward. upward. RGB BGR GB Ğ R G G В RGB BGR Fig. 3-18 Fig. 3-19 (3) Pattern of left-sided (4) Pattern of right-sided deflection yoke deflection yoke Move the deflection Move the defication yoke to the left when yoke to the right when viewed from the CRT viewed from the CRT screen. screen. Fig. 3-20 Fig. 3-21 2 zone 1 zone
 - Fig. 3-23
- 2. Turn the neck of the deflection yoke to align the V pin vertically.
- * Applicable only to group of models 4.

Insert the wedge between the deflection yoke and CRT funnel to lock the deflection yoke. (Fig.3-24)








Group of models 4 have been treated.

Fig. 3-24


4. The following patterns cannot be corrected by turning the neck. (Figs.3-25, 3-26, and 3-27)



*Gun rotatuon

The X-axis and Y-axis beams are distorted on both sides.


Fig. 3-25



*HCR Large(Small)

The horizontal portion of the G raster is wider(narrower) than that of the RB raster on both sides of the screen.

Fig. 3-26



*VCR Large(Small)

The vertical portion of the G raster is wider(narrower) than that of the RB raster on both sides of the screen.

Fig. 3-27

3-8. Convergence adjustment (2)




Fig. 3-28 Convergence compensation VR,coil,and compensator

Note: When adjustment is insufficient, use permalloy for perfect adjustment.

1. Group of models 4 (See Table 3-3.)

- 1. Input a cross-hatch signal.
- Make adjustment with the TLV, YCH, YBH VR, and XCV coils of the deflection yoke to minimize nonconvergence.
- When the nonconvergence of the TILT component is included in the horizontal convergence, make adjustment with the TLH compensator. (Fig. 3-28)

2. Groups of models 1, 2, and 3 (See Table 3-3.)


- 1. Input a cross-hatch signal.
- Make adjustment with the TLV, YCH VR, and XCV coils of the deflection yoke to minimize nonconvergence.
- When the nonconvergence of the TILT component is included inthe horizontal convergence, insert the TLH compensator into the deflection yoke for adjustment. (Fig.3-28)

3. Group of models 5 (See Table 3-3.)

- 1. Input a cross-hatch signal.
- Make adjustment with the XCV coil of the deflection yoke to minimize nonconvergence.
- When the nonconvergence of the TILT component is included in the vertical convergence, insert the TLV compensator into the deflection yoke for adjustment. (Fig.3-28)

3-9. G2 adjustment

- 1. Input a 525 monoscope signal.
- 2. Connect the probe of the oscilloscope to TP403 on the A board.
- 3. Measure the lowest reference pulse of the three.
- Make adjustment with SCREEN VR so that the left end of the waveform will be 1.35 V±0.05 V.






Fig. 3-29

3-10. White balance adjustment

- Input a 525 monoscope signal. (Input from LINE A or B with no burst.)
- 2. Set as follows:

CONT: 0%

BRT: 50%

 Adjust <u>SUB-BRIGHT</u> in the service mode so that the 20-tone gray scale will be as follows:

0 and 5 IRE → Cut off

10 IRE → Slight glow

- 4. Input 525 all-white (COMPOSITE signal without burst).
- 5. Set CONT VR to 80%.
- Adjust the all-white luminance so that the screen luminance will be 3 NIT.
- 7. Press MENU and select COL TEMP/BAL.
- 8. Select 6500K.

Set 3200K SW to "0" for both 9300K and 6500K.

- 9. Put the unit into the service mode.
- Adjust to the standard values with <RED> and <BLUE> of C/T1 6500K BIAS or C/T2 6500K BIAS .
 Set cut-off to 3 NIT.

<GREEN>

Group of models (Table 3-3)	Fix as follows:	
2, 3, 5	"40O"	
1, 4	"512"	

- 11. Switch the all-white signal luminance to 100 IRE.
- 12. Adjust to the standard values with <RED> and <BLUE> of C/T2 6500KGAIN .

 Green>

Set it to "700."

- 13. Repeat adjustment (10, 11, and 12) until the adjustment is complete, and then write the adjustment data.
- 14. Press MENU and select COL TEMP/BAL.
- 15. Select 9300K.
- Adjust CT2 9300K BIAS CT2 9300K GAIN or CT1 9300K BIAS
 CT1 9300K GAIN in the same manner as adjustments 1013.

BIAS < GREEN>

Group of models (Table 3-3)	Fix as follows:
2, 3, 5	"400"¹
1, 4	"512 "

GAIN <GREEN>
Fix it at "700."

3-11. Blue-only white balance adjustment

- Turn ON the blue-only of the user controller SW. (To set blue-only.)
- Input all-white (COMPOSITE signal without burst). The all-white signal luminance shall be 100 IRE. CONT: 80% BRT: 50%
- 3. Select COL TEMP/BAL.
- 4. Select 6500K.
- 5. Adjust to the standard values with C/T1 6500K B/O<RED> and C/T1 6500K B/O<GREEN> or C/T2 6500K B/O<RED> and C/T1 6500K B/O<GREEN>
- 6. Select COL TEMP/BAL.
- Select 9300K.
- 8. Adjust to the standard values with C/T2 9300K B/O<RED> and C/T2 9300K B/O<GREEN> OF C/T1 9300K B/O<RED> and C/T1 9300K B/O<GREEN>
- Adjust the all-white signal luminance, and check that the white balance is satisfactory when the luminance of the screen is 8NIT.

3-12. SUB BRT adjustment

- 1. Input a 525 monoscope signal.
- 2. CONT ... MIN BRT CENTER (50&)
- 3. Select SUB BRIGHT in the service mode.
- Adjust SUB BRIGHT so that 10 IRE glows slightly and 0 IRE is cut off.

3-13. Focus adjustment

1. PVM-20M4 Series

- Adjust the H focus (upper side of focus pack) by means of a dot signal.
- Adjust the V focus (lower side of focus pack) by means of a dot signal.
- Turn the H focus fully clockwise when viewed from the front by means of a dot signal.
- Turn the H focus counterclockwise and focus well the dot in the center of the screen. When the dot is well focused, it will be divided into two sections.
- Turn the H focus VR clockwise (returning direction) so that the dot will be as shown in Fig.3-30. At that time, both ends of the central section of the screen are in the same state.



Fig. 3-30

- 6. Check that the resolution is more than 800 lines by means of a digital monoscope signal.
- Check that the magenta ring is unconspicuous by means of an all-white signal.



Fig.3-31 Movement of VR when viewed from the front

2. PVM-14M4 Series

- Adjust the H focus (upper side of focus pack) by means of a dot signal.
- Adjust the V focus (lower side of focus pack) by means of a dot signal.
- Turn the H focus fully clockwise when viewed from the front by means of a dot signal.
- Turn the H focus counterclockwise and focus the dot in the center of the screen well. The dot signal is divided into two sections at that time.
- Turn the H focus VR counterclockwise so that the dost will be as shown in Fig.3-32. At that time, both ends of the central section of the screen are in the same state.



Fig. 3-32

- Check that the resolution is more than 800 lines by means of a digital monoscope signal.
- Check that the magenta ring is unconspicuous by means of an all-white signal.





Fig.3-33 Movement of VR when viewed from the front

3. PVM-14M2 Series (CRT14MG)

Make adjustment so that the dots in the central section (right and left edges) will be undivided, respectively. (When well-focused, the dot is divided into two sections.)






Fig. 3-34

4. PVM-20M2 Series

Focus the character "30" in the center of monoscope well is usually.

SECTION 4 SAFETY RELATED ADJUSTMENT

When the parts (with a ⋈ , ⋈ mark on the circuit diagram) shown below are replaced, confirm the matters described in items 4-1 and 4-2 shown below.

R1536

R551, R506, R519, R518, R516, R515, R508, R517, R1560,
 R1537, C549, C512, C513, C523, C592, D501, D533, Q500,
 Q511, IC500, and IC507

When the following parts are replaced, check the +B voltage: IC600, IC602, D610, C615, C631, C621, C632, and T603

Confirmation procedure

- 1. Input 120 VAC.
- Input a monoscope signal, and minimize CONTRAST and BRIGHT.
- 3. Check that the voltage of the CN605 (4) pin is 115.7 VDC.

4-1. CONFIRAMATION OF +B MAXIMUM

Standard: Less than 115.7 VDC(CN605 pin (4)) Check Condition Input voltage: 130 VAC

Note: Use NF Power Supply or make sure that distortion factor is

3% or less.

Input signal: Monoscope

Controls: BRT & CONT → Normal

4-2. CONFIRAMATION OF HOLD-DOWN CIRCUIT

Check Condition Input voltage: 130 VAC

Input signal: White &Dot

Controls: BRT & Cont → Max. & Min.

4-2-1.Hold-Down Circuit (+B)

- a) Adjust the beam current to 600±50µA with the pin ♠ of CN605 with the external DC power supply (less than 127.0 VDC)to the point just before the hold-down circuit works.


 Input Signal: White
- b) Adjust the beam current to 80±20µA with the pin ② of CN605 with the external DC power supply (less than 127.0 VDC) to the point just before the hold-down circuit works. Input Signal: Dot


4-2-2. Hold-Down Circuit (3rd Wire voltage of FBT)

Check item: Check of pin 10 of IC500 voltage: more than 110.0VDC

- a) Adjust the beam current to 600±50µA with the pin ① of IC500 with the external DC power supply (less than 141.0 VDC) to the point just before the hold-down circuit works.


 Input Signal: White
- b) Adjust the beam current to 80±20µA with the pin ① of IC500 with the external DC power supply (less than 141.0 VDC)to the point just before the hold-down circuit works. Input Signal: Dot





SECTION 5 CIRCUIT ADJUSTMENTS

5-1. A BOARD ADJUSTMENT



1. PREPARATION/SIGNAL SPECIFICATIONS

1. Signal specifications

 Supply a composite video or component signals from the CN301 connector. Refer to Table 5-1 to take into consideration the effect on the Q board.

The level of the signal to supply should equal to values shown in Table 5-1 plus/minus 2% max.

Table 5-1

Signal		Details ofsignal	Standard level (Pedestal white)	Reduction rate %	Connector supply level (P·W)
		100% white	0.714V	93%	0.664V
	358NT)	75% white	0.536V	•	0.498V
Composite video		Burst (Green section) (P-P for this item only)	286mV (632mV)	94% (94%)	269mV (594mV)
bar)		100% white	0.7V	*	0.651V
	PAL	75% white	0.525V	*	0.488V
	SECAM } PAL M	PAL burst (Green section) (P-P for this item only)	300mV (664mV)	94% (94%)	282mV (624mV)
		100% white	0.7V	94.8%	0.664V
	BETA 0	75% white	0.525	*	0.498V
Compo- nent		75% color B-Y, R-Y (P-P for this item only)	0.7V	•	0.664V
(75% color		100% white	0.7V	*	0.664V
ber)		75% white	0.525V	*	0.498V
	SMPTE	75% color B-Y, R-Y (P-P for this item only)	0.525	•	0.498V

2. Preparation

* In this chapter, indicates the control items in the service mode.

Example: 60 H-FRQ

Write the applicable model data at the location of NO.114 MODEL in the service mode.

Group of models 4 ... 0

Group of models 5 ... 1

Group of models 1 ... 5

Group of models 2 ... 6

Group of models 3 ... 8

* Refer to Table 5-2 for the following groups of models.

Table 5-2

Group of models		Models	
1	PVM-14M4U PVM-14M4A	PVM-14M4J	PVM-14M4E
2	PVM-14M2U	PVM-14M2E	PVM-14M2A
3	PVM-14M1J		
4	PVM-20M4U PVM-20M4A	PVM-20M4J	PVM-20M4E
5	PVM-20M2U	PVM-20M2E	

* CONT 80% is the center click position of the user controller.

2. ADJUSTMENT OF DEFLECTION SYSTEM

1. Adjustment of horizontal oscillation frequency

- 1. Input a 525 monoscope signal.
- 2. CONT ... 80%

BRT 50%

3. Set the unit in the service mode.

 Connect the IC507 ① PIN on the A board to GND via the 100μ/ 16V chemical capacitor. (Use CN505 ③ PIN for GND.) Or insert the H-FREQ jig into CN505.




Fig.5-1 H-FREQ jig

- Adjust 60 H-FREQ so that the slanting lines on the screen will be vertical. (Fig.5-2)
- 6. Input a 625 monoscope signal.
- Adjust 50 H-FREQ so that the slanting lines on the screen will be vertical. (Fig.5-2)




Fig.5-2

2. H BLANKING adjustment

- 1. Input a 525 monoscope signal.
- 2. CONT ... 80% BRT ... 50%
- 3. Set the unit in the service mode.
- Observe the anode of TP300 or D516 with an oscilloscope, and adjust <u>H-BLANKING</u> so that the waveform will be as shown in Fig.5-3.




Fig.5-3

3. Picture phase adjustment

- 1. Input a 525 monoscope signal.
- 2. Set the unit in the UNDER SCAN mode.
- 3. CONT ... Min. BRT Max.
- 4. Set the unit in the service mode.
- Adjust <u>UNH-SIZE</u> so that the white frame of the monoscope will be approx. 1 cm to the inside of the effective screen.
- 6. Turn RV501 (H-CENT) so that B = B'.
- Adjust 60 VIDEO PHASE so that the signal area will be in the center (A = A') of the deflection area. (Fig. 5-4)
- 8. Input a 625 monoscope signal.
- 9. Adjust 50 VIDEO PHASE in the same manner.




Fig.5-4

4. V BLANKING adjustment

- 1. Input a 525 monoscope signal.
- 2. Set the unit in the UNDER SCAN mode.
- 3. CONT ... Min. BRT ... Max.
- 4. Set the unit in the service mode.
- 5. Adjust V-BLANKING <60> so that the white frame in the upper section of the monoscope will be about to be blanked.

Note: Blanking up to the point 1H away from the white frame is permissible, but the adjusting center should be up to the point 0.5H away from the frame.

- Cancel the UNDER SCAN mode, and set the unit in the normal 16:9 mode.
- 7. Adjust 16:9 BLANKING START<60> and 16:9 BLANKING END<60> that the number of frames in the vertical direction in the lumnous section of the screen will be 11.74 and the BLK quantity it the top and bottom will be the same.

Note: Make adjustment before 16:9 V-SIZE adjustment.

- 8. Input a 625 monoscope signal.
- 9. In the same way as 5. shown above, adjust V-BLANKING <50>.
- 10. Adjust 16:9 BLANKING START<50> and 16:9 BLANKING END<50>, in the same was as 6. and 7., so that the number of frames in the vertical direction in the luminous section of the screen will be 11.2 and the BLK quantity at the top and bottom will be the same.

5. Vertical deflection adjustment

- 1. Input a 525 monoscope signal.
- 2. CONT ... 80% BRT ... 50%
- 3. Set the unit in the service mode.
- 4. Roughly adjust NOR 60 V.SIZE so that the size will be 12 frames. Adjust V.LIN with V.LIN.

Adjust CENT with V.CENT

V.CENT must be reviewed after adjustment of V.LIN.

Adjust NOR 60 V.SIZE so that it will equal the standard value.

- 5. Set the unit in the 16:9 mode by the user controller SW.
- 6. Make the same adjustment with 16:9 NOR V.SIZE <60>.
- 7. Set the unit in the NORMAL SCAN mode.
- 8. Input a 625 signal.
- Adjust NOR 50 V.SIZE so that the SIZE will equal the standard value.
- 10. Set the unit in the 16:9 mode.
- 11. Adjust 16:9 NOR V.SIZE <50> so that it will equal the standard value.

Table 5-3 NORMAL V. SIZE standard

	525		625
4:3		11.75±0.2 frames 11.2±0.2 frames	
10.0	14"	154mm	-
16:9	20"	217mm	4

Horizontal deflection adjustment (Normal scan adjustment)

- 1. Input a 525 monoscope signal.
- 2. CONT ... 80% BRT ... 50%
- 3. Set the unit in the service mode.
- 4. Rough adjustment of H.SIZE

Roughly adjust NOR H.SIZE so that H.SIZE will be 15.75 frames.

- Adjust the horizontal deflection by means of NOR PIN AMP, NOR PIN PHASE, NOR U.PIN AMP, SEXY, V BOW, V ANGL, NOR H SIZE, L PIN AMP, and L V BOW.
 - (While correcting a distorted parallelogram and curvature with V.ANGL and BOW, make adjustment so that the horizontal and vertical lines of the screen will be straight.)
- 6. Set the unit in the 16:9 mode.
- 7. Make the same adjustment as 5. with 16:0 NOR PIN AMP and 16:9 NOR PIN PHASE

Table 5-4 NORMAL H. SIZE standard

	525	625
4:3	11.75±0.2 frames	15.0±0.2 frames
16:9	11.75±0.2 frames	15.0±0.2 frames




Fig.5-5

Horizontal deflection adjustment (UNDER SCAN adjustment)

- 1. Input a 525 monoscope signal.
- 2. CONT ... 80% BRT ... 50%
- 3. Set the unit in the U/S mode.
- 4. Set the unit in the service mode.
- Adjust <u>U/S V SIZE <60></u> so that UNDER V.SIZE will be within the standard.
- Adjust <u>UNSHSIZE</u> so that UNDER H.SIZE will be within the standard.
- Adjust <u>U/S PIN AMP</u> and <u>U/S PIN-PHASE</u>. (Adjust tracking according to 5., 6., and 7.)
- After adjustment, the white frame of the monoscope shall not be out of the effective screen.
- 9. Set the unit in the 16:9 mode.
- 10. Make the same adjustment with 5. and 7. by means of [16:9 U/S V SIZE <60>], [16:9 U/S PIN-AMP] and [16:9 U/S PIN-PHASE].

Table 5-5
Standerd values for groups of models 1, 2, and 3 (14")

	525	625
U/S H-SIZE V-SIZE	252mm 188mm	-
16 : 9 U/S V-SIZE	142mm	← .

Table 5-6
Standerd values for groups of models 4 and 5 (20")

	525	625
U/S H-SIZE V-SIZE	364mm 272mm	4
16 : 9 U/S V-SIZE	205mm	-

- 11. Set the unit in the 16:9 mode.
- 12. Input a monoscope signal.
- 13. Make the same adjustment with 5. by means of U/S V SIZB <50>
- 14. Set the unit in the 16:9 mode.
- 15. Make the same adjustment with 5. by means of 16:9 U/S V SIZE < 50>.

Note: If there is not time enough for adjustment (5. Vertical deflection adjustment and 6. and 7. Horizontal deflection adjustment), confirm that the respective sections will operate normally and that adjustment is possible, and then input standard adjustment values.

8. H/V-DELAY adjustment

Note: This item applies only to groups of models 1, 2, 4, and 5.

- 8-1. H-DELAY adjustment
- 1) Input a 525 monoscope signal.
- 2) CONT ... 80% BRT 50%
- 3) Set the unit in the H/V DELAY mode.
- 4) Set the unit in the service mode.
- 5) Connect the probe of an oscilloscope to IC503 ⑦ PIN. Adjust HDELAY so that the output waveform will be as shown in Fig.5-




Fig.5-6

- 8-2. V-DELAY adjustment
- 1) Input a 525 monoscope signal.
- 2) CONT ... 80% BRT 50%
- 3) Set the unit in the H/V DELAY mode.
- 4) Set the unit in the service mode.
- 5) Connect the probe of an oscilloscope to IC502 ⑦ PIN. Adjust V DELAY so that the output waveform will be as shown in Fig.5-7.




Fig.5-7

8-3. Confirmation of screen Confirm that the screen is as shown in Fig.5-8.




Fig.5-8

9. Writing adjustment results

Write the adjustment results.

Note: Do not turn off the power before writing the adjustment results; otherwise, they will all be lost.

3. Signal system adjustment

1. SUB CON adjustment during NORM and H/V DL

Note: H/V-DL is not applicable to the group of models 3.

Adjustment must be completed before the HUE adjustment of NTSC358/443.PAL.

1. Input a vertical white line signal.

Note : Use a vertical white line signal (without 525 burst; H width of $3\mu S$; 100IRE).

- 2. CONT ... 80% BRT 50%
- Connect the probe of an oscilloscope to CN401 ③ PIN on the A board.
- 4. Set the unit in the service mode.
- Temporarily input "69" as an adjustment value for SUB.BRIGHT. Set the values in Table 5-7 as BIAS and GAIN data of C.TEMP1 and C.TEMP2.

Table 5-7


Group of models	1, 4	2, 3, 5
BIAS GREEN	512	400
GAIN GREEN	700	700

6. Adjust the pedestal or the distance between SYNCTIP and WHITE by means of SUB CON <4:3, NOR>,

SUB CON <4:3, H/V DELAY), SUB CON <16:9, NOR>, and

SUB CON <16:9, NOR>.

SUB CON <4:3. NOR>




SUB-CON 4:3. H/V-DL SUB-CON 16:9. H/V-DL

SUB CON <16:9. NOR> (Fig.5-9)

Group of models	4	1	5	2	3
4:3	1.39Vp-p	1.16Vp-p	1.37Vp-p	1.47Vp-p	1.47Vp-p
16:9	1.22Vp-p	1.04Vp-p	1.19Vр-р	1.32Vp-p	1.32Vp-p

Fig. 5-9

SUB CON <4:3. H/V DELAY>
SUB CON <16:9. H/V DELAY> (Fig.5-10)



SUB-CON 4:3. H/V-DL SUB-CON 16:9. H/V-DL

Group of models	4	1	5	2
4:3	1.39Vp-p	1.16Vp-p	1.37Vp-p	1.47Vp-p
16:9	1.22Vp-p	1.04Vp-p	1.19Vp-p	1.32Vp-p


Fig. 5-10

Note: Not applicable to PVM-14M1J

2. SUB PHASE adjustment

Note: Not applicable to the group of models 3.

- Input a component color bar (R-Y) and EXT SYNC. (BETA 0 level signal)
- 2. Set the unit in the EXT SYNC mode for component input.
- 3. Connect the probe of an oscilloscope to IC404 @ PIN or TP402.
- 4. Set the unit in the service mode.
- 5. Adjust SUB PHASE so that the output waveform will be minimum (15 mVp-p or less). (Fig.5-11)



3. SUB PHASE adjustment

Note: Not applicable to groups of models 1, 2, 4, and 5.

- 1. Input an NTSC color bar.
- Connect L309 to GND and TP307 to 5V line (L320 line), respectively.
- 3. Set the unit in the service mode.
- 4. Adjust SUB PHASE so that the output waveform will be minimum (15 mVp-p or less). (Fig.5-11)

4. SUB CHROMA adjustment

Note: Not applicable to the group of models 3.

- Input component color bars (R-Y, Y, and B-Y). (BETA 0 level signal)
- 2. Set COMPONENT LEVEL to BETA 0 via MENU.
- 3. Connect the probe of an oscilloscope to IC404 @ PIN or TP402.
- 4. Set the unit in the service mode.
- 5. Adjust SUB CHROMA NORMAL so that the peaks of waveforms will be flush with each other as shown in Fig.5-12.




Fig. 5-12

5. SUB COL adjustment

Note: Not applicable to groups of models 1, 2, 4, and 5.

- 1. Set the unit in the service mode.
- 2. Input adjustment value 98 to SUB CHROMA NORMAL. (Fig.5-12)

6. R-Y LEVEL adjustment

Note: Not applicable to the group of models 3.

- 1. Input component color bars (R-Y, Y, and B-Y). (BETA 0 level signal)
- 2. Set COMPONENT LEVEL to BETA 0 via MENU.
- 3. Connect the probe of an oscilloscope to IC404 ① PIN or TP401.
- 4. Set the unit in the service mode.
- Adjust R-Y LEVEL COMPONENT so that the peaks of waveforms will be flush with each other as shown in Fig.5-13.

Make adjustment so that B = D as shown above. (20 mV max.) Check that the difference between B and C is 30 mV or less.




Fig. 5-13

7. SUB CHROMA N10/SMPTE

Note: Not applicable to the group of models 3.

- Input component color bars (R-Y, Y, and B-Y). (SMPTE level signal)
- 2. Set COMPONENT LEVEL to N10/SMPTE via MENU.
- 3. Connect the probe of an oscilloscope to IC404 @ PIN or TP402.
- 4. Set the unit in the service mode.
- Adjust <u>SUB CHROMA SMPTE</u> so that the levels of B and D will be the same. (Fig.5-14)




Fig. 5-14

8. Adjustment of burst gate pulse width

- 1. Input an NTSC color bar.
- 2. Connect the probe of an oscilloscope to TP301 (COMP-SYNC) and Q363 (E) or IC305 ① PIN. (Exercise care since IC305 (1) PIN is a high-impedance line.)
- 3. Set the unit in the service mode.
- Adjust BGP WIDTH so that the output waveforms will be as shown in Fig.5-15.





Fig. 5-15

9. VXO adjustment

9-1. X'tal 358

- 1) Input an NTSC color bar.
- 2) Connect a frequency counter to IC305 ② PIN.
- 3) Set the unit in the service mode.
- 4) Connect IC305 ① PIN as shown in Fig.5-16.
- 5) Adjust NTSC CRYSTAL so that the counter reading will be within the standard values shown below. (Adjustment may be made at a point at which the color flickering stops.)

X'tal 358 standard vlaue: 3579545±20 Hz



(Arrange 4 Di's as close as possible to ①PIN at the shortest possible distance.)

Fig. 5-16

9-2. X'tal 443

- 1) Input a 443 NTSC color bar.
- 2) Connect a frequency counter to IC305 ② PIN.
- 3) Set the unit in the service mode.
- Connect IC305 ① PIN in the same way as 9.-4) in 9. VXO adjustment.
- 5) Adjust NTSC 443 CRYSTAL in the same way as 9.-5) in 9. VXO adjustment.

X'tal 443 standard value: 4433619±20 Hz

10. NTSC - NTSC443 - PAL color demodulation adjustment

Note: 10-1, is not applicable to the group of models 3.

10-1. NT358PHASE (NORMAL)

- 1) Input an NTSC color bar.
- 2) Connect the probe of an oscilloscope to TP306.
- 3) Set the unit in the H/V DELAY mode.
- 4) Set the unit in the service mode.
- Adjust PHASE NTSC 358 NOR so that the burst section of the output waveform will be straight. (Fig.5-17)

10-2. NT 358 PHASE (ACC OFF)

- 1) Conduct ACC OFF via MENU.
- 2) Make adjustment in the same way as 10-1. shown above by means of PHASE NTSC 443 ACC OFF. (Fig. 5-17)




Fig. 5-17

10-3. NT 358 B-Y PHASE

Note: Make adjustment after PHASE adjustment and before CHROMA adjustment.

- Input an NTSC color bar. (Input only the R-Y component. B-Y and Y should be OFF.)
- 2) Connect the probe of an oscilloscope to TP305.
- 3) Set the unit in the service mode.
- Adjust B-Y PHASE NTSC 358 so that the color components will be straight.

10-4. NT 358 CHROMA (NORMAL)

- 1) Input an NTSC color bar.
- 2) Connect the probe of an oscilloscope to IC404 **9** PN or TP402.
- 3) Set the unit in the service mode.
- 4) Adjust CHROMA NTSC 358 NOR so that the peaks of waveforms will be flush with each other as shown in Fig.5-18.

10-5, NT 358 CHROMA (ACC OFF)

Note: 10-5, is not applicable to the group of models 3.

- 1) Conduct ACC OFF via MENU.
- 2) Adjust CHROMA NTSC 358 ACC OFF in the same way as 10-4. shown above. (Fig. 5-18)





Fig. 5-18

10-6. NTSC 358 R-Y LEVEL

Note: Be sure to set ACC in the ON position before this adjustment.

- 1) Input an NTSC 358 color bar.
- 2) Connect the probe of an oscilloscope to IC 404 @PIN or TP401.
- 3) Set the unit in the service mode.
- 4) Adjust **R-Y LEVEL NTSC 358** so that the peaks of waveforms will be flush with each other as shown in Fig.5-19.



Make adjustment so that B=D as shown above.(20mV max.) Check that the difference between B and C is less than 60mV.

Fig. 5-19

10-7. NTSC 443 PHASE (NORMAL)

Note: 10-7-3). is not applicable to the group of models 3.

- 1) Input an NTSC 433 color bar.
- 2) Connect the probe of an oscilloscope to TP306.
- 3) Set the unit in the H/V DELAY mode.
- 4) Set the unit in the service mode.
- Adjust PHASE NTSC 443 NOR so that the burst section of the output waveform will be straight. (Fig. 5-20)




Fig. 5-20

10-8. NTSC 443 PHASE (ACC OFF)

Note: 10-8. is not applicable to group of models 3.

- 1) Conduct ACC OFF via MENU.
- 2) Adjust PHASE NTSC 443 ACC OFF in the same way as 10-7-5). (Fig.5-21)




Fig. 5-21

10-9. NTSC 443 B-Y PHASE NTSC 443 CHROMA NOR

Note: Be sure to set ACC in the ON position before this adjustment.

Note: Remove HV.DELAY before this adjustment.

- 1) Input an NTSC 443 color bar.
- 2) Connect the probe of an oscilloscope to TP402.
- 3) Set the unit in the service mode.
- 4) While tracking by means of **B-Y PHASE NTSC 443** and **CHROMA NTSC 443 NOR**, make adjustment so that the peaks of waveforms will be the same. (Fig. 5-22)





Fig. 5-22

10-10. NTSC 443 CHROMA (ACC OFF)

Note: 10-10. is not applicable to the group of models 3.

- 1) Conduct ACC OFF via MENU.
- 2) Adjust [CHROMA NTSC 443 ACC OFF] in the same way as 10-9-4). (Fig.5-23)



10-11. NT 443 R-Y LEVEL

Note: Be sure to set ACC in the ON position before this adjustment.

- 1) Input an NTSC 443 color bar.
- 2) Connect the probe of an oscilloscope to TP401.
- 3) Set the unit in the service mode.
- 4) Adjust R-Y LEVEL NTSC 443 in the same way as 10-6-4). (Fig.5-24)

Make adjustment so that B = D. (20 mV max.) Check that the difference between B and C is 60 mV or less.





Fig. 5-24

10-12. PAL PHASE (NORMAL)

- 1) Input a PAL SP color bar.
- 2) Connect the probe of an oscilloscope to TP306.
- 3) Set the unit in the service mode.
- Adjust PHASE PAL NOR so that the waveform of the B-Y anti-PAL signal will be "0."



"The signal waveform differs slightly every hour. Adjust it to "0."

Fig. 5-25 R-Y OUT

10-13. PAL PHASE (ACC OFF)


Note: 10-13. is not applicable to the group of models 3.

- 1) Conduct ACC OFF via MENU.
- 2) Adjust PHASE PAL ACC OFF in the same way as 10-12-4).

10-14. PAL B-Y PHASE

Note: Be sure to set ACC in the ON position before this adjustment.

- 1) Input a PAL SP color bar.
- 2) Connect the probe of an oscilloscope to TP305.
- 3) Set the unit in the service mode.
- Adjust <u>B-YPHASEPAL</u> so that the waveform of the R-Y anti-PAL signal will be "0." (Fig.5-26)



*The signal waveform differs slightly every hour. Adjust it to "0."

Fig. 5-26 B-Y OUT


10-15. PAL CHROMA (NORMAL)

- 1) Input a PAL color bar.
- 2) Connect the probe of an oscilloscope to IC404 30 PIN or TP402.
- 3) Set the unit in the service mode.
- Adjust CHROMA PAL NOR so that the peaks of waveforms will be flush with each other. (Fig.5-27)

10-16. PAL CHROMA (ACC OFF)

Note: 10-16 is not applicable to the group of model 3.

- 1) Conduct ACC OFF via MENU.
- Adjust CHROMA PAL ACC OFF in the same way as 10-15-4). (Fig.5-27)



10-17. PAL R-Y LEVEL

Note: Be sure to set ACC in the ON position before this adjustment.

- 1) Input a PAL color bar.
- 2) Connect the probe of an oscilloscope to IC404 ① PIN or TP401.
- 3) Set the unit in the service mode.
- 4) Adjust R-Y LEVEL PAL so that the peaks of waveforms will be flush with each other as shown on the right, (Fig. 5-28)




Fig. 5-28

11. SECAM adjustment

Note: Make adjustment after deflection adjustment.

Note: Subject to H-FREQ, H-BLK, VIDEO-PHASE, ANGLE,

BOW, H-DELAY, etc.


Note: 11. SECAM adjustment is not applicable to the group of models 3.

11-1. HP WIDTH (NORMAL) adjustment

1) Input a SECAM color bar.

Note: The board is roughly adjusted in 11-1., and IC317 ® PIN pulse width may be used for control.

- 2) Set the unit in the UNDER SCAN mode.
- 3) Set the unit in the service mode.
- 4) Adjust HP WIDTH NOR so that the color section at the left edge of the upper portion of the screen is about to disappear. (Fig.5-29)



Make adjustment so that colors are about to disappear.

Fig. 5-29

11-2. Writing HP.WIDTH (NORMAL) data

Note: Not applicable to groups of models 1, 2, 4, and 5.


- 1) Set the unit in the service mode.
- 2) Input 102 to HP.WIDTH (NOR).

11-3. HP POSITION adjustment

Note: 11-3. is not applicable to the group of models 3.

- 1) Input a SECAM color bar.
- 2) Set the HV-DL mode.
- 3) Set the unit in the service mode.
- 4) Adjust HP POSITION as shown in Fig.5-30.

Note: The same as 11-3. The phase relationship between the beginning of IC317 ® PIN pulse and the input VIDEO signal may be used for control.



Bring the BLK edge to this position by HP WIDTH H/V.

Fig. 5-30

11-4. HP WIDTH (H/V-DL) adjustment

Note: 11-4. is not applicable to the group of models 3.

- 1) Input a SECAM color bar.
- 2) Set the unit in the HV-DELAY mode.
- 3) Set the unit in the service mode.
- Adjust HP WIDTH H/V-DELAY as shown in Fig.5-30. (Note: Check HP POSITION. If it is not in position, repeat 2) and 3).)

11-5. SECAM COL BALANCE


Note: 11-5. is not applicable to the group of models 3.

- 1) Input a SECAM color bar.
- 2) Connect the probe of an oscilloscope to TP306.
- 3) Set the unit in the service mode.
- Adjust <u>SECAM COLOR BALANCE R-Y</u> so that the level in the achromatic color will be straight.

- 5) Connect the probe of an oscilloscope to TP305.
- Adjust <u>SECAM COLOR BALANCE B-Y</u> so that the level in the achromatic color will be straight.

11-6. SECAM CHROMA

- 1) Input a SECAM color bar.
- 2) Connect the probe of an oscilloscope to IC404 @ PIN or TP402.
- 3) Set the unit in the service mode.
- Adjust CHROMA SECAM so that the peaks of waveforms will be flush with each other as shown in Fig.5-31.



11-7. SECAM R-Y LEVEL

- 1) Input a SECAM color bar.
- 2) Connect the probe of an oscilloscope to IC404 @ PIN or TP401.
- 3) Set the unit in the service mode.
- 4) Adjust R-Y LEVEL SECAM so that the peaks of waveforms will be flush with each other as shown in Fig.5-32.

IC404 (PIN Make adjustment so that B=D.





Fig. 5-32


12. Writing adjustment results


Write adjustment results in the memory.

SECTION 6 DIAGRAMS

6-1. BLOCK DIAGRAMS (1)










-41-












- 48 -

6-2. FRAME SCHEMATIC DIAGRAM




- 50 -





6-3. CIRCUIT BOARDS LOC.



6-4. PRINTED WIRING BOAF

- All capacitors are in μF unless othe 50 WV or less are not indicated except
- Indication of resistance, which does electrical power, is as follows.

Pitch: 5 mm Rating electrical power 1/4 W

- · All resistors are in ohms.
- : nonflammable resistor.
- : fusible resistor. △ : internal component.
- ______ : panel designation, and adjus


B. unless otherwise noted.

- All variable and adjustable resistors ha
- The components identified by 🔀 it diagram have been carefully factory-s order to satisfy regulations regarding X-Should replacement be required, replacement originally used.
- When replacing components identifie necessary adjustments indicated. If r specified value, change the compone repeat the adjustment until the speci (Refer to R1536 adjust on Page 25 and
- When replacing the part in below table related adjustment.

Part replaced ()

C512, C513, C523, C549, C592, D533, IC500, IC507, Q500, Q51 R508, R515, R516, R517, R518, R551, R1537, R1560---- (A E

6-3. CIRCUIT BOARDS LOCATION



6-4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

Note

- All capacitors are in μF unless otherwise noted. pF: μμF
 50 WV or less are not indicated except for electrolytics.
- Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch: 5 mm Rating electrical power ¼ W

- All resistors are in ohms.
- : nonflammable resistor.
- fusible resistor.
- : internal component.
- in panel designation, and adjustment for repair.

 All variable and adjustable resistors have characteristic curve
- order to satisfy regulations regarding X-ray radiation.

 Should replacement be required, replace only with the value originally used.
- When replacing components identified by . make the
 necessary adjustments indicated. If results do not meet the
 specified value, change the component identified by . and
 repeat the adjustment until the specified value is achieved.
 (Refer to R1536 adjust on Page 25 and 26.)
- When replacing the part in below table, be sure to perform the related adjustment.

Part replaced (☑)	Adjustment (►)
C512, C513, C523, C549, C592, D501, D533, IC500, IC507, Q500, Q511, R506, R508, R515, R516, R517, R518, R519, R551, R1537, R1560	R1536 (HOLD-DOWN)

- All voltages are in V.
- Voltage are dc with respect to ground unless otherwise noted.
- Readings are taken with a color-bar signal input.
- Voltage variations may be noted due to normal production tolerances.
- B + bus.
- signal path.
- No mark: with PAL colour-bar signal sreceived or common voltage.
- For the respective voltage ratings in SECAM, NTSC 3.58, NTSC 4.43
 S-VIDEO, and ANALOG RGB modes, see the table

Reference information

RESISTOR : RN METAL FILM

: RC SOLID

	: FPRD	NONFLAMMABLE CARBON
	: FUSE	NONFLAMMABLE FUSIBLE
	: RW	NONFLAMMABLE WIREWOUND
	: RS	NONFLAMMABLE METAL OXIDE
	: RB	NONFLAMMABLE CEMENT
COIL	: LF-8L	MICRO INDUCTOR
CAPACITOR	: TA	TANTALUM
	: PS	STYROL
	: PP	POLYPROPYLENE
	: PT	MYLAR-
	: MPS	METALIZED POLYESTER
(4)	: MPP	METALIZED POLYPROPYLENE
-	: ALB	BIPOLAR
	: ALT	HIGH TEMPERATURE
M)	: ALR	HIGH RIPPLE


Note: Les composants identifiés par une trame et par une marque A sont d'une importance critique pour la sécurité. Ne les remplacer que par des pièces de numéro spécifié.

A BOARD (COMPONENT SIDE)

C
IC102
C104 B-2 C308 C105 B-3 C311 C106 C-3 C314 C107 C-3 C320 C110 C-3 C320 C111 B-2 C335 C112 B-2 C340 C200 A-5 C341 C301 G-2 C342 C302 G-3 C302 G-3 C303 E-1 C304 G-1 C305 G-2 C348 C306 F-3 C309 F-3 C310 D-3 C311 E-3 C312 E-3 C315 C311 E-3 C355 C311 E-3 C355 C311 E-3 C315 C312 E-3 C355 C312 E-3 C356 C312 E-3 C357 C313 F-2 C360 C315 C315 C315 C315 C316 G-5 C362 C317 D-1 C320 F-5 C318 D-2 C320 F-5 C321 F-5 C322 E-5 C322 E-5 C324 E-4 C323 E-5 C324 E-4 C325 E-4 C325 E-4 C326 E-2 C401 C327 C-3 C327 C321 C326 E-2 C401 C327 C-3 C411 C350 D-2 C408 C326 E-2 C400 C327 C-3 C411 C402 D-4 C403 B-5 C404 C405 C406 C407 C-5 C406 B-5 C407 C-5 C408 C-6 C407 C-5 C408 C-6 C409 C-6 C407 C-5 C409 C-6
C506 E-6 Q446 C507 D-7 Q447 C508 C-7 Q449 C509 C-8 Q501 C510 E-3 Q502 C511 A-7 Q503 C512 A-8 Q512 Q513 TRANSISTOR Q515 Q518 Q102 C-2 Q523 Q104 B-2 Q524 Q105 A-3 Q525 Q525
Q107 A-3 Q526


-A BOARD- <component side=""></component>					: Pattern from the
2	3 4	5	6	7 8	9
					1514 C581
o Commission in the commission of the commission					- No.
COMPANY TO THE PARTY OF THE PAR					52 CS87
Proceedings of the control of the co					42 14 15 15 15 15 15 15 15 15 15 15 15 15 15
			200		1515 1521
			一点(这篇		
			望海等到		
10000000000000000000000000000000000000					
				512	00 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
ONCE					
			GICLES.	- 0 M q - 154 CS10	
					1000
		000000 punt			
GE LE			司交位的		
TO OUR LESS TANKS LESS					
	graffic (FL)		£ (12)		
			建筑 18		
	超 高。	De La Company			
人名·伊克克德斯	STATE OF THE				
C. C	Concession Losse		100	50 (P)	
The second secon		ELNSUZ			

• : Pattern from the side



A BOARD (CONDUCTOR SIDE)

Q368 Q369 Q375 Q401 Q402 Q403	Q333 Q334 Q336 Q338 Q345 Q349 Q350 Q351 Q352 Q355 Q361 Q363 Q364 Q367	Q101 Q111 Q113 Q114 Q200 Q201 Q301 Q302 Q303 Q305 Q306 Q307 Q309 Q310 Q312 Q313 Q315 Q319 Q321 Q322 Q323 Q325 Q326 Q327 Q328 Q328 Q329 Q330 Q331 Q332	TRANS	IC101 IC108 IC200 IC303 IC404 IC500 IC505 IC507 IC511 IC512	IC
E-8 E-8 D-8 B-6 B-6 B-6	991888988858988 DHUCDDEDDDLLGGDE	A-10 A-17 A-18 A-15 A-16 B-16 B-17 B-18 B-18 B-18 B-18 B-18 B-18 B-18 B-18	ISTOR	A-9 B-8 A-5 E-9 D-6 G-3 E-4 D-4 A-4 A-3	;
D309 D310 D311 D315 D317 D320	DIO D101 D102 D103 D107 D111 D115 D116 D200 D301 D303 D304 D307	Q444 Q448 Q501 Q502 Q503 Q505 Q506 Q507 Q508 Q509 Q510 Q511 Q512 Q513 Q514 Q515 Q516 Q517 Q519 Q520 Q522 Q525 Q526 Q527 Q528 Q529 Q529 Q530 Q531 Q532 Q2501	Q434 Q439	Q417 Q418 Q419 Q420 Q421 Q422 Q423 Q423 Q424 Q428 Q431	Q405 Q407 Q409
G-8 G-9 E-8 D-9 D-9	B-10 B-9 B-9 B-9 B-9 G-2 A-4 G-8 F-7 G-7 G-8	59223354545454211424345441334223 BEGDDBEBECGCGAABBCCCBBEAGEADDGCC	C-5 C-6		C-6 C-7 D-7
VARIA RESIS	D526 D527 D528 D529 D530 D531 D532 D533 D534 D536 D542 D546 D547 D548	D404 D405 D407 D410 D411 D421 D422 D425 D427 D500 D501 D502 D503 D504 D505 D506 D507 D508 D509 D510 D511 D512 D513 D514 D515 D516 D517 D518 D519 D518 D519 D514 D515 D516 D517 D518 D519 D523 D524 D525	D401 D402 D404	D325 D326 D336 D337 D344 D345 D346 D347 D363 D364	D322 D323 D324
B-2	B-4 B-3 A-1 A-2 A-1 B-4 B-4 G-2 B-4 A-5 B-1 D-4 G-2	0	B-7 B-7 D-6	D-8 E-9 C-9 E-8 D-8 E-7 E-7 E-7 E-8 E-8	D-9 C-9 E-9



A BOARD (CONDUCTOR SIDE)


Q401 Q402 Q403	Q368 Q369 Q375	Q336 Q338 Q339 Q345 Q350 Q351 Q352 Q355 Q361 Q363 Q364 Q367	Q333 Q334	Q101 Q111 Q113 Q114 Q200 Q201 Q301 Q302 Q303 Q305 Q306 Q307 Q309 Q310 Q312 Q313 Q315 Q319 Q321 Q322 Q323 Q325 Q326 Q327 Q328 Q327 Q328 Q329 Q329 Q330 Q331 Q331 Q331 Q331 Q331	IC512	IC303 IC404 IC500 IC505 IC507 IC511	IC101 IC108 IC200	IC
B-6 B-6	E-8 E-8 D-8 B-6	E-10 C-8 D-8 D-8 E-9 D-8 D-8 F-5 F-8 G-9 D-8 E-8	D-9 F-9	A-9 C-10 A-8 A-5 B-16 B-7 B-8 B-7 B-8 B-7 B-8 B-7 B-8 B-7 B-8 B-7 B-8 B-7 B-8 B-7 B-8 B-17 B-18 B-18 B-18 B-19 B-19 B-19 B-19 B-19 B-19 B-19 B-19	A-3	E-9 D-6 G-3 E-4 D-4 A-4	A-9 B-8 A-5	;
D315 D317 D320	D309 D310 D311	D101 D102 D103 D107 D111 D115 D116 D200 D301 D303 D304 D307	DIC	Q434 Q439 Q444 Q448 Q500 Q501 Q502 Q503 Q506 Q506 Q507 Q508 Q509 Q510 Q511 Q512 Q513 Q514 Q515 Q516 Q517 Q519 Q520 Q522 Q525 Q526 Q527 Q528 Q529 Q530 Q531 Q532 Q2501	Q431	Q420 Q421 Q422 Q423 Q424 Q428	Q409 Q417 Q418 Q419	Q405 Q407
E-8 D-9 D-9	G-8 G-8 G-9	B-10 B-9 B-9 B-9 B-9 G-2 A-4 G-8 F-7 G-7		\$\f\$\f\$\f\$\f\$\f\$\f\$\f\$\f\$\f\$\f\$\f\$\f\$\f\$	B-5 C-5	C-6 B-5 B-5 C-5 C-5 D-6	D-7 C-5 B-5 C-6 C-6	C-6 C-7 D-7
RV501	RESI	D526 D527 D528 D529 D530 D531 D532 D533 D534 D536 D542 D546 D547 D548	D525 D526	D401 D402 D404 D405 D407 D410 D411 D421 D422 D425 D427 D500 D501 D502 D503 D504 D505 D506 D507 D508 D509 D511 D512 D513 D514 D515 D516 D515 D516 D517 D518 D519 D523 D524	D364 D401	D337 D344 D345 D346 D347 D363	D325 D326 D333	D322 D323 D324
6-2	ABLE STOR B-2	B-3 A-1 A-2 A-1 B-4 B-4 G-2 B-4 G-2 B-4 G-2 B-4 G-2	C-2 B-4	B-7-6-6-5-7-5-6-5-2-2-2-2-1-2-5-5-5-5-5-2-5-4-1-5-4-5-4-2-2-2-2-2-2-2-2-2-2-2-2-2-2-2-2	E-8 B-7	E-8 D-8 E-7 E-7 E-7 E-8	D-8 E-9 C-9	D-9 C-9 E-9





NOTE:


The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.

Pattern from the side which enables seeing.
 Pattern of the rear side.









• A BOARD WAVEFORMS

· A BOARD WAVE	FORMS	
①	②	3
	<i>///</i>	
4.3 Vp-p(H)	5.6 Vp-p (10MHz)	4.8 Vp-p (V)
PAL 0.3 Vp-p (H) SECAM 0.32 Vp-p (H)	(4) 1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-	5 -24 ML24 ML24 0.45 Vp-p (H) SECAM 0.5 Vp-p (H)
(5) -24) Lugh Lug NTSCS, 59 0.42 Vp-p (H) NTSC4, 43 0.38 Vp-p (H)	5 - 1060 VP-P (H)	6 PAL 57 Vp-p (H) SECAM 0.45 Vp-p (H)
6 10 4 4 10 10 10 10 10 10 10 10 10 10 10 10 10	PAL 2.4 Vp-p(H) SECAM 2.3 Vp-p(H)	TSC3.58 2.1 Vp-p(H) NTSC4.43 2.2 Vp-p(H)
3-V1060 2.4 Vp-p (H)	② 	(B) (M) (M) (M) (M) (M) (M) (M) (M) (M) (M
ANALOG ROB O. 6 Vp-p (H)	AMALOG POS 0.6 Vp-p (H)	PAL 2.6 Vp-p (H) SECAM 2.5 Vp-p (H)
MTSC3.58 Vp-p (H) 2.4 Vp-p (H) 2.5 Vp-p (H)	5-VIDEO (H)	MALDO ROB 3. 0 Vp-p (H)
(2) 4.6 Vp-p (V)	PAL 1. 8 Vp - p (H) SECAM 1. 9 Vp - p (· H)	MTSCS.58 NTSCS.58 NTSCS.58 NTSCS.58 1.8 Vp-p (H)
3-11060 0-11060 0-11060 0-1100 0-100 0-100 0-100 0-100 0-1000 0-1000 0-1000 0-1000	(3) 	3.7 Vp-p(H)
(5)		

A BOARD (1/3) * MARK LIST

3.6 Vp-p (V)

	PVM-20M4U/E/A	PVM-20M2U/E
R414	10k : CHIP	0 : CHIP

A BOARD (1/3) * MARK

A BO	ARD (1	1/3) *	MARK	(
	PAL	SECAM	NTSC 3.58	NTSC 4.43	S-VIDE
IC101 ②	2.3 4.5	2.4 4.6	2.2 4.5	2.2 4.4	2.0 4.4
0	4.1 3.4	3.4 3.5	0 3.5	0.1 3.5	3.1
3	0	0	0	0	4.8 0
Ø	4.9 5.0	5.0	0	5.0	0
8	0	5.0 5.0	0	0	0
89	5.0	5.0	5.0	5.0	0
39	5.0	5.0	5.0	5.0	5.0
8	4.2	4.1	4.6	5.0 5.0	3.9
9	0.3 4.2	4.4 0.1	0.1 4.3	0.7 4.2	4.2
<u>\$</u>	4.0 0.5	3.4 0.9	3.6 1.0	3.7 0.8	3.9
9	3.6	2.5 3.0	2.6	3.2	3.8
IC103 ®	0.2	0	0.2	4.0 0.2	0
IC104 @	2.3 3.5	3.5	3.5	3.5	3.1
(C105 (3)	2.3 0 2.6	2.3 0.1 2.7	2.2 0.1 2.7	2.2 0 2.6	11.8
1C106 (3)	5.4	5.4	5.4 2.2	5.4	2.8 6.6 2.1
\$	5.4	5.4	5.4	5.4 2.4	4.1
0	7.8	7.8	7.6	7.7	5.5
®	0.1	10.5	10.5	10.5	10.9
(3)	2.4 6.3	4.6 6.3	2.1	9.0	2.1
3	3.6	3.6	4.8	3.6 0.3	4.3
1C107 ②	4.6 2.3	4.5 2.3	4.5 2.2	4.5	4.4
(2.8	2.8	2.8	2.8	3.3 2.3
0	2.9 2.6	2.9 2.6	2.9	2.9 2.6	2.1
(9)	2.9	2.9 2.6	2.9	2.9 2.8	2.6 2.8
(b)	3.2 4.5	3.2 4.6	5.4 5.0	5.4 5.0	5.3 3.7
IC109 ②	6.3 4.6	6.3 4.5	6.1 4.5	6.1 4.5	6.0 4.4
3	2.3 11.9	2.3 11.9	2.2 11.9	2.2 11.9	2.1
IC110 ③	11.9 2.3	11.9	0.1 2.2	2.2	2.0
(4)	7.2 5.8	7.2 5.8	7.2 5.8	7.2 5.8	8.3 6.2
	11.9	11.9 7.9	11.9 7.9	11.9 7.9	7.8 7.8
IC111 (I)	3.7 0.3	3.7 0.3	3.5 0.3	3.5 0.3	3.5 0
0	0.2	5.0	0.1 5.0	0.1 5.0	0.1
IC402 ②	3.1	5.0 3.9	2.9	5.0 3.0	3.0
① (C403 (D	2.9	2.3	2.3	0	2.2
2	1.2	1.2	0.8	0.B 0.8	1.2
(3) (6)	0.8	0.8	0.9	0.9	0.8
6	0.6	0.5	0.6	0.6	0.6
(D)	1.0 1.6	1.0	1.0	1.0	1.4
0	0.9	1.4 1.0	1.0	1.0	0.8
IC404 (6)	3.0	3.0	0.6 3.0 4.9	0.6 3.0 4.9	4.5 4.7
0	5.6 5.6	5.6 5.6	5.6 5.6	5.6 5.6	5.6 5.6
6	0 3.8	0.1	0	0	0
9	7.1	6.6	8.0 1.2	8.0	7.7
9	7.0	7.3	8.1	7.8 1.1	7.8
9	7.8	7.8 7.1	7.7	7.8	8.0 7.6
0	1.2	1.2 7.2	1.0	1.0	1.2
6	7.2	7.2	7.2	7.2	5.9 5.5
IC405 (1)	1.6	1.5	1.1	1.3	1.4
3	1.2	1.2	0.9	0	1.1
⑤	1.3 0.5	1.3 0.5	1.0 0.6	0	1.2
0	0.5 1.2	0.5 1.2	0.6 0.8	1.3	0.3
0	1.4	1.3 1.2	0.9 0.8	1.3	1.3
(\$) IC406 (1)	1.4 4.8	1.3 5.1	1.0	1.3 4.8	1.2 4.8
<u> </u>	1.0	0.9	0.9	0.9	0.8 0.8
(S)	5.1	5.1	1.1 4.9	1.1 4.9	0.B 4.9
IC407 ①	0.4	1.2 - 0.1	0.9	0.3	1.2 0.4
0	0.6	0	0.7	1.3 0.5	1.2 0.5
(S)	2.0 11.7	1.8	2.0 11.6	2.0	2.0 11.7
9	5.5 5.5	5.5 5.5	5.5 5.5	5.5 5.5	5.4 5.4
0	1.4 0.6	1.4 - 0.1	1.0 0.7	1.3 0.6	1.2 0.5
0	2.0	1.7	2.0	2.0 2.0	2.0
IC408 ①	3.1 4.1	2.9 3.8	2.9 3.9	3.1 4.1	3.7 4.2
1C409 ①	0	0.6	9.0	9.4 0.3	0.3
6	5.9 5.9	5.9 5.9	6.3 6.3	6.0	5.9 5.9
0	5.9 0.1	5.9 1.8	6.3 0.5	1.2	5.9 0.1
0	0	10.7	6.6	6.9	0

· A BOARD WAVEFORMS

· A BOARD WAVE	FURMS	
1	② ∧ ∧	3
	<i>J V \</i>	
4.3 Vp-p(H)	5.6 Vp-p (10MHz)	4.8 Vp-p(V)
PAL 0.3 Vp-p (H)	4 NTSC3.58 4.43 0.28 Vp-p (H)	3 -24/10/4/10/44 PAC. 45 Vp-p (H)
SECAM 0.32 Vp-p (H)	5-V18E0 0.35 Vp-p (H)	0.5 Vp-p (H)
5 -24 1 24 1 24 0.42 Vp-p (H) MTSC4.43 0.38 Vp-p (H)	5 - 110E0 O. 45 Vp-p (H)	6 PAL 57 Vp-p (H) SECAM 0.45 Vp-p (H)
(A)	PAL 2. 4 Vp-p (H) SECAM 2. 3 Vp-p (H)	7
5-V10E0 (H)	7 1.7.7.7.7.7.7.7.7.7.7.7.7.7.7.7.7.7.7.	B MM MM M ANALOG REB O. 6 Vp-p (H)
9 ANALOG RIGB 0.6 V p - p (H)	AMALOG POP P (H)	PAL 2.6 Vp-p (H) SECAM 2.5 Vp-p (H)
MTSC3.58 2.4 Vp-p (H) MTSC4.43 2.5 Vp-p (H)	1) 	ANALDO ROB 3.0 Vp-p(H)
12 4.6 Vp-p (V)	PAL 1. 8 Vp-p (H) SECAM 1. 9 Vp-p (.H)	MTSC3.58 Vp-p(H)
3 2-v1060 1.9 vp-p (H)	ANALDO RGB 2.4 Vp-p (H)	3.7 Vp-p(H)
3.6 Vp-p (V)		

A BOARD (1/3) * MARK LIST

	PVM-20M4U/E/A	PVM-20M2U/E
R414	10k : CHIP	0 : CHIP
		# : Not Used

A BOARD (1/3) * MARK

A BO	ARD (1/3) *	MAH	K		
	PAL	SECAM	NTSC 3.58	NTSC 4.43	S-VIDEO	ANALOG RGB
IC101 ②		2.4 4.6	2.2 4.5	2.2	2.0	2.3 4.5
6	4.1	3.4	0	0.1	0	0
<u> </u>	0	3.5	3.5 0	3.5	3.1 4.8	3.5
9		5.0	0	0	0	4.9
9		5.0 5.0	0	5.0	0	0
6	0	5.0	0	0	0	0
8	5.0	5.0	5.0	5.0	4.9 0	0.1 5.0
39	5.0	5.0 5.0	5.0	5.0 5.0	4.9 5.0	0.1
S	4.2	4.1	4.6 4.6	5.0 5.0	3.9 3.6	3.9
(9)	0.3	4.4	0.1	0.7	0.1	0.1
<u> </u>	4.0	3.4	4.3 3.6	4.2 3.7	4.2 3.9	4.3
<u>\$</u>	3.0	0.9 2.5	1.0	0.8	3.1	1.9
9	3.6	3.0 4.0	2.9	3.2 4.0	3.9	4.0
IC103 ®	0.2	0	0.2	0.2	0	0
IC104 @	3.5	2.3 3.5	2.2 3.5	2.2 3.5	2.0 3.1	2.3 3.5
IC105 (3)	2.3	0.1	0.1	0	11.8	0
6	2.6 5.4	2.7 5.4	2.7 5.4	2.6 5.4	2.8 6.6	2.8 8.1
IC106 (3)	2.3 5.4	2.3 5.4	2.2 5.4	2.2	2.1	2.3
0	2.4	2.4	2.4	2.4	4.1 0.5	5.4 2.4
(a)	7.8 5.1	7.8 5.1	7.8 5.1	7.7 5.1	5.5 4.0	7.8 5.1
<u>®</u>	3.1	10.5 3.1	10.5	10.5 3.1	10.9	10.5 2.5
(9)	6.3	4.6 6.3	2.1	9.0	2.1	3.2
3	3.6	3.6	4.8	3.6	4.3	9.5
IC107 ②	0.8 4.6	1.8 4.5	0.4 4.5	0.3 4.5	2.4 4.4	3.1 4.5
3	2.3	2.3 2.8	2.2	2.8	2.1 3.3	2.8
®	1.5	1.4 2.9	1.4	1.4	2.3 2.1	1.4
0	2.6	2.6	2.6	2.6	2.9	2.6
1	2.6	2.6	2.8	2.9	2.6 2.8	2.9 2.8
3	3.2 4.5	3.2 4.6	5.4 5.0	5.4 5.0	5.3 3.7	5.4
IC109 (2)	6.3	6.3 4.5	6.1 4.5	6.1 4.5	6.0	6.1
3	2.3	2.3 11.9	2.2 11.9	2.2	2.1	2.3
9	11.9	11.9	0.1	0	0.1	11.8
IC110 (3)	7.2	7.2	7.2	7.2	2.0 8.3	7.2
®	5.8	5.8 11.9	5.8 11.9	5.8 11.9	6.2 7.8	5.8 11.9
(4)	3.7	7.9 3.7	7.9 3.5	7.9 3.5	7.8 3.5	7.9
IC111 @	0.3	0.3	0.3	0.3	0	3.6 0.3
	0.2	5.0	0.1 5.0	0.1 5.0	0.1	5.0
IC402 ②	5.0	5.0 3.9	5.0 2.9	5.0 3.0	3.0	5.0 3.6
0	2.9	2.3 2.9	2.3 2.9	0	2.2	2.2
IC403 ①	0.8	0.8	0.8 0.8	0.8	0.8	0
3	1.4	1.3	0.9	0.9	1.3	0.9
(4)	0.8	0.B 0.5	0.9	0.9	0.8	0.6
(E)	0.5	0.6	0.6	0.6	0.6 0.8	0
9	1.6	1.5	1.1	1.1	1.4	1.6
0	0.9	1.0	1.0	1.0	0.8	1.5
IC404 (3.0	0.6 3.0	3.0	0.6 3.0	4.5	0.6
<u> </u>	4.9 5.6	4.9 5.6	4.9 5.6	4.9 5.6	4.7 5.6	6.1 5.8
(b)	5.6 0	5.6 0.1	5.6 0	5.6 0	5.6	5.8 4.4
8	3.8 7.1	4.0	4.1	4.2	4.0	3.6
₩	1.4	1.3	8.0 1.2	8.0	7.7 1.2	7.9
<u>9</u>	7.0	7.3 1.3	8.1 1.2	7.8	7.8	7.8
39	7.8	7.8 7.1	7.7	7.8	8.0 7.6	7.7 7.6
0	7.2	1.2 7.2	1.0	1.0	1.2	1.3
6	7.2	7.2	7.2	7.2	8.3 6.9	7.2
IC405 ①	6.6 1.6	6.6 1.5	1.1	6.6	5.5 1.4	1.6
3	1.4	1.4	0.9	0	1.2	1.5
(1.4	1.3	1.0	0	1.2	1.4
0	0.5 0.5	0.5 0.5	0.6	1.0	0.3	0.2
0	1.2	1.2	0.6	1.3	1.2	1.3
0	1.4	1.3	0.9	1.3	1.3	1.4
IC406 ①	1.4	1.3 5.1	1.0	1.3	1.2 4.8	1.5 5.1
(S)	0.8	0.9	0.9	0.9	0.8	1.0
6	1.0	1.0	1.1	1.1	0.8	1.1
IC407 ①	5.1 1.2	5.1	4.9 0.9	1.2	1.2	5.1 1.3
3	0.4	- 0.1 1.3	0.5 1.0	0.3	0.4	0.5
(4)	0.6 2.0	0	0.7	0.5	0.5	0.7
6	11,7	10.7	2.0	11.3	11.7	11.2
® 9	5.5 5.5	5.5 5.5	5.5 5.5	5.5 5.5	5.4 5.4	8.5 8.4
0	1.4 0.6	1.4	1.0	1.3	1.2	1.5
•	2.0	1.7	2.0	2.0	0.5 2.0	2.0
IC408 ①	3.1	2.9	2.0	3.1	2.0 3.7	2.0 3.4
1C409 ①	4.1	3.8 8.8	3.9 9.0	4.1 9.4	4.2 0	4.1 7.5
3	0 5.9	0.6 5.9	0.4 6.3	0.3	0.3 5.9	1.6
® •	5.9 5.9	5.9 5.9	6.3 6.3	6.0	5.9 5.9	5.9
0	0.1	1.8	0.5	1.2	0.1	5.9 0
<u> </u>		10.1	6.6	6.9	0	10.7

	PAL	SECAM	NTSC 3.58	NTSC 4.43	S-VIDEO	ANALO RGB
IC410 ①	3.8	4.0	4.0	4.0	0	3.9
2	3.0	3.1	2.4	3.1	0	4.0
3	1.3	0.7	1.4	1.6	2.3	1.5
•	3.5	3.6	3.0	3.8	3.9	3.9
•	0.6	1.3	1.1	1.1	3.1	1.7
6	4.0	4.0	4.0	3.9	0	0
(9)	0	2.0	1.9	1.8	2.5	1.4
0	2.0	2.3	2.3	2.0	1.8	3.0
IC411 ①	4.1	4.0	3.9	3.8	4.2	4.1
0	1.8	2.0	1.9	1.8	2.5	1.3
0	2.0	2.3	2.3	2.1	1.8	3.0
IC412 ②	0.4	0.5	0.4	0.4	5.9	0.6
(8.9	8.9	8.9	8.9	8.9	
6	9.0	8.9	9.0	8.9		8.3
0	6.0				8.9	8.3
	0.4	6.0	6.0	6.0	6.0	0
(D)		0.5	0.4	0.4	5.9	0.5
	7.9	8.0	8.0	8.0	0	6.9
<u> </u>	0	5.5	5.5	5.5	5.4	0
(5)	5.5	5.5	5.5	5.5	5.4	8.6
• •	3.1	3.1	3.1	3.1	0	5.1
0	3.1	3.1	3.1	3.1	6.0	5.1
(5)	7.9	7.9	8.0	7.9	6.3	6.9
0102 B	10.9	10.9	10.9	10.9	10.7	10.9
C	8.1	B.1	8.1	8.1	0	8.1
E	11.5	11.5	11.5	11.5	11.3	11.5
Q104-1 B	- 0.2	0	- 0.2			
				0	0	- 0.2
Q107 B	5.0	5.0	5.0	5.0	5.0	0.1
C C	0	0	0	0	0	5.0
Q108 C	2.6	2.6	2.6	2.6	2.9	2.6
(E	2.6	2.6	2.6	2.6	2.9	2.6
0111 B	5.0	5.0	0	0	4.9	4.9
С	0.4	0.4	0	0	0.4	0.4
Q113 C	4.1	4.3	4.2	4.2	3.8	4.0
0401 B	1.1	0.8	1.5	1.6	1.2	1.0
c	7.5	5.5	6.0	5.2	8.4	10.0
E	1.4	1.6	3.2	3.4	3.1	1.0
Q402 B	0.5	0.5	0.5	0.5	2.4	0.5
C	9.5	7.7	8.1	7.4	10.4	6.9
E	1.4	1.6	3.2	3.3	3.2	1.0
Q404 B	5.3	4.1	4.9	5.2	5.3	5.2
Ε	6.1	6.3	6.0	6.1	6.1	6.2
Ω405 B	1.3	1.3	1.2	1.1	1.2	1.4
Q406 B	0.7	0.7	0	0.7	0.7	0.7
С	1.6	1.5	1.0	1.5	1.4	1.6
Q407 B	0	0	0	0	0	
C	6.6	6.6	6.6	6.6	5.4	0.6
Q408 B	5.3	4.7	4.9			0
E	6.0	6.2		5.0	5.2	5.2
Q409 B			5.9	6.1	6.0	6.1
	1.9	1.6	1.6	1.6	1.7	1.6
E .	2.0	2.2	2.2	2.2	2.3	2.2
0411 C	1.4	1.4	0.9	1.3	1.3	1.4
Q412 B	1.3	1.3	1.0	1.3	1.1	1.4
E .	2.0	1.9	1.7	1.9	1.8	2.0
Q413 G	2.0	- 15.1	1.6	- 2.2	1.8	- 2.1
D	2.0	1.9	- 4.3	0	2.2	2.0
S	2.0	1.9	1.7	1.9	1.8	2.0
Q417 B	1.4	1.4	1.2	1.2	1.2	1.4
Q418 C	2.1	2.1	1.7	1.7	1.7	2.0
0419 B	1.4	1.4	1.2	1.1	1.2	1.5
E	2.0	1.9	1.7	1.7	1.8	2.0
Q420 B	1.2	1.2	1.0	1.0	1.2	1.3
E	1.8	1.8	1.6	1.6	1.8	1.9
0422 C	2.1	2.1	1.7	1.7	1.8	2.0
O423 B	0.5	0.3	0.4	0.4	0.4	0.2
0425 C	4.5	4.5	4.5	4.5	4.7	4.5
0426 C	0.8	0.8	0.7	0.7	0.7	0
Q429 B	0.1	8.0	0.4	0.4	0.1	0.1
E	0	- 2.3	- 1.2	- 1.2	0.4	0.4
0432 B	- 0.3	- 3.8	- 3.4	- 2.7	- 0.1	- 3.9
C	11.9	11.6	11.8	11.8	12.0	
Q433 B	0	- 0.1	0	0	0	11.6
C	3.0	3.0	3.0	3.0		2.7
Q434 B	- 0.1	0	0		4.5	0
C	3.6	4.7		0	- 0.1	0.4
O438 B			4.5	4.8	2.9	0
	- 0.4	- 2.9	- 3.1	- 2.4	0	- 2.4
C	11.7	11.4	11.7	11.7	11.6	11.7
Q439 B	2.0	1.9	1.8	1.7	1.8	2.0
E	2.6	2.5	2.4	2.4	0	2.6
Q440 B	2.6	2.5	2.5	2.5	2.4	2.7
0441 G	- 1.1*	- 13.0	1.7	- 4.8	0	- 0.7
	2.0	1.9	- 8.1	1.9	1.8	2.0
D	2.0	1.9	1.6	1.9	1.8	2.0
S				1.1	1.1	2.0
	1.3	1.3				
S 0442 B	0.9	0.9	0.7			
S 0442 B E	0.9	0.9	0.7	0.7	0.7	1.5
S 0442 B						

- 63 -

A BOARD (2/3) * MARK


	PAL	SECAM	NTSC 3.58	NTSC 4.43	S-VIDEO	ANALOG RGB
C301 ①	2.8	0	2.8	3.0	3.0	2.3
0	2.0	0	1.8	1.7	1.7	3.5
C302 ①	2.9	2.9	2.9	0.3	2.9	2.9
(5)	5.3	5.1	4.5	4.5	4.5	4.5
0	10.5	8.4	0	0	0	0
C303 ®	2.3	2.6	2.2	2.2	2.6	2.8
@	0.1	4.2	0.6	0.6	0.6	0.1
•	3.9	2.8	3.1	3.1	3.3	3.9
C304 @	2.2	2.6	2.2	2.2	2.2	2.2
0	9.4	2.1	9.4	9.4	9.4	9.4
0	7.3	7.3	2.5	2.5	2.6	2.5
0	7.3	7.3	2.5	2.6	2.6	2.5
0	1.9	1.9	2.2	2.2	2.2	2.2
(3)	2.5	2.5	2.2	2.2	2.3	2.2
C305 ①	2.8	2.8	2.8	0	2.8	2.8
(2.5	1.1	2.5	2.4	2.4	
0	4.1	4.1	4.1	4.1	4.2	1.3
9	0.4					4.5
		0.2	0	0	0	0.1
0	2.6	2.6	2.5	2.4	2.5	2.7
<u>@</u>	0	0	0.8	0.8	0.9	0.9
®	2.1	2.7	1.9	1.9	1.9	2.7
C306 ①	8.1	8.1	8.1	8.1	8.1	0
②	0	0	0	0.1	0.1	4.4
C309 ②	3.6	0	3.6	3.6	3.6	3.6
•	Ō	0	0	0	0	4.4
C310 ①	6.2	6.2	6.2	6.2	6.2	5.9
3	6.3	6.3	6.2	6.2	6.2	5.9
0	5.9	5.9	6.0	6.3	5.9	5.9
C311 ①	0	6.2	6.2	6.2	6.2	6.2
2	6.2	6.2	6.2	6.2	6.2	5.9
0	6.2	6.3	6.3	6.2	6.2	5.9
6	3.3	3.3	2.9	2.9	2.9	0
- 0	5.9	5.9	5.9	6.2	5.8	5.9
0	0.4	0.4	0.4	0.4	0.5	0.7
C312 (2)	3.6	0	3.6	3.6	3.6	3.6
(1)	0	Ō	0	12.0	0.1	4.5
C313 ①	0	6.3	Ö	6.3	6.3	6.3
C314 ②	0	3.0	7.6	0.3	3.0	
(- 6	0	0	- 0 -		0
C315 ①	0.4	0.4	0.4		2.9	0.1
C313 (I)	0.6	0.4		0.4	0.4	0.6
0	9.4		0.6	0.6	0.6	0.6
		9.3	9.3	9.2	9.3	9.4
0	2.5	2.5	2.5	2.5	2.5	7.2
0	0.4	0.4	0.4	0.4	0.4	0.6
(5)	0.4	0.4	0.4	0.4	0.4	0.6
C317 @	2.0	0	2.0	2.1	2.0	12.0
	12.0	0	12.0	12.0	12.0	12.0
①	10.7	10.6	10.6	10.6	10.5	10.7
®	9.4	9,4	9.4	9.4	9.1	9.4
C318 (5)	11.5	11.5	0	11.4	11.4	11.4
C320 ①	6.3	6.3	6.3	6.3	6.3	· 0
•	3.0	0	0	3.1	0	0
•	0	0	0	0	3.3	0
C321 ②	0	0.1	0.1	0	2.9	0
•	0	0	0	0	0.1	2.7
C322 🕲	5.8	5.9	6.0	6.3	5.9	5.9
C323 (\$)	6.2	6.3	6.2	6.2	6.2	5.9
0	0	5.6	5.6	5.6	5.6	5.6
C324 (\$)	6.2	6.2	6.2	6.2	6.2	5.9
C326 ①	5.9	5.9	6.0	6.3	5.9	5.9
(2)	5.9	5.9	5.9	6.2	5.8	5.9
3	5.9	5.9	5.9	6.2	5.8	5.9
(5)	1.7	1.9	1.6	1.6	2.1	2.1
6	2.4	1.0	2.3	2.3	2.3	4.6
0	0	- 0.1	10.B	0		
0	6.3	6.3			- 0.1	5.9
			6.3	6.3	6.2	
(Q)	6.3	6.3 6.3	6.3 6.2	6.3 6.2	6.2	5.9
	0.5	D.5	n 2	n 2	B 2	5.9

	PAL	SECAM	NTSC 3.58	NTSC 4.43	S-VIDEO	ANALOG RGB
IC326 @	6.2	6.2	6.2	6.2	6.2	5.9
0	6.2	6.2	6.2	6.3	6.2	5.9
100	6.2	6.2	6.2	6.2	6.2	5.9
C350 ①	6.6	6.5	6.4	6.3	6.1	6.9
②	6.2	6.2	6.2	6.3	6.0	6.4
3	6.2	6.2	6.2	6.3	6.0	6.4
O300 B	2.5	2.5	2.2	2.2	2.2	2.2
c	10.2	10.2	10.4	10.5	10.4	10.5
Ε	1.9	1.9	1.6	1.6	1.6	1.6
0301 E	8.6	8.5	8.2	8.3	8.5	9.8
Q303 E	5.7	5.7	5.7	5.7	5.5	5.7
Q304 B	6.3	6.3	6.3	6.4	6.2	6.3
ΕΕ	5.7	5.7	5.7	5.7	5.5	5.7
Q305 B	8.6	8.5	8.2	8.3	8.5	9.8
E	7.9	7.9	7.6	7.7	7.9	9.1
0307 E	1.4	1.4	1.1	1.2	1.4	2.7
O309 B	1.4	1.4	1.1	1.2	1.4	2.6
С	0.1	0.1	0.2	0.1	0.1	0
E	0.7	1.8	1.7	1.8	0	1.8
Q312 C	8.2	8.2	8.6	8.3	B.3	8.1
0313 B	B.2	8.2	8.6	8.3	8.2	8.1
E	8.8	8.8	9.3	9.0	8.9	8.7
Q314 B	11.9	6.4	11.9	11.9	11.9	11.9
C	0	11.9	0	0	0	
Q315 B	3.3	3.2	2.9	3.1		0
U313 B	3.9			3.8	3.2	3.3
		3.9	3.5		3.8	4.0
Q318 B	12.1	12.0	11.7	11.9	12.1	12.1
C	1.0	1.0	1.2	1.0	1.0	0.9
Q322 B	2.4	2.4	2.3	2.3	5.6	2.4
E	1.8	1.8	1.8	1.8	5.0	1.8
Q323 B	5.0	5.0	0	0	0	0
C	0	0	3.5	3.5	3.5	3.6
Q324 B	4.1	4.2	0	0	0	0
C	0	0	0.8	0.8	0.8	0.9
Q328 B	2.2	2.2	2.2	2.2	2.0	1.3
C	2.8	2.8	2.8	2.8	0	0
0329 D	2.1	2.1	2.2	2.4	0	2.2
G	0	0	1.6	0	2.9	2.8
Q332 B	4.9	5.0	0	4.9	0	Ö
C	0	0	4.4	0	4.3	4.4
Q333 B	1.7	1.7	1.9	1.8	1.7	1.7
E	1.5	1.5	1.7	1.5	1.5	1.4
Q336 G	4.7	4.6	4.6	4.7	4.2	4.8
D	4.3	4.3	4.3	4.3	4.5	4.3
Q339 B	12.3	12.5	12.5	12.4	12.5	12.3
0347 B	0.1	4.2	0.1	0.1	0.6	0.1
c	9.4	0.1	9.4	9.4	9.4	9.4
Q349 B	2.8	2.7	2.7	2.7	2.2	2.8
E	3.4	3.3	3.4	3.4	2.8	3.4
Q354 B	12.0	0.6	0	0	0	0
E	12.0	0.4	Ö	- 6	ŏ	- 0.2
Q358 E	2.2	2.2	ŏ	2.2	2.2	2.2
0360 1	6.2	6.2	6.2	6.3	6.1	6.4
3	6.2	6.2	6.2	6.3	6.0	6.4
5	1.3	4.7	2.2	4.1	5.3	3.8
Q361 B	4.9	4.9	5.0	5.0	5.0	0.8
C	0.1	0	0	0	0.1	4.9
Q362 C	9.0	9.0	9.0	9.5	9.2	B.5
0364 C	3.3	3.3	2.9	2.9	2.8	2.9
Q365 B	0.4	0				
			0.3	0.3	0.4	0.4
0369 B	0.8	0.9	0.8	0.8	0.9	4.9
Q372 B	0	0	0	0	0	4.9
C	11.7	11.7	11.8	11.8	11.7	0
0374 B	10.4	10.3	10.1	10.3	10.7	6.4
С	0	0	0	0	6.2	6.7
E	6.4	6.4	6.3	6.3	6.1	6.7
		100	10.7	10.7	10.7	EO
Q375 B	10.7	10.8	10.7	10.7	10.7	5.9
	0	0	0	0	6.3	6.4


A BOARD (2/3) * MARK LIST

	PVM-20M4U/E/A	PVM-20M2U/E
C525	0.0115 2kV : PP	0.012_2kV : PP
C1524	100	#
C1525	0.0047 2kV E	#
C1531	0.1 25V B :CHIP	#
C1532	47 25V	#
C1534	47 25V	#
C1535	47 25V	#
C1536	0.1 :MPS	#
C1537	0.33 100V :MPS	#
CN509	3P WHT :S-MICRO	#
D544	MA111	#
D545	MA111	#
D546	V11N	#
D548	RD16ESB2	#
	LA6500-FA	#
IC511 IC512	NJM79M12FA	#
L506	1-459-087-00	1-459-104-00
L509	1-459-087-00	1-459-104-00
Q526	2SC4686A	#
Q527	2SC4686A	#
Q531	2SA1037K	#
Q532	IRF520	#
R562	47 1/4W : FPRD	22 1/4W : FPRD
R566	47k : RN-CP	27k : RN-CP
R574	47k : CHIP	
R577	10k : CHIP	#
R581	1k : CHIP	#
R584		#
	3.9k : CHIP	10k : CHIP
R1506 R1539	1k: CHIP	470 : CHIP
	100k : CHIP	#
R1542 R1564	22 : FPRD	#
	560 : RN-CP	#
R1580	27k : CHIP	#
R1581	10M 1W:RS	#
R1582	2M 1W : RS	#
R1583	470 1/2W : RF	#
R1584	9.1k : RN-CHIP	#
R1585	1.8k : CHIP	#
R1586	47k : RN-CHIP	#
R1587	2.2k : CHIP	#
R1588	2.2 : CHIP	#
R1590	10 : CHIP	#
R1591	0.47 : FPRD	#
R1592	4.7k 1/2W : FPRD	#
R1593	8.2 1/2W : FPRD	#
		#
R1594	8.2 TW : HS	
R1594	8.2 1W : RS 10k 1/2W : RC	
R1594 R1599	10k 1/2W : RC	#
R1594	8.2 TW : HS 10k 1/2W : RC 150k : CHIP 330k : CHIP	

A BOARD IC303 CXA1214P





A BOARD IC305 M51279FP





·A BOARD WAVEFORMS

10	(6)	10
1	75-75-	2/2000
1.0 Vp-p(H)	5-VIDED 0.94 Vp-p (H)	0.85 Vp-p(H)
(D)		
_	(18)	(19)
ALEST LEST	-11 Mary 11	3 4
5-v18E0 0.94 Vp-p (H)	0.6 Vp-p (H)	5-VIDEO 0.6 Vp-p (H)
20	20	
	NTSC3.58 0.24 Vp-p(H) NTSC4.43 0.12 Vp-p(H)	
PAL 0.2 Vp-p (H)	NTSC4.43 0.12 Vp-p (H)	
2)	②	2)
h-Oh-d		
PAL	SECAN	NTSC3.58. 4.43 0.24 Vp-p (H)
0.27 Vp-p(H)	0.17 Vp-p (H)	0.27 Vp-p(H)
(3)	2	2
PAL PA PA	MTSC3.58	The start
0.4 Vp-p (H)	MTSC3.58 0.37 Vp-p(H) MTSC4.43	S-VIDED 0.4 Vp-p(H)
0.36 Vp-p(H)	4.0 Vp-p (H)	
		29
	V V V	B-4-1100-4-10
ANALDO RGB 1.9 Vp-p (H)	1.0 Vp-p (H)	O. 26 Vp-p (H)
②	29	2 3
The same		
SECAN	NTSC3, 58, 4, 43	S-V10E0
0.2 Vp-p (H)	0.23 Vp-p (H)	0.18 Vp-p (H)
23	27	27
	manghaphr	man and
I V V V	PAL	NTSC3.58. 4.43 S-V10E0
5.4 Vp-p(H)	PAL 1.0 Vp-p (H)	1.1 Vp-p(H)
	_	
23 20. 110.	28 E.L. B.E.L.	29
	(B) (M) (M) (M) (M) (M) (M) (M) (M) (M) (M	29 7000 0000
	28 MTSC1.43 0.73 VP-P (H)	
PAL 0.8 Vp-p (H) 0.85 Vp-p (H)	(28) HTSC4.43 0.73 Vp-p (H) 0.9 Vp-p (H)	ANALGO RGB 0.7 Vp-p (H)
PAL O. 8 Vp-p (H) 0.85 Vp-p (H) 30	28 MTSC1.43 0.73 VP-P (H)	
PALO.8 Vp-p (H) 0.85 Vp-p (H) 30	(3) MTSC4.73 Vp-p (H) 0.773 Vp-p (H) 0.9 Vp-p (H)	ANALOGO RGE PP-P (H) 32
PAL O. 8 Vp-p (H) 0.85 Vp-p (H) 30	(28) HTSC4.43 0.73 Vp-p (H) 0.9 Vp-p (H)	
PALO.8 Vp-p (H) 0.85 Vp-p (H) 30	28 MTSC4,43 Vp-p (H) 9.73 Vp-p (H) 0.9 Vp-p (H) 31 ANALDO ROB 0.7 Vp-p (H)	ANALOO ROB 0.7 Vp-p (H)
PALO . 8 Vp-p (H) 0.85 Vp-p (H) 30 ANALOG ROB 0.7 Vp-p (H) 32	(3) (28) (10,4) (10	ANALOGO RGE PP-P (H) 32
PALO . 8 Vp-p (H) 0 . 85 Vp-p (H) 30 ANALOG RGB 0 . 7 Vp-p (H) 32 ANALOG RGB	(3) ANALDO ROB O.7 Vp-p (H) (3)	ANALOG RGB ANALOG RGB O. 7 Vp-p (H) 32 S-V10EQ 1.7 Vp-p (H)
PALO. 8 VP-P (H) NTSC3.55 VP-P (H) 30 ANALOG RGB 0.7 VP-P (H) 32	(3) (28) (10,4) (10	ANALOO ROB 0.7 Vp-p (H)
PALO . 8 Vp-p (H) 0 . 85 Vp-p (H) 30 ANALOG RGB 0 . 7 Vp-p (H) 32 ANALOG RGB	(3) ANALDO ROB O.7 Vp-p (H) (3)	ANALOG RGB ANALOG RGB O. 7 Vp-p (H) 32 S-V10EQ 1.7 Vp-p (H)
PALO. 8 Vp-p (H) 0.85 Vp-p (H) 30 ANALOG RGB 0.7 Vp-p (H) 32 ANALOG RGB 1.4 Vp-p (H)	MTSC4.43 Vp-p (H) 9.73 Vp-p (H) 9.9 Vp-p (H) 3) ANALOG RGB 0.7 Vp-p (H) 33 5-VIBEG 1.3 Vp-p (H)	ANALOO RGB 0.7 Vp-p(H) 32 5-V1060 1.7 Vp-p(H) 33 ANALOO RGB 1.4 Vp-p(H)
PALO . 8 VP - P (H) 0.85 VP - P (H) 30 ANALOG ROB 0.7 VP - P (H) 32 ANALOG ROB 1.4 VP - P (H) 34	(3) ANALDO ROB O.7 Vp-p (H) (3) S-VIDEO 1.3 Vp-p (H)	ANALOG RGB 5-VIDEO 1.7 Vp-p (H) 33 ANALOG RGB 1.4 Vp-p (H) 33
PALO : 8 VP-P (H) 0.85 VP-P (H) 30 ANALOG ROB 0.7 VP-P (H) 32 ANALOG ROB 1.4 VP-P (H) 34 5-VIBEO VP-P (H)	MTSC4.43 Vp-p (H) O.773 Vp-p (H) S-Vi060 O.9 Vp-p (H) ANALOG ROB O.7 Vp-p (H) S-VIDEO 1.3 Vp-p (H)	ANALOG RGB 1.4 Vp-p(H) 39 ANALOG RGB 1.4 Vp-p(H) 39 PAL 0.3 Vp-p(H)
PALO . 8 VP - P (H) 0.85 VP - P (H) 30 ANALOG ROB 0.7 VP - P (H) 32 ANALOG ROB 1.4 VP - P (H) 34	(3) ANALDO ROB O.7 Vp-p (H) (3) S-VIDEO 1.3 Vp-p (H)	ANALOG RGB 5-VIDEO 1.7 Vp-p (H) 33 ANALOG RGB 1.4 Vp-p (H) 33
PALO . 8 VP - P (H) 0.85 VP - P (H) 30 ANALOG ROB 0.7 VP - P (H) 32 ANALOG ROB 1.4 VP - P (H) 34 5-VIBEO 1.3 VP - P (H)	(3) S-VIDEO ROB 1.4 Vp-p(H) (3) S-VIDEO NO ROB 1.4 Vp-p(H) (3) ANALOO ROB 1.4 Vp-p(H) (3)	ANALOG RGB 5-VIBEG 1.7 Vp-p (H) 33 ANALOG RGB 1.4 Vp-p (H) 35 PAL 0.3 Vp-p (H)
PALO : 8 VP-P (H) 0.85 VP-P (H) 30 ANALOG ROB 0.7 VP-P (H) 32 ANALOG ROB 1.4 VP-P (H) 34 5-VIBEO VP-P (H)	MTSC4.43 Vp-p (H) O.773 Vp-p (H) S-Vi060 O.9 Vp-p (H) ANALOG ROB O.7 Vp-p (H) S-VIDEO 1.3 Vp-p (H)	ANALOG RGB 5-VIBEG 1.7 Vp-p (H) 33 ANALOG RGB 1.4 Vp-p (H) 35 PAL 0.3 Vp-p (H)
PALO . 8 Vp - p (H) 0.85 Vp - p (H) 30 ANALOG ROB 0.7 Vp - p (H) 32 ANALOG ROB 1.4 Vp - p (H) 34 5-VIDED 1.3 Vp - p (H) 35 SECAM 0.1 Vp - p (H)	MTSC4.43 Vp-p (H) O.773 Vp-p (H) O.9 Vp-p (H) ANALOG ROB O.7 Vp-p (H) S-VIBEO 1.3 Vp-p (H) ANALOG ROB 1.4 Vp-p (H) S-VIBEO O.15 Vp-p (H)	ANALOG RGB 1.7 Vp-p (H) 32 5-V10EQ 1.7 Vp-p (H) 33 ANALOG RGB 1.4 Vp-p (H) 35 PAL 0.3 Vp-p (H) 35 MT9C4.AB 0.3 Vp-p (H)
PALO . 8 VP - P (H) 0.85 VP - P (H) 30 ANALOG ROB 0.7 VP - P (H) 32 ANALOG ROB 1.4 VP - P (H) 34 5-VIBEO 1.3 VP - P (H)	MTSC3.73 Vp-p (H) S-VIDEO 0.9 Vp-p (H) ANALDO ROB 0.7 Vp-p (H) 33 S-VIDEO 1.3 Vp-p (H) 34 ANALOG ROB 1.4 Vp-p (H) 35 NTSC3.58 0.15 Vp-p (H)	ANALOG RGB 5-VIBEG 1.7 Vp-p (H) 33 ANALOG RGB 1.4 Vp-p (H) 35 PAL 0.3 Vp-p (H)
PALO . 8 Vp-p (H) 0.85 Vp-p (H) 30 ANALOG RGB 0.7 Vp-p (H) 32 ANALOG RGB 1.4 Vp-p (H) 33 5-V10ED 3 Vp-p (H) 35 SECAM 0.1 Vp-p (H)	MTSC4.43 Vp-p (H) S-ViDEO 1.3 Vp-p (H) 3) S-VIDEO 1.3 Vp-p (H) 34 AMALOO ROB 1.4 Vp-p (H) 35 NTSC3.50 Vp-p (H) 36	ANALOG RGB S-VIBEG ANALOG RGB ANALOG RGB 1.4 Vp-p (H) 33 ANALOG RGB ANALOG RGB O. 3 Vp-p (H) 39 MTSC4. AS Vp-p (H) 39
PAL () . 8 Vp - p (H) () . 85 Vp - p (H) () . 85 Vp - p (H) () . 1 Vp - p (H) () . 2 Vp - p (H) () . 4 Vp - p (H) () . 5 Vp - p (H) () . 5 Vp - p (H)	MTSC3.73 Vp-p (H) S-VIDEO 0.9 Vp-p (H) ANALDO ROB 0.7 Vp-p (H) 33 S-VIDEO 1.3 Vp-p (H) 34 ANALOG ROB 1.4 Vp-p (H) 35 NTSC3.58 0.15 Vp-p (H)	ANALOG RGB 1.7 Vp-p (H) 32 5-V10EQ 1.7 Vp-p (H) 33 ANALOG RGB 1.4 Vp-p (H) 35 PAL 0.3 Vp-p (H) 35 MT9C4.AB 0.3 Vp-p (H)
PALO: 8 VP-P (H) 0.85 VP-P (H) 30 ANALOG RGB 0.7 VP-P (H) 32 ANALOG RGB 1.4 VP-P (H) 34 S-VIDED VP-P (H) 35 SECAM 0.1 VP-P (H) 35	MTSC4.43 Vp-p (H) S-ViDEO 1.3 Vp-p (H) 3) S-VIDEO 1.3 Vp-p (H) 34 AMALOO ROB 1.4 Vp-p (H) 35 NTSC3.50 Vp-p (H) 36	ANALOG RGB 1.4 Vp-p (H) 33 ANALOG RGB 1.4 Vp-p (H) 35 PAL 0.3 Vp-p (H) 35 MTSCA. AT Vp-p (H) 36 SECAN
PALO . 8 VP-P (H) 0.85 VP-P (H) 30 ANALOG RGB O. 7 VP-P (H) 32 ANALOG RGB I. 4 VP-P (H) 34 S-VIDEO O. 1 VP-P (H) 35 SECAM O. 1 VP-P (H) 35 5-VIDEO O. 2 VP-P (H)	MTSC3.58 VP-P(H) 3 AMALOO ROB 1.3 VP-P(H) 3 AMALOO ROB 1.4 VP-P(H) 3 AMALOO ROB 1.5 VP-P(H) 3 AMALOO ROB 1.5 VP-P(H) 3 AMALOO ROB 1.3 VP-P(H) 3 AMALOO ROB 1.3 VP-P(H) 4 AMALOO ROB 1.4 VP-P(H) 4 AMALOO ROB 1.5 VP-P(H) 4 AMALOO ROB 1.5 VP-P(H)	ANALOG RGB
PALL O. 8 VP-P (H) 0. 85 VP-P (H) 30 ANALOG RGB 0. 7 VP-P (H) 32 ANALOG RGB 1. 4 VP-P (H) 33 SECAM 0. 1 VP-P (H) 35 SECAM 0. 2 VP-P (H) 36	MTSC4.43 Vp-p (H) O.773 Vp-p (H) O.9 Vp-p (H) ANALOO ROB O.7 Vp-p (H) 3 S-VIBED 1.3 Vp-p (H) 3 ANALOO ROB 1.4 Vp-p (H) 3 ANALOO ROB 0.15 Vp-p (H) 3 PAL 0.3 Vp-p (H) 3 PAL 0.3 Vp-p (H)	ANALOGO RGB O. 7 Vp-p (H) 32 5-V10EQ 1. 7 Vp-p (H) 33 ANALOG RGB 1. 4 Vp-p (H) 35 PAL O. 3 Vp-p (H) 35 NT9C4. AN Vp-p (H) 36 SECAN O. 1 Vp-p (H) 36
PALO . 8 VP-P (H) 0.85 VP-P (H) 30 ANALOG ROB 0.7 VP-P (H) 32 ANALOG ROB 1.4 VP-P (H) 33 S-VIDEO 0.1 VP-P (H) 35 S-VIDEO 0.2 VP-P (H) 36 NTSC3.58 0.07 VP-P (H)	MTSC4.43 Vp-p (H) 31 ANALDO ROB 0.7 Vp-p (H) 33 S-VIDEO 1.3 Vp-p (H) 34 ANALOO ROB 0.15 Vp-p (H) 35 NTSC3.50 Vp-p (H) 36 PALO.3 Vp-p (H) 36 NTSC4.43 Vp-p (H)	ANALOG RGB
PALO . 8 VP-P (H) 0.85 VP-P (H) 30 ANALOG RGB 0.7 VP-P (H) 32 ANALOG RGB 1.4 VP-P (H) 33 S-VIOCO 0.1 VP-P (H) 35 SECAM 0.1 VP-P (H) 36	MTSC4.43 Vp-p (H) O.773 Vp-p (H) O.9 Vp-p (H) ANALOO ROB O.7 Vp-p (H) 3 S-VIBED 1.3 Vp-p (H) 3 ANALOO ROB 1.4 Vp-p (H) 3 ANALOO ROB 0.15 Vp-p (H) 3 PAL 0.3 Vp-p (H) 3 PAL 0.3 Vp-p (H)	ANALOGO RGB O. 7 Vp-p (H) 32 5-V10EQ 1. 7 Vp-p (H) 33 ANALOG RGB 1. 4 Vp-p (H) 35 PAL O. 3 Vp-p (H) 35 NT9C4. AN Vp-p (H) 36 SECAN O. 1 Vp-p (H) 36
PALO . 8 VP-P (H) 0.85 VP-P (H) 30 ANALOG ROB 0.7 VP-P (H) 32 ANALOG ROB 1.4 VP-P (H) 33 S-VIDEO 0.1 VP-P (H) 35 S-VIDEO 0.2 VP-P (H) 36 NTSC3.58 0.07 VP-P (H)	MTSC4.43 Vp-p (H) 31 ANALDO ROB 0.7 Vp-p (H) 33 S-VIDEO 1.3 Vp-p (H) 34 ANALOO ROB 0.15 Vp-p (H) 35 NTSC3.50 Vp-p (H) 36 PALO.3 Vp-p (H) 36 NTSC4.43 Vp-p (H)	ANALOGO RGB O. 7 Vp-p (H) 32 5-V10EQ 1. 7 Vp-p (H) 33 ANALOG RGB 1. 4 Vp-p (H) 35 PAL O. 3 Vp-p (H) 39 NT9C4. AN O. 3 Vp-p (H) 30 SECAM O. 1 Vp-p (H) 30
PALO . 8 VP-P (H) 0.85 VP-P (H) 30 ANALOG ROB 0.7 VP-P (H) 32 ANALOG ROB 1.4 VP-P (H) 33 S-VIDEO 0.1 VP-P (H) 35 S-VIDEO 0.2 VP-P (H) 36 NTSC3.58 0.07 VP-P (H)	MTSC4.43 Vp-p (H) 31 ANALOG ROB 1-1.3 Vp-p (H) 33 S-VIDEO 1-3 Vp-p (H) 34 ANALOG ROB 0.15 Vp-p (H) 35 NTSC3.50 Vp-p (H) 36 PALO.3 Vp-p (H) 36 NTSC4.43 Vp-p (H) 38	ANALOGO RGB O. 7 Vp-p (H) 32 5-V10EQ 1. 7 Vp-p (H) 33 ANALOG RGB 1. 4 Vp-p (H) 35 PAL O. 3 Vp-p (H) 39 NT9C4. AN O. 3 Vp-p (H) 30 SECAM O. 1 Vp-p (H) 30
PAL () . 8 Vp - p (H) () . 85 Vp - p (H) () . 85 Vp - p (H) () . 85 Vp - p (H) () . 7 Vp - p (H) () . 4 Vp - p (H) () . 5 Vp - p (H) () . 5 Vp - p (H) () . 5 Vp - p (H) () . 6 Vp - p (H) () . 6 Vp - p (H) () . 7 Vp - p (H) () . 7 Vp - p (H) () . 7 Vp - p (H) () . 7 Vp - p (H) () . 7 Vp - p (H) () . 7 Vp - p (H) () . 7 Vp - p (H)	MTSC4.43 Vp-p (H) 31 ANALDO ROB 0.7 Vp-p (H) 33 S-VIDEO 1.3 Vp-p (H) 34 ANALOO ROB 0.15 Vp-p (H) 35 NTSC3.50 Vp-p (H) 36 PALO.3 Vp-p (H) 36 NTSC4.43 Vp-p (H)	ANALOGO RGB O. 7 Vp-p (H) 32 5-V10EQ 1. 7 Vp-p (H) 33 ANALOG RGB 1. 4 Vp-p (H) 35 PAL O. 3 Vp-p (H) 39 NT9C4. AN O. 3 Vp-p (H) 30 SECAM O. 1 Vp-p (H) 30










- 69 -

-7



\$\frac{\text{\$A BOA}}{\text{\$\frac{3}{9}}}\$\$
\$\times 0.7 \text{\$\frac{4}{9}}\$\$
\$\tag{10.0 \text{\$\frac{4}{9}}}\$\$
\$\tag{4.2 \text{\$\frac{4}{9}}}\$\$
\$\tag{11.0 \text{\$\frac{4}{9}}}\$\$
\$\tag{11.0 \text{\$\frac{4}{9}}}\$\$
\$\tag{5.9 \text{\$\frac{4}{9}}}\$\$
\$\tag{5.9 \text{\$\frac{4}{9}}}\$\$

60


63

6


3.8 V

170 V







·A BOARD WAVEFORMS




A BOARD IC404 CXA1739S




A BOARD IC200 AN5265




A BOARD IC101 µPD78013YCW







A BOARD IC404 CXA1739S



A BOARD IC200 AN5265



A BOARD IC101 μPD78013YCW





Schematic diagram


Schematic diagrams


(A(3/3)) board


-73 -























24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 |






CN108 3P BLK-L :S-MICRO ALLY C CN602







-G BOARD-




-G BOARD-























-Q BOARD-



-J BOARD-




-S BOARD-PVM-20M2U/20M4U ONLY




-X BOARD-









C BOARD * MARK LIST

	PAL	SECAM	NTSC 3.58	NTSC 4.43	S-VIDEO	ANALOG RGB
Q701 B	2.0	1.9	1.73	1.8	1.8	2.0
E	1.4	1.3	1.1	1.1	1.2	1.4
0702 B	2.0	1.9	1.7	1.7	1.8	2.0
E	1.5	1.3	1.1	1.1	1.2	1.4
Q703 B	1.9	1.8	1.6	1.6	1.8	1.9
E	1.3	1.2	1.0	1.0	1.2	1.3
Q704 B	143.6	148.0	153.9	153.4	144.9	143.8
C	129.0	134.3	135.4	134.5	31.2	111.5
E	139.7	144.4	150.3	149.6	140.4	140.1
Q705 B	141,7	145.8	154.9	154.2	145.0	141.8
C	124.9	130.2	132.3	130.4	60.4	106.6
E	138.3	142.3	151.3	150.6	140.7	138.5
Q706 B	149.7	151.5	160.4	159.8	144.9	148.6
С	134.5	138.3	141.2	141.1	103.2	114.7
E	146.2	148.0	157.1	156.4	140.8	145.0
Q707 C	143.8	148.0	154.0	153.4	144.9	143.7
0708 C	141.9	145.9	155.2	154.3	145.0	141.8
0709 C	149.8	151.5	160.6	159.9	144.9	148.5
Q710 B	172.8	173.1	174.3	173.9	167.0	173.5
E	160.9	164.0	162.9	162.2	154.0	161.2
Q711 B	172.8	173.2	174.3	173.9	167.0	173.5
C	160.6	161.0	162.3	161.8	154.1	161.3
Q712 B	172.9	173.2	174.0	174.2	167.0	173.5
E	161.6	163.6	164.1	164.8	154.5	161.4
Q713 B	172.8	173.2	173.9	173.9	166.8	173.5
С	184.2	184.5	184.7	184.6	176.6	183.8
E	173.3	173.6	174.3	174.3	167.2	173.9
Q714 C	173.6	173.7	174.5	174.4	167.4	174.1
Q715 B	146.7	148.6	157.6	157.0	140.3	145.7
С	149.5	151.5	160.6	159.9	144.9	148.5
Ē	146.1	148.0	157.2	156.5	140.7.	145.0
Q716 B	139.2	143.3	152.5	151.5	140.7	139.4
C	141.7	145.8	155.2	154.2	145.1	141.8
E	138.2	142.3	151.4	150.5	140.6	138.4
Q717 B	140.9	145.4	151.7	150.8	140.6	141.2
C	143.6	148.0	154.1	153.4	144.9	143.8
E	139.8	144.4	150.5	149.6	140.4	140.0

D703	PROTECT 3
D704	PROTECT 4
D705	PROTECT 5
D706	PROTECT 6
D707	PROTECT 7
D708	PROTECT 8
D709	PROTECT 9
D713	PROTECT 10
D715	PROTECT 11
D716	PROTECT 12
D717	PROTECT 13
0701	B DRIVE
0702	G DRIVE
0703	R DRIVE
Q704	B BUFF
Q705	G BUFF
0706	R BUFF
Q707	B OUT
Q708	G OUT
0709	R OUT
0710	IK SW 1
0711	IK SW 2
0712	IK SW 3
Q713	V. BLK OUT
Q714	V. BLK INT
0715	TRACE SW 1
Q716	TRACE SW 2
0717	TRACE SW 3


D701 PROTECT 1
D702 PROTECT 2

WAVEFORMS


,(н)	2 \$98.0 Vp-p (H) \$96.0 Vp-p (H)	ONTSC3.58 Vp-p (H) NTSC4.43 NP-p (H)	2 5-V18E0 69.0 Vp-p (H) AMALOG RGB 88.0 Vp-p (H)	3
ь(H)	3 78.0 Vp-p (H)	(4) (1) (1) (1) (1) (1) (1) (1) (1) (1) (1	(4) UUUUU MT963:58 (1:43 p (H)	4 S 7 8 . 0 Vp - p (H) AMALOG RGB 88 . 0 Vp - p (H)



-C BOARD- PVM-20M2U/20M2E ONLY




-C BOARD- PVM-20M4U/20M4E/20M4A ONLY



– 86 –

6-5. SEMICONDUCTORS



- 87 -

SECTION 7 EXPLODED VIEWS

NOTE:

· Items with no part number and no description are not stocked because they are seldom required for routine service.

7-1. CHASSIS

- : 7-685-648-79 +BVTP 3X12 +PS 4X8 **1**: 7-682-661-01 **+BVTP 3X8 ▲** : 7-685-646-79 **+BVTP 4X16 •** : 7-685-663-79
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.


The componants identified by shading and mark A are criti-

7-2. PICTURE TUBE

: 7-685-648-79


+BVTP 3X12

Les composants identifies par une trame et une marque A sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.



The componants identified by shading and mark A are critical for safety. Replace only with part number specified.

Les composants identifies par une trame et une marque A sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.



					(69)	•	
REF. N	O. PART NO.	DESCRIPTION	REMARK	REF. NO	PART NO.	DESCRIPTION	REMARK
51		BEZEL ASSY (20M2U/E) BEZEL ASSY (20M4U/E/A)	52-57 52-57		4-901-947-01	LEG	
52	4-052-200-01		32-37		L 8-736-135-05	PICTURE TUBE 20FZ5	(DADE) (SOLESTIA)
53	* 4-043-670-01				8-736-379-05		
54	* 4-043-669-01				8-736-381-05		
٠.	10100000	nem i ortoeniem (e), m m vee		76	3-704-372-01		
55	* 4-043-797-01	PLATE, BLIND		77	3-703-961-01		
56		BRACKET (A), PICTURE TUBE					
57	* 4-043-673-01	BRACKET (B), PICTURE TUBE		78 /	<u> 1-451-349-11</u>	DEFLECTION YOKE (Y20FZA) (20M2U/E)
58	* A-1450-186-A	BRACKET ASSY (R), SIDE			61-451-456-11	DEFLECTION YOKE (Y20MTA) (20M4U/E/A)
59	* A-1450-185-A	BRACKET ASSY (L), SIDE				NA3012-M4 (20M4U/E	
						C BOARD, COMPLETI	
60	4-044-606-01				* A-1331-628-A	C BOARD, COMPLETI	E (20M4U/E/A)
61	* 4-043-671-01						************************************
62		X BOARD, COMPLETE				COIL, DEMAGNETIZA	ITION
63		SCREW, TAPPING, STEP (20M4U/E			* 4-303-774-99		
64	* 4-379-189-01	CUSHION, SPEAKER (20M4U/E/A)			1411-657-11		RECTION (20M4U/E/A)
	4 844 040 40			84	1-543-827-11	CLAMP, SLEEVE FERE	
65	1-544-063-12	SPEAKER		0.5	4 000 004 01	50DDW 440 (DV	(20M2E/20M4E/20M4A)
66		H BOARD, COMPLETE		85	4-389-025-01	SCREW (M4) (EXT TO	OTH WASHER)
67 68	4-043-802-02			0.0	+ 4 207 204 01	HOLDED LEAD	
69	4-043-681-01 4-043-683-01			86 87	* 4-387-284-01 4-365-808-01	HOLDER, LEAD	
09	4-043-063-01	BUTTOM, POWER SWITCH		88	4-308-870-00	SCREW (5), TAPPING CLIP,LEAD WIRE	
70	A 12602-021-11	SWITCH,PUSH (A.C. POWER)		89	1-452-032-00	MAGNET, DISK: 10mn	24
71		J BOARD, COMPLETE		90	1-452-094-00		
72		CABINET ASSY, BOTTOM	73,74		1-432-034-00	MACINEI, KOIAIABL	L'DISK, IJIIIII
73		CABINET, BOTTOM	13,14	91	4-051-736-21	PIECE A(90), CONV. C	ORRECT
			i	, ,,	7 331-130-21		V.C.C.

(20M2E/20M4E/20M4A)

*4-043-690-01 BRACKET, MAIN

SECTION 8 ELECTRICAL PARTS LIST



NOTE:

Les composants identifies par une trame et une marque A sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The componants identified by shading and mark A are critical for safety.
Replace only with part number specified.

- The components identified by
 in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

When indicating parts by reference number, please include the board name.

RESISTORS

- · All resistors are in ohms
- F : nonflammable
- CAPACITORS PF : μμ F
- There are some cases the reference number on one board overlaps on the other board. Therefore, when ordering parts by the reference number, please include the board name.

REF. NO.	PART NO.	DESCRIPTION		REMARK	REF. NO.	PART NO.	DESCRIPTION		Ē	REMARK
	* A-1298-003-A	A BOARD, COMPLETE (I	PVM-20)M4U/E/A)	C200 C201	1-126-963-11 1-137-353-11		4.7MF 0.047MF	20% 10%	50V 100V
	* A-1298-005-A	A BOARD, COMPLETE (I	PVM-20	M2U/E)	C202 C203 C204	1-163-017-00 1-126-963-11 1-126-964-11		0.0047MF 4.7MF 10MF	10% 20% 20%	50V 50V 50V
	* 4-043-994-01	SOCKET, IC (20M4U/E/A) PLATE (CF), SHIELD SCREW (M3X10), P, SW (+)		C205 C206	1-126-767-11 1-128-526-11		1000MF 100MF	20% 20%	16V 25V
	7-682-948-01	SCREW +PSW 3X8			C207 C208 C209	1-104-665-11 1-126-964-11 1-126-963-11	ELECT ELECT	100MF 10MF 4.7MF	20% 20% 20%	25V 50V 50V
PPE400	1 224 242 11	<band filter="" pass=""></band>			C300 C301		CERAMIC CHIP CERAMIC CHIP		0.25PF	50V 50V
BPF400	1-230-303-11	FILTER, BAND PASS			C302 C304		CERAMIC CHIP CERAMIC CHIP		0.25PF 10%	50V 25V
		<capacitor></capacitor>			C305 C306	1-163-259-91	CERAMIC CHIP CERAMIC CHIP	220PF	5%	50V 50V
C105 C106	1-163-251-11	CERAMIC CHIP 100PF CERAMIC CHIP 100PF	5% 5%	50V 50V	C309	1-163-031-11	CERAMIC CHIP	0.01MF		50V
C114 C115 C116	1-163-031-11	CERAMIC CHIP 0.01MF CERAMIC CHIP 0.01MF CERAMIC CHIP 0.01MF		50V 50V 50V	C310 C311 C312		CERAMIC CHIP		10% 10% 20%	25V 25V 50V
C110		CERAMIC CHIP 0.01MF		50V	C312 C313 C314	1-163-145-00	CERAMIC CHIP CERAMIC CHIP	0.0015MF		50V 50V
C118 C119	1-165-319-11	CERAMIC CHIP 220PF CERAMIC CHIP 0.1MF	5%	50V 50V	C315	1-126-964-11		10MF	20%	50V
C121 C123		CERAMIC CHIP 27PF CERAMIC CHIP 0.1MF	5%	50V 50V	C316 C317 C318	1-104-664-11 1-163-231-11 1-126-964-11	CERAMIC CHIP	47MF 15PF 10MF	20% 5% 20%	25V 50V 50V
C124 C132	1-163-141-00	CERAMIC CHIP 100PF CERAMIC CHIP 0.001MF	5% 5%	50V 50V	C319	1-163-222-11	CERAMIC CHIP	5PF	0.25PF	50V
C133 C134	1-163-251-11	CERAMIC CHIP 100PF CERAMIC CHIP 100PF CERAMIC CHIP 100PF	5% 5% 5%	50V 50V 50V	C320 C322 C323	1-163-119-00	CERAMIC CHIP	120PF	5% 5%	50V 50V 50V
C135 C136		CERAMIC CHIP 100PF	5%	50V	C324 C325		CERAMIC CHIP CERAMIC CHIP ELECT		5% 20%	50V 50V
C140 C141	1-164-004-11 1-164-161-11	CERAMIC CHIP 0.1MF CERAMIC CHIP 0.0022MF		25V 50V	C326	1-164-004-11	CERAMIC CHIP	0.1MF	10%	25V
C142 C143		CERAMIC CHIP 220PF CERAMIC CHIP 0.1MF	5%	50V 50V	C327 C328 C329	1-163-031-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.01MF	10% 5%	25V 50V 50V
C144 C145		CERAMIC CHIP 0.1MF CERAMIC CHIP 0.1MF		50V 50V	C330		CERAMIC CHIP		5%	50V
C154 C155	1-163-023-00	CERAMIC CHIP 0.022MF CERAMIC CHIP 0.015MF CERAMIC CHIP 0.0068MF	10% 10%	50V 50V	C331 C332	1-164-004-11	CERAMIC CHIP	0.1MF	5% 10%	50V 25V
C156 C157		CERAMIC CHIP 0.0068MF		50V 50V	C333 C334 C335	1-163-141-00	CERAMIC CHIP CERAMIC CHIP	0.001MF	5% 5%	50V 50V 50V
C158 C159	1-163-809-11 1-164-344-11	CERAMIC CHIP 0.047MF CERAMIC CHIP 0.068MF	10% 10%	25V 25V	C336	1-104-664-11	ELECT	47MF	20%	25V
C161 C162	1-104-664-11 1-163-141-00	CERAMIC CHIP 0.001MF	20% 5%	25V 50V	C337 C338 C339	1-163-119-00	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	120PF	5% 5%	50V 50V
C164 C165		CERAMIC CHIP 0.1MF CERAMIC CHIP 0.1MF		50V 50V	C340		CERAMIC CHIP		J-74	50V 50V
C166 C167	1-126-925-11		10% 20%	25V 10V	C341 C342	1-163-018-00	CERAMIC CHIP CERAMIC CHIP	0.0056MF	5% 10%	50V 50V
C168 C169	1-126-925-11	ELECT 470MF CERAMIC CHIP 0.01MF	20% 10%	10V 50V	C343 C344 C345	1-163-141-00	CERAMIC CHIP CERAMIC CHIP	0.001MF	5% 5%	50V 50V 50V
C171 C174	1-163-251-11	CERAMIC CHIP 100PF CERAMIC CHIP 47PF	5% 5%	50V 50V	C346 C347	1-126-960-11		1MF	20% 5%	50V 50V



REF. NO.	PART NO.	DESCRIPTION		REMARK	REF. NO.	PART NO.	DESCRIPTION		REMARK
C348	1-164-004-11	CERAMIC CHIP 0.1M			C421		CERAMIC CHIP 0.22MF		25V
C349		CERAMIC CHIP 0.00		50V 50V	C422 C423	1-126-960-11	ELECT 1MF CERAMIC CHIP 0.047MF	20% 10%	50V 25V
C350	1-103-141-00	CERAMIC CHIP 0.00	MIF 370	30₹	C424		CERAMIC CHIP 0.047MF	10%	25V
C351	1-104-664-11				C426	1 162 242 11	CERAMIC CUID ATRE	5%	50V
C352 C353		CERAMIC CHIP 0.01 CERAMIC CHIP 0.1M		50V 50V	C426 C427		CERAMIC CHIP 47PF CERAMIC CHIP 0.01MF	370	50V
C354		CERAMIC CHIP 150H	F 5%	50V	C428	1-104-661-91	ELECT 330MF	20%	16V
C355	1-126-960-11	ELECT 1MF	20%	50V	C429 C430	1-163-031-11 1-104-661-91	CERAMIC CHIP 0.01MF ELECT 330MF	20%	50V 16V
C356	1-126-963-11	ELECT 4.7N	F 20%	50V	C430	1-104-001-91	BLECI JJUMI	20 10	104
C357	1-163-031-11	CERAMIC CHIP 0.01	MF .	50V	C431		CERAMIC CHIP 0.1MF	100	50V
C358 C359	1-163-031-11 1-104-664-11	CERAMIC CHIP 0.01 ELECT 47M		50V 25V	C432 C433		CERAMIC CHIP 0.1MF CERAMIC CHIP 22PF	10% 5%	25V 50V
C360		CERAMIC CHIP 0.01			C434		CERAMIC CHIP 0.1MF	10%	25V
C261	1 162 021 11	CED ANG CHIP A A1	ATC:	50V	C435	1-163-089-00	CERAMIC CHIP 6PF	0.25PF	50V
C361 C362		CERAMIC CHIP 0.01 CERAMIC CHIP 0.01		50V	C436	1-164-004-11	CERAMIC CHIP 0.1MF	10%	25V
C363	1-163-099-00	CERAMIC CHIP 18PI	5%	50V	C437		CERAMIC CHIP 0.1MF	10%	25V
C364		CERAMIC CHIP 0.01 MYLAR 0.00		50V 100V	C438 C439		CERAMIC CHIP 0.047MF CERAMIC CHIP 0.047MF	10% 10%	25V 25V
C365	1-106-343-00	MILAR 0.00	IMI. 10%	100 4	C440		CERAMIC CHIP 0.1MF	10%	25 V
C366		CERAMIC CHIP 0.01		50V	6441	1 104 040 11	ELECT 2.2ME	200	50V
C367 C368	1-163-031-11 1-124-261-00	CERAMIC CHIP 0.01 ELECT 10M		50V 50V	C441 C442	1-126-962-11	ELECT 3.3MF CERAMIC CHIP 0.047MF	20% 10%	25V
C369		CERAMIC CHIP 0.15			C443		CERAMIC CHIP 39PF	5%	50V
C370	1-104-664-11				C444		CERAMIC CHIP 0.1MF	100	50V
C371	1-104-664-11	ELECT 47M	F 20%	25V	C445	1-163-809-11	CERAMIC CHIP 0.047MF	10%	25V
C371		CERAMIC CHIP 0.01		50V	C446	1-163-229-11	CERAMIC CHIP 12PF	5%	50V
C373	1-163-141-00	CERAMIC CHIP 0.00	MF 5%	50V	C447		CERAMIC CHIP 330PF	5%	50V
C374	1-126-960-11			50V 50V	C448 C449		CERAMIC CHIP 39PF CERAMIC CHIP 10PF	5% 0.5PF	50V 50V
C375	1-103-239-91	CERAMIC CHIP 2201	r 370	30 V	C450		CERAMIC CHIP 0.047MF	10%	25V
C376	1-126-959-11				CASI	1 164 004 11	CER ANG CUID O INC	1.007	2637
C377 C378		CERAMIC CHIP 0.04 CERAMIC CHIP 0.04			C451 C452		CERAMIC CHIP 0.1MF CERAMIC CHIP 330PF	10% 5%	25V 50V
C379		CERAMIC CHIP 0.01		50V	C453	1-164-004-11	CERAMIC CHIP 0.1MF	10%	25V
C380	1-126-767-11	ELECT 1000	MF 20%	16V	C454		CERAMIC CHIP 39PF	5%	50V 50V
C381	1-163-031-11	CERAMIC CHIP 0.01	MF	50V	C455	1-103-203-11	CERAMIC CHIP 330PF	5%	30 V
C382		CERAMIC CHIP 47PI	5%	50V	C456		CERAMIC CHIP 12PF	5%	50V
C383 C384	1-104-664-11	ELECT 47M CERAMIC CHIP 82PI		25V 50V	C457 C458		CERAMIC CHIP 0.1MF CERAMIC CHIP 82PF	10% 5%	25V 50V
C385	1-103-249-11				C459		CERAMIC CHIP 0.1MF	370	50V
G007			D 000	5017	C460	1-164-004-11	CERAMIC CHIP 0.1MF	10%	25V
C386 C387	1-124-261-00	ELECT 10M CERAMIC CHIP 0.00		50V 50V	C461	1-163-119-00	CERAMIC CHIP 120PF	5%	50V
C388	1-124-261-00				C462		CERAMIC CHIP 0.1MF	10%	25V
C389	1-104-664-11				C463		CERAMIC CHIP 0.1MF	10% 10%	25V 25V
C390	1-163-243-11	CERAMIC CHIP 47PI	5%	50V	C464 C465		CERAMIC CHIP 0.22MF CERAMIC CHIP 15PF	5%	50V
C391	1-104-664-11	ELECT 47M	F 20%	25V					5011
C392 C393		CERAMIC CHIP 0.15			C466 C467		CERAMIC CHIP 120PF CERAMIC CHIP 120PF	5% 5%	50V 50V
C394	1-104-298-11	CERAMIC CHIP 0.15 ELECT 47M			C469		CERAMIC CHIP 0.022MF	10%	50V
C395	1-163-235-11	CERAMIC CHIP 22P		50V	C470		CERAMIC CHIP 47PF	5%	50V
C396	1-164-200-11	CERAMIC CHIP 0.22	MF 10%	25V	C471	1-103-105-00	CERAMIC CHIP 33PF	5%	50V
C397	1-104-664-11				C472		CERAMIC CHIP 0.01MF		50V
C398	1-104-664-11				C473		CERAMIC CHIP 0.01MF		50V 50V
C399 C400	1-104-664-11 1-164-004-11	ELECT 47M CERAMIC CHIP 0.1N			C475 C476		CERAMIC CHIP 0.01MF CERAMIC CHIP 0.01MF		50V
					C477		CERAMIC CHIP 0.22MF	10%	25V
C401 C402		CERAMIC CHIP 1MF ELECT 47M		16V 50V	C478	1-126-964-11	ELECT 10MF	20%	50V
C402	1-126-967-11 1-164-232-11	CERAMIC CHIP 0.01			C478		CERAMIC CHIP 150PF	5%	50V
C406	1-126-965-11	ELECT 22M	F 20%	50V	C482	1-126-925-11		20%	10V
C407	1-104-664-11	ELECT 47M	F 20%	25V	C483 C484		CERAMIC CHIP 82PF CERAMIC CHIP 68PF	5% 5%	50V 50V
C408	1-164-232-11	CERAMIC CHIP 0.01	MF 10%	50V	C707				
C409	1-163-031-11	CERAMIC CHIP 0.01	MF	50V	C485		CERAMIC CHIP 68PF	5%	50V 50V
C410 C411	1-126-965-11	ELECT 22M CERAMIC CHIP 0.1N			C486 C487		CERAMIC CHIP 82PF CERAMIC CHIP 22PF	5% 5%	50V
C414		CERAMIC CHIP 0.11		50V	C490	1-164-336-11	CERAMIC CHIP 0.33MF	- /-	25V
CA15				£01/	C491	1-164-336-11	CERAMIC CHIP 0.33MF		25V
C415 C416	1-126-964-11 1-164-232-11	ELECT 10M CERAMIC CHIP 0.01			C492	1-164-336-11	CERAMIC CHIP 0.33MF		25V
C417	1-164-232-11	CERAMIC CHIP 0.01	MF 109	50V	C493	1-104-760-11	CERAMIC CHIP 0.047MF	10%	50V
C418 C419		CERAMIC CHIP 0.00			C494 C495	1-164-005-11 1-126-964-11	CERAMIC CHIP 0.47MF ELECT 10MF	20%	25V 50V
	1-126-925-11				C495		CERAMIC CHIP 82PF	5%	50V
C420	1-163-809-11	CERAMIC CHIP 0.04	7MF 109	25V	1				

The componants identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

Les composants identifies par une trame et une marque Λ sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.



REF. NO.	PART NO.	DESCRIPTION		R	REMARK	REF. NO.	PART NO.	DESCRIPTION			REMARK
C497 C498 C499	1-126-961-11 1-163-031-11	CERAMIC CHIP	2.2MF 0.01MF	10% 20%	50V 50V 50V	C572 C573 C575	1-104-709-11 1-136-177-00 1-163-031-11		4.7MF 1MF 0.01MF	0 5%	160V 50V 50V
C500 C501	1-164-182-11	CERAMIC CHIP CERAMIC CHIP	0.0033MF		25V 50V	C576 C577	1-102-244-00 1-107-906-11	ELECT	220PF 10MF	10% 20%	500V 50V
C502 C503 C504	1-163-251-11 1-136-495-11	CERAMIC CHIP CERAMIC CHIP FILM	100PF 0.068MF	5% 5% 5%	50V 50V 50V	C578 C579 C580	1-136-111-00 1-107-910-11 1-136-105-00	ELECT	1MF 100MF 0.33MF	5% 20% 5%	200V 50V 200V
C505 C506	1-126-959-11		0.47MF	5% 20%	50V 50V	C581 C582	1-126-963-11 1-102-002-00	CERAMIC	4.7MF 680PF 1.5MF	20% 10% 5%	50V 500V 200V
C507 C508 C509	1-128-526-11 1-130-497-00 1-128-566-11	MYLAR ELECT	100MF 0.15MF 470MF	20% 5% 20% 10%	25V 50V 100V 200V	C583 C584 C585	1-136-541-11 1-107-949-11 1-107-960-11	ELECT	2.2MF 4.7MF	20% 20%	160V 250V
C511 C512 C513	1-107-368-11 1-126-959-11 1-124-261-00	ELECT	0.047MF 0.47MF	20%	50V 50V	C586 C587 C588	1-126-942-61 1-102-030-00 1-107-906-11	CERAMIC	1000MF 330PF 10MF	20% 10% 20%	25V 500V 50V
	∆ 1-129-718-91	FILM CERAMIC CHIP	0.022MF	10% 10% 10%	630V 25V 500V	C589 C590	1-102-030-00 1-107-903-11	CERAMIC	330PF 2.2MF	10% 20%	500V 50V
C517 C518		CERAMIC CHIP		10%	50V 160V	C591 C592 C593	1-107-365-91 1-107-635-11 1-165-319-11		0.015MF 4.7MF 0.1MF	10% 20%	200V 160V 50V
C519 C520 C521	1-163-017-00	CERAMIC CHIP CERAMIC CHIP	0.0047MF	10% 5%	50V 50V 2KV	C594 C595	1-107-889-11		220MF	5% 20%	50V 25V
C522 C523	1-126-768-11 1-107-902-11	ELECT	2200MF 1MF	20% 20%	16V 50V	C596 C597 C598	1-164-346-11	CERAMIC CHIP	1MF	20%	25V 16V 16V
	<u> </u>		0.012MF 0.0115MF	3%	2KV (20M2U/E) 2KV)M4U/E/A)	C599 C1300 C1301	1-124-261-00 1-104-664-11 1-104-664-11	ELECT	10MF 47MF 47MF	20% 20% 20%	50V 25V 25V
C526 C529	∆ 1-162-116-91 1-107-901-11		680PF 0.47MF	10% 20%	2KV 50V	C1302 C1304 C1305		CERAMIC CHIP ELECT		5% 20% 20%	50V 25V 25V
C530 C531 C532	1-104-666-11 1-104-664-11 1-163-031-11		220MF 47MF 0.01MF	20% 20%	25V 25V 50V		1-163-031-11	CERAMIC CHIP CERAMIC CHIP			50V 50V
C533 C534	1-102-212-00 1-107-662-11	CERAMIC	820PF 22MF	10% 20%	500V 250V	C1308 C1309 C1310	1-163-031-11	CERAMIC CHIP CERAMIC CHIP	0.01MF	20% 5%	10V 50V 50V
C537 C538 C539	1-126-971-11 1-137-150-11 1-130-480-00	MYLAR FILM	470MF 0.01MF 0.0056MF		50V 100V 50V	C1311		CERAMIC CHIP		20%	25V 50V
C540 C541	1-107-905-11		470PF 4.7MF 0.0022MF	5% 20%	50V 50V 100V	C1313 C1314 C1315 C1316	1-104-664-11 1-104-664-11		47MF 47MF	20% 20%	50V 25V 25V 50V
C542 C543 C544 C545	1-136-481-11 1-136-481-11 1-137-150-11 1-102-212-00	MYLAR MYLAR	0.0022MF 0.0022MF 0.01MF 820PF		100V 100V 100V 500V	C1317 C1318	1-104-664-11 1-104-664-11	ELECT	47MF 47MF	10% 20%	25V 25V
C546 C547	1-163-119-00	CERAMIC CHIP	120PF	5%	50V 50V	C1319 C1320 C1321		CERAMIC CHIP ELECT		10% 10% 10%	50V 25V 25V
C548 C549 C550	1-102-212-00 1-107-906-11 1-107-905-11	CERAMIC ELECT	820PF 10MF 4.7MF	10% 20% 20%	500V 50V 50V	C1322 C1323		CERAMIC CHIP		10%	16V 50V
C551 C552	1-106-375-12 1-107-889-11	ELECT	0.022MF 220MF	10% 20%	100V 25V	C1324 C1325 C1326		CERAMIC CHIP CERAMIC CHIP ELECT		20%	50V 50V 25V
C553 C554 C555	1-106-389-00 1-130-736-11 1-126-964-11	FILM ELECT	0.082MF 0.01MF 10MF	10% 5% 20%	200V 50V 50V	C1327 C1328	1-163-031-11	CERAMIC CHIP CERAMIC CHIP	0.01MF	10.07	50V 50V
C556 C557	1-126-964-11 1-106-381-12 1-126-960-11	MYLAR	10MF 0.039MF 1MF	20% 10% 20%	50V 100V 50V	C1329 C1330 C1331	1-126-964-11 1-163-031-11 1-104-664-11	CERAMIC CHIP	10MF 0.01MF 47MF	20% 20%	50V 50V 25V
C558 C559 C561 C564	1-126-960-11 1-136-173-00 1-136-159-00 1-126-964-11	FILM FILM	0.47MF 0.033MF 10MF	5% 5% 20%	50V 50V 50V	C1332 C1333 C1334	1-104-664-11 1-104-664-11 1-163-227-11		47MF 47MF 10PF	20% 20% 0.5 P F	25V 25V 5 50V
C565 C566	1-126-960-11 1-137-150-11	ELECT	1MF 0.01MF	20% 10%	50V 50V 100V	C1335 C1336	1-104-664-11 1-104-664-11	ELECT	47MF 47MF	20% 20%	25V 25V
C567 C568 C569	1-136-499-11 1-126-960-11	FILM	0.047MF 1MF 3.3MF	5% 20% 10%	50V 50V 25V	C1338 C1339 C1340	1-163-031-11 1-163-031-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.01MF 0.01MF		50V 50V 50V
C570 C571	1-126-767-11 1-164-232-11	ELECT CERAMIC CHIP	1000MF 0.01MF	20% 10%	16V 50V	C1341 C1342	1-163-105-00	CERAMIC CHIP	33PF	5% 5%	50V 50V
						C1343	1-103-113-00	CERAMIC CHIP	OSPr	5%	50V



REF. NO.	PART NO.	DESCRIPTION		F	REMARK	REF. NO.	PART NO.	DESCRIPTION		REMARK
C1344 C1345	1-124-261-00		10 MF	0.25PF 20%	50V	C1525	1-162-114-00	CERAMIC	0.0047MF	2KV (20M4U/E/A)
C1346 C1347		CERAMIC CHIP		20%	16V 50V	C1530 C1531		CERAMIC CHIP CERAMIC CHIP		50V 10% 25V
C1348 C1349 C1350	1-163-117-00	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	100PF	5% 5% 10%	50V 50V 50V	C1532	1-104-664-11	ELECT	47MF	(20M4U/E/A) 20% 25V (20M4U/E/A)
C1351 C1352	1-126-960-11		1MF	20% 10%	50V 50V	C1534	1-104-664-11		47MF	20% 25V (20M4U/E/A)
C1353 C1354		CERAMIC CHIP CERAMIC CHIP		5%	50V 50V	C1535	1-104-664-11	ELECT	47MF	20% 25V (20M4U/E/A)
C1355 C1356	1-163-259-91 1-163-235-11	CERAMIC CHIP CERAMIC CHIP	220PF 22PF	5% 5%	50V 50V	C1536	1-136-165-00		0.1MF	5% 50V (20M4U/E/A)
C1357	1-104-661-91		330MF	20%	16V	C1537	1-130-783-00		0.33MF	10% 100V (20M4U/E/A)
C1358 C1359 C1360		CERAMIC CHIP CERAMIC CHIP		20% 5%	16V 50V 50V	C1538 C2501 C2502		CERAMIC CHIP CERAMIC CHIP		10% 50V 10% 50V 10% 50V
C1362 C1363	1-163-249-11	CERAMIC CHIP CERAMIC CHIP	82PF	5% 5%	50V 50V	C2502	1-104-232-11	CERAMIC CIII	U.UIIVII	1070 301
C1364	1-163-133-00	CERAMIC CHIP	470PF	5%	50V			<connector></connector>		
C1365 C1366	1-104-664-11		47MF	0.5PF 20%	50V 25V	CN101 CN102	*1-564-514-11	CONNECTOR, B	TOR 11P	BOARD 11P
C1367 C1369	1-104-664-11 1-163-237-11	CERAMIC CHIP	47MF 27PF	20% 5%	25V 50V	CN104 CN105 CN201	*1-565-503-11	PLUG, CONNEC CONNECTOR, B PLUG, CONNEC	OARD TO	BOARD 12P
C1370 C1372	1-104-664-11		47MF	5% 20%	50V 25V	CN301		PLUG, CONNEC		
C1373 C1374	1-104-664-11 1-104-664-11	ELECT	47MF 47MF	20% 20%	25V 25V	CN302 CN303	*1-766-745-11	PLUG, CONNECTOR, B	OARD TO	BOARD 12P
C1375 C1378	1-126-963-11	CERAMIC CHIP	4.7MF	20% 5%	50V 50V	CN305 CN401		PIN, CONNECTO PLUG, CONNEC		
C1380 C1381	1-163-163-00	CERAMIC CHIP CERAMIC CHIP	18PF	5% 5%	50V 50V	CN402 CN501		PLUG, CONNEC		P (20M4U/E/A)
C1382 C1383	1-126-933-11 1-104-664-11		100MF 47MF	20% 20%	10V 25V	CN501 CN502 CN503	*1-573-964-11	CONNECTOR PI PIN, CONNECTO PIN, CONNECTO	OR (PC BO	ARD) 6P
C1384 C1385		CERAMIC CHIP CERAMIC CHIP			25V 50V	CN503		PLUG, CONNEC	·	ARD) OF
C1386 C1387	1-163-031-11	CERAMIC CHIP CERAMIC CHIP	0.01 MF		50V 50V	CN505 CN507	*1-564-506-11	PLUG, CONNECTAB (CONTACT	TOR 3P	
C1388		CERAMIC CHIP		5%	50V	CN508 CN509		PIN, CONNECTO PLUG, CONNEC		
C1393 C1400	1-163-031-11	CERAMIC CHIP	0.01MF	5%	50V 50V 50V			-COMPOSITION	CIDCILIT	DI OCV
C1401 C1402 C1403	1-136-173-00 1-163-031-11 1-136-173-00	CERAMIC CHIP	0.47MF 0.01MF 0.47MF	5% 5%	50V 50V	CP300	1-236-366-11	<composition< p=""> MODULE, TRAP</composition<>		BLOCK>
C1404		CERAMIC CHIP		10%	25V	CP301 CP302		MODULE, TRAP		
C1405 C1406	1-163-090-00	CERAMIC CHIP	7PF	5% 0.25PF		CP303	1-466-162-61	FILTER BLOCK,	COM (CFI	B-4)
C1407 C1408		CERAMIC CHIP CERAMIC CHIP		0.25PF 5%	50V 50V			<diode></diode>		
C1500 C1501	1-126-768-11 1-126-925-11		2200MF 470MF	20% 20%	16V 10V	D100 D101		DIODE MA111 DIODE 1SS226		
C1505 C1506	1-136-165-00 1-104-661-91	ELECT	0.1MF 330MF	5% 20%	50V 16V	D102 D103	8-719-045-70	DIODE 1SS226 DIODE 1SV230T	РН3	
C1507 C1508	1-163-141-00	CERAMIC CHIP	0.001MF 4.7MF	5% 20%	50V 50V	D104 D105		DIODE 1SS226 DIODE 1SS226		
C1509 C1510	1-126-964-11 1-126-963-11	ELECT	10MF 4.7MF	20% 20%	50V 50V	D107 D108	8-719-800-76	DIODE 153226 DIODE 152836		
C1511 C1512		CERAMIC CHIP			50V 50V	D109 D111	8-719-801-78	DIODE 1SS184 DIODE DTZ6.2		
C1513 C1514	1-163-197-00 1-130-477-00	CERAMIC CHIP	470PF 0.0033MF	5% 5%	50V 50V	D114 D115		DIODE MA111 DIODE DTZ6,2		
C1515 C1516	1-126-964-11		10MF	20% 10%	50V 50V	D116 D200	8-719-404-49	DIODE MAIII DIODE DTZ13C		
C1517	1-128-526-11	ELECT	100MF	20%	10V	D300	8-719-025-07	DIODE 1SV232-7	гРН3	
C1518 C1520	1-107-909-11 1-162-129-00	CERAMIC	47MF 150PF	20% 10%	16V 2KV	D301 D303	8-719-977-05	DIODE MA111 DIODE DTZ6.2		
C1521 C1524	1-163-243-11 1-107-910-11	CERAMIC CHIP ELECT	47PF 100MF	5% 20%	50V 50V)M4U/E/A)	D304 D305 D307	8-719-800-76	DIODE 1SS184 DIODE 1SS226 DIODE MA111		
				(20		2307	U 117 TUT 77	ZIODE MAIII		



REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
D308 D309 D310 D311 D313	8-719-404-49 8-719-104-34 8-719-045-70	DIODE MA111 DIODE MA111 DIODE 1S2836 DIODE 1SV230TPH3 DIODE 1SS184		D518 D519 D520 D521 D522	8-719-404-49 8-719-801-78 8-719-404-49	DIODE MA111 DIODE MA111 DIODE 1SS184 DIODE MA111 DIODE DTZ6,2	
D314 D315 D317 D320 D322	8-719-404-49 8-719-404-49 8-719-404-49	DIODE MAIII DIODE MAIII DIODE MAIII DIODE MAIII DIODE MAIII		D524 D525 D526 D527	8-719-920-76 8-719-200-02 8-719-200-02 8-719-404-49	DIODE 1S2076 DIODE 10E-2 DIODE 10E-2 DIODE MA111 DIODE 10E-2	
D323 D324 D325 D326 D327	8-719-045-70 8-719-801-78 8-719-045-70 8-719-104-34	DIODE MA111 DIODE 1SV230TPH3 DIODE 1SS184 DIODE 1SV230TPH3 DIODE 1S2836		D528 D529 D530 D531 D532	8-719-200-02 8-719-300-76 8-719-977-32 8-719-800-76	DIODE RH-1A DIODE 10E-2 DIODE RH-1A DIODE DTZ11B DIODE 1SS226	
D332 D333 D335 D336 D337	8-719-404-49 8-719-404-49 8-719-404-49 8-719-404-49	DIODE MA111 DIODE MA111 DIODE MA111 DIODE MA111 DIODE MA111		D533 D534 D535 D536 D537	8-719-404-49 8-719-404-49 8-719-800-76 8-719-800-76	DIODE EL1Z DIODE MA111 DIODE MA111 DIODE 1SS226 DIODE 1SS226	
D338 D339 D344 D345 D346	8-719-404-49 8-719-801-78 8-719-104-34 8-719-104-34	DIODE MA111 DIODE MA111 DIODE 1SS184 DIODE 1S2836 DIODE 1S2836		D538 D539 D540 D541 D542	8-719-920-76 8-719-404-49 8-719-801-78 8-719-404-49	DIODE 1SS226 DIODE 1S2076 DIODE MA111 DIODE 1SS184 DIODE MA111	
D347 D360 D361 D362 D363	1-216-295-91 1-216-295-91 8-719-158-40	DIODE 1S2836 CONDUCTOR, CHIP CONDUCTOR, CHIP DIODE RD10SB1 DIODE RD10SB1		D543 D544 D545 D546 D547	8-719-404-49 8-719-404-49 8-719-901-19 8-719-404-49	DIODE MA111 DIODE MA111 (20M4U/E/A) DIODE MA111 (20M4U/E/A) DIODE V11N (20M4U/E/A) DIODE MA111	
D364 D365 D381 D401 D404	8-719-404-49 8-719-404-49 8-719-404-49	DIODE 1S2836 DIODE MA111 DIODE MA111 DIODE MA111 DIODE 1SS226		D548 DL300		DIODE RD16ESB3 (20M4U/E/A) <delay line=""> DELAY LINE, Y</delay>	
D405 D406 D407 D408 D410	8-719-404-49 8-719-404-49 8-719-404-49	DIODE 1SS184 DIODE MA111 DIODE MA111 DIODE MA111 DIODE MA111		DL301 DL401	1-415-632-11	DELAY LINE, Y DELAY LINE <ferrite bead=""></ferrite>	
D411 D414 D415 D416 D417	8-719-801-78 8-719-801-78 8-719-801-78	DIODE MA111 DIODE 1SS184 DIODE 1SS184 DIODE 1SS184 DIODE 1SS184	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	FB501	1-410-396-41	FERRITE BEAD INDUCTOR 0.45 <filter></filter>	SUH .
D418 D421 D422 D423	8-719-801-78 8-719-404-49 8-719-404-49 8-719-800-76	DIODE 1SS184 DIODE MA111 DIODE MA111 DIODE 1SS226	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	FL300 FL401	1-236-547-11 1-236-364-11	TRAP, LC FILTER, BAND PASS <ic></ic>	
D424 D425 D427 D500 D501 D502	8-719-800-76 8-719-404-49 8-719-404-49 8-719-977-03	DIODE MA111 DIODE 1SS226 DIODE MA111 DIODE MA111 DIODE DTZ5.6B DIODE UF5406		IC101 IC101 IC102 IC103 IC104	8-759-462-05 8-759-354-28 8-759-008-48	SOCKET, IC (20M2U/E) IC uPD78P018FYCW-M01 (20M4 IC ST24C02FM6TR IC MC74HC86F IC uPD6451AGT-632-E2	U/E/A)
D503 D504 D505 D506 D507	8-719-404-49 8-719-901-83 8-719-028-72 8-719-033-83	DIODE MA111 DIODE 1SS83 DIODE RGP02-17EL-6433 DIODE ERD07-15 DIODE 1SS226		IC105 IC106 IC107 IC108 IC109	8-759-196-70 8-759-196-70 8-759-042-02	IC M62358FP-E1 IC M62358FP-E1 IC M62358FP-E1 IC S-80743AL-A7-S IC M62358FP-E1	
D508 D509 D510 D512 D513	8-719-800-76 8-719-404-49 8-719-302-43 8-719-979-80	DIODE 1SS226 DIODE MA111 DIODE EL1Z DIODE UF5406 DIODE MA111	# # # # # # # # # # # # # # # # # # #	IC110 IC111 IC112 IC200 IC301	8-759-009-22 8-759-354-27 8-759-420-04	IC M62358FP-E1 IC MC14094BF IC ST24C01FM6TR IC AN5265 IC CXA1211M	
D514 D515 D516 D517	8-719-971-20 8-719-404-49	DIODE ERC38-06 DIODE ERC38-06 DIODE MA111 DIODE MA111		IC302 IC303 IC304 IC305 IC306	8-759-932-67 8-759-631-08	IC LM358D IC CXA1214P IC BU4053BCF IC M51279FP IC NJM2245M	



Les composants identifies par une trame et une marque \(\Lambda\) sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The componants identified by shading and mark \triangle are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
IC309 IC310 IC311 IC312 IC313	8-759-932-67 8-759-008-67 8-759-711-32	IC NJM2245M IC BU4053BCF IC MC14066BF IC NJM2245M IC MM1113XFF		L314 L316 L317 L319	1-412-011-31 1-410-090-41 1-408-421-00	INDUCTOR CI INDUCTOR 18 INDUCTOR 10	HIP 27UH BmH BOUH
IC314 IC315 IC316 IC317 IC318	8-759-932-67 8-759-084-76 8-759-009-51	IC MM1113XFF IC BU4053BCF IC MM1111XF IC MC14538BF IC MC14584BF		L320 L401 L402 L403 L404	1-410-478-11 1-410-215-31 1-410-215-31 1-410-215-31	INDUCTOR 47 INDUCTOR CI INDUCTOR CI INDUCTOR CI	'UH HIP 82UH HIP 82UH HIP 82UH
IC320 IC321 IC322 IC323 IC324	8-759-287-89 8-759-287-89 8-759-287-89	IC MM1113XFF IC MM1113XFF IC MM1113XFF IC MM1113XFF IC MM1113XFF		L405 L406 L407 L408 L409	1-408-419-00 1-408-413-00 1-408-413-00 1-410-215-31	INDUCTOR 68 INDUCTOR 68 INDUCTOR 22 INDUCTOR 22 INDUCTOR CI	BUH BUH BUH HIP 82UH
IC325 IC326 IC327 IC350 IC401	8-759-060-00 8-759-008-67 8-759-100-96	IC MM1113XFF IC BA10324AF IC MC14066BF IC uPC4558G2 IC BA7655AF-E2		L500 L501 L502 L503 L504	1-407-365-00 1-407-365-00 1-410-093-11 1-410-666-31	COIL (WITH C COIL,CHOKE COIL,CHOKE INDUCTOR 33 INDUCTOR 18	mH UH
IC402 IC403 IC404 IC405 IC406	8-759-008-67 8-752-067-05 8-759-932-67	IC CXA1211M IC MC14066BF IC CXA1739S IC BU4053BCF IC LM358D		L505 L506 L506 L507 L508	1-459-087-00 1-459-104-00 1-410-686-11 1-412-530-31	COIL, DUST C INDUCTOR 1n INDUCTOR 27	ST CORE 3.9mH (20M4U/E/A) ORE (20M2U/E) nH UH
IC407 IC408 IC409 IC410 IC411	8-759-509-91 8-759-060-00 8-759-009-06	IC MC14066BF IC XRA10393F IC BA10324AF IC MC14052BF IC MC14024BF		L513 L514	1-459-106-00 1-459-232-11 1-412-447-11 1-459-104-00	COIL, DUST COIL, CORE INDUCTOR 3.5	9mH ORE
IC412 IC413 IC500 IC502 IC503	8-759-932-67 8-749-010-08 8-759-009-51	IC BU4053BCF IC BU4053BCF IC H8D7249 IC MC14538BF IC MC14538BF		L515 L517		COIL, DUST COINDUCTOR 68	юшн
IC504 IC505 IC506 IC507 IC508	8-752-053-21 8-759-520-07 8-759-009-51 8-759-100-60	IC CXA1211M IC XXA17812T IC MC14538BF IC uPC1377C IC CXA1211M		NL500 Q101		<pre>LAMP, NEON <transistor pre="" transistor<=""></transistor></pre>	R> DTC144EKA-T146
IC509 IC510 IC511 IC512	8-759-998-98 8-759-009-51 8-759-803-42	IC LM358D IC MC14538BF IC LA6500-FA (20M4U/E/A) IC LM7912CT (20M4U/E/A)		Q102 Q103 Q104 Q105 Q107	8-729-216-22 8-729-216-22 8-729-907-26 8-729-027-38	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	2SA1162-G 2SA1162-G
JR302 JR307	1-216-295-91	<chip conductor=""> CONDUCTOR, CHIP CONDUCTOR, CHIP</chip>		Q108 Q109 Q110 Q111	8-729-422-29 8-729-422-29 8-729-422-29 8-729-027-38	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	2SD601A-S 2SD601A-S 2SD601A-S DTA144EKA-T146
JR310 L101		CONDUCTOR, CHIP COIL> INDUCTOR 33UH		Q112 Q113 Q114 Q200 Q201	8-729-422-29 8-729-422-29 8-729-140-96	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	2SD601A-S 2SD601A-S 2SD774-34
L102 L104 L105 L300	1-408-417-00 1-408-425-00 1-410-482-31 1-410-478-11	INDUCTOR 47UH INDUCTOR 22UUH INDUCTOR 100UH INDUCTOR 47UH		Q300 Q301 Q302 Q303 Q305	8-729-422-29 8-729-216-22 8-729-422-29	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	2SD601A-S 2SA1162-G 2SD601A-S
L301 L302 L303 L304 L305	1-412-008-31 1-408-416-00 1-412-008-31	INDUCTOR 15UH INDUCTOR CHIP 15UH INDUCTOR 39UH INDUCTOR CHIP 15UH INDUCTOR CHIP 2.2UH		Q306 Q307 Q308 Q309 Q310	8-729-422-29 8-729-422-29 8-729-422-37	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	2SD601A-S 2SD601A-S 2SB709A-R
L306 L307 L308 L309 L311	1-408-411-00 1-410-466-41 1-410-470-11	INDUCTOR 39UH INDUCTOR 15UH INDUCTOR 4.7UH INDUCTOR 10UH INDUCTOR 10UH		Q311 Q312 Q313 Q314	8-729-422-37 8-729-422-29 8-729-422-37 8-729-027-38	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	2SB709A-R 2SD601A-S 2SB709A-R DTA144EKA-T146
L312	1-412-011-31	INDUCTOR CHIP 27UH		Q315 Q316		TRANSISTOR TRANSISTOR	



1976 1979-1979 TANNISTOR 258010A-S 1979-1979-1979 1979-1979 1979-1979-1979 1979-1979-1979 1979-197	REF. NO.	PART NO.	DESCRIPTION	REMARK ;	REF. NO.	PART NO.	DESCRIPTION	REMARK
Gip 8-779-4-42-9 TRANSISTOR SEDIOLAS CARD 8-779-42-9 TRANSISTOR SEDIOLAS CARD CAR	O318	8-729-422-37	TRANSISTOR 2SB709A-R			8-729-422-37	TRANSISTOR 2SB709A-R	
ĞQZI 8-729-422-9 TRANSISTOR 25060IA-S Q42 8-729-120-28 TRANSISTOR 25060IA-S Ö123 8-729-022-9 TRANSISTOR 25060IA-S Q42 8-729-027-9 TRANSISTOR 25060IA-S Ö124 8-729-027-9 TRANSISTOR DICI-44EKA-T-146 Q42 8-729-027-9 TRANSISTOR DICI-44EKA-T-146 Ö125 8-729-422-9 TRANSISTOR 25060IA-S Q42 8-729-027-9 TRANSISTOR DICI-44EKA-T-146 Ö126 8-729-422-9 TRANSISTOR 25060IA-S Q43 8-729-027-9 TRANSISTOR DICI-44EKA-T-146 Ö127 8-729-422-9 TRANSISTOR 25060IA-S Q42 8-729-027-9 TRANSISTOR DICI-44EKA-T-146 Ö128 8-729-422-3 TRANSISTOR 25060IA-S Q43 8-729-027-9 TRANSISTOR 25060IA-S Ö139 8-729-02-17 TRANSISTOR 25060IA-S Q41 8-729-027-9 TRANSISTOR DICI-44EKA-T-146 Ö130 8-729-02-17 TRANSISTOR 25060IA-S Q43 8-729-027-9 TRANSISTOR 25060IA-S Ö130 8-729-02-17 TRANSISTOR 25060IA-S Q44 8-729-027-9 TRANSISTOR 25060IA-S Ö130 8-729-02-18 TRANSISTOR 25060IA-S Q43 8-729-027-9 TRANSISTOR 25060IA-S Ö130 8-729-02-18 TRANSISTOR 25060IA-S Q44 8-729-027-9 TRANSISTOR 25060IA-S Ö130 8-729-02-18 TR	Q319			į				
0.222 8-779-422-27 TRANSITOR 25E06/IAS Col.					Q422	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
0.000	Q322	8-729-422-29	TRANSISTOR 2SD601A-S		Q423	8-729-422-29	TRANSISTOR 25D00TA-5	
0025 8-729-422-9 TRANSISTOR 25D00IA-S Q46 8-729-422-9 TRANSISTOR 25D00IA-S 026 8-729-422-9 TRANSISTOR 25D00IA-S Q49 8-729-422-9 TRANSISTOR 25B709A-R 027 8-729-422-9 TRANSISTOR 25B709A-R Q49 8-729-422-9 TRANSISTOR 25B709A-R 028 8-729-141-53 TRANSISTOR 25B709A-R Q49 8-729-422-9 TRANSISTOR 25B709A-R 029 8-729-122-9 TRANSISTOR 25B709A-R Q49 8-729-422-9 TRANSISTOR 25B709A-R 031 8-729-422-9 TRANSISTOR 25B709A-R Q43 8-729-422-9 TRANSISTOR 25B00IA-S 032 8-729-422-9 TRANSISTOR 25B00IA-S Q43 8-729-422-9 TRANSISTOR 25B00IA-S 033 8-729-422-9 TRANSISTOR 25B00IA-S Q43 8-729-022-9 TRANSISTOR 25B00IA-S 033 8-729-422-9 TRANSISTOR 25B00IA-S Q43 8-729-022-9 TRANSISTOR 25B00IA-S 033 8-729-422-9 TRANSISTOR 25B00IA-S Q43 8-729-022-9 TRANSISTOR 25B00IA-S 034 8-729-422-9 TRANSISTOR 25B00IA-S Q44 8-729-022-9 TRANSISTOR 25B00IA-S 034 8-729-422-9 TRANSISTOR 25B00IA-S Q44 8-729-022-9 TRANSISTOR 25B00IA-S 034 8-729-422-9 TRANSISTOR 25B00IA-S Q44 <	Q323							
Color	Q325	8-729-422-29	TRANSISTOR 2SD601A-S	1	Q426	8-729-027-59	TRANSISTOR DTC144EKA-T146	
0.228	Q326	8-729-422-29	TRANSISTOR 2SD601A-S	8 8 8 8				
\$\frac{9}{0390}					_	9.720.422.20	TD ANGIGT OF TOTAL OT	
Q331 8-729-422-75 TRANSISTOR DTC14EKA-T146 Q332 8-729-422-97 TRANSISTOR DTC14EKA-T146 Q333 8-729-422-97 TRANSISTOR DTC14EKA-T146 Q334 8-729-422-9 TRANSISTOR SED0IA-S Q45 Q335 8-729-422-9 TRANSISTOR SED0IA-S Q46 Q336 8-729-422-9 TRANSISTOR SED0IA-S Q47 Q337 8-729-422-9 TRANSISTOR SED0IA-S Q47 Q338 8-729-422-9 TRANSISTOR SED0IA-S Q48 Q338 8-729-422-9 TRANSISTOR SED0IA-S Q49 Q341 8-729-422-9 TRANSISTOR SED0IA-S Q40 Q342 8-729-422-9 TRANSISTOR SED0IA-S Q44 Q343 8-729-422-9 TRANSISTOR MITUS Q42 Q444 8-729-422-9 TRANSISTOR SED0IA-S Q44 Q445 8-729-422-9 TRANSISTOR SED0IA-S Q44 Q446 8-729-422-9 TRANSISTOR SED0IA-S Q44 Q448 8-729-422-9 TRANSISTOR SED0IA-S Q44 Q449 8-729-422-9 TRANSISTOR SED0IA-S Q44 Q449 8-729-422-9 TRANSISTOR SED0IA-S Q44 Q45 8-729-422-9 TRANSISTOR SED0IA-S Q44	Q329	8-729-141-53	TRANSISTOR 2SK94-X2X3X4		Q431	8-729-422-29	TRANSISTOR 2SD601A-S	
132								
\$\(\frac{0}{233} \) 8-729-422-29 TRANSISTOR 2SD60IA-S \$\(\frac{0}{235} \) 8-729-422-39 TRANSISTOR 2SB709A-R \$\(\frac{0}{235} \) 8-729-422-39 TRANSISTOR 2SB709A-R \$\(\frac{0}{235} \) 8-729-422-39 TRANSISTOR 2SD60IA-S \$\(\frac{0}{235} \) 8-729-422-39 TRANSISTOR 2SD60I	-							
0335 8-729-422-29 TRANSISTOR SIDSOBA-X4 Q438 8-729-422-29 TRANSISTOR DTC144EKA-T146 0336 8-729-10-94 TRANSISTOR SIDSOBA-S Q439 8-729-422-29 TRANSISTOR SIDSOBA-S Q439 8-729-422-29 TRANSISTOR SIDSOBA-S Q449 8-729-422-29 TRANSISTOR SIDSOBA-S Q441 8-729-422-29 TRANSISTOR SIDSOBA-S Q441 8-729-422-29 TRANSISTOR SIDSOBA-S Q441 8-729-422-29 TRANSISTOR SIDSOBA-S Q441 8-729-422-29 TRANSISTOR SIDSOBA-S Q443 8-729-422-29 TRANSISTOR SIDSOBA-S Q443 8-729-422-29 TRANSISTOR SIDSOBA-S Q446 8-729-422-29 TRANSISTOR SIDSOBA-S Q446 8-729-422-37 TRANSISTOR SIDSOBA-S Q446 8-729-422-39 TRANSISTOR SIDSOBA-S Q446 8-729-422-39 TRANSISTOR SIDSOBA-S Q446 8-729-422-39 TRANSISTOR SIDSOBA-S Q446 8-729-422-39 TRANSISTOR SIDSOBA-S Q448 8-729-422-39 TRANSISTOR SIDSOBA-S Q449 8-729-422-39 TRANSISTOR SIDSOBA-S Q449 8-729-422-39 TRANSISTOR SIDSOBA-S Q449 8-729-422-39 TRANSISTOR SIDSOBA-S Q449 <		8-729-422-29	TRANSISTOR 2SD601A-S					
Q336 8-729-109-44 TRANSISTOR SSP601A-S Q439 8-729-422-29 TRANSISTOR SSP601A-S Q439 8-729-422-22 TRANSISTOR SSP601A-S Q440 8-729-422-29 TRANSISTOR SSP601A-S Q441 8-729-422-37 TRANSISTOR SSP601A-S Q442 8-729-422-39 TRANSISTOR SSP601A-S Q442 8-729-422-39 TRANSISTOR SSP601A-S Q442 8-729-422-39 TRANSISTOR SSP601A-S Q442 8-729-422-29 TRANSISTOR SSP601A-S Q442 8-729-422-29 TRANSISTOR SSP601A-S Q444 8-729-422-37 TRANSISTOR SSP601A-S Q446 8-729-422-37 TRANSISTOR SSP601A-S Q448 8-729-422-39 TRANSISTOR SSP601A-S Q448 8-729-422-37 TRANSISTOR SSP601A-S Q500 8-729-422-37								
G338 8-729-422-29 TRANSISTOR 25D601A-S					Q438	8-729-422-29	TRANSISTOR 2SD601A-S	
G338 8-729-120-22 TRANSISTOR 2SC1623-L5.16 Q440 8-729-42-23 TRANSISTOR 2SD01A-S Q441 8-729-42-23 TRANSISTOR 2SD01A-S Q442 8-729-42-23 TRANSISTOR 2SD01A-S Q442 8-729-42-23 TRANSISTOR 2SD01A-S Q443 8-729-42-23 TRANSISTOR 2SD01A-S Q444 8-729-42-23 TRANSISTOR 2SD01A-S Q445 8-729-42-23 TRANSISTOR 2SD01A-S Q446 8-729-42-23 TRANSISTOR 2SD01A-S Q447 8-729-027-59 TRANSISTOR DTC144EKA-T146 Q478 8-729-42-23 TRANSISTOR 2SD01A-S Q488 8-729-42-23 TRANSISTOR 2SD01A-S Q489 8-729-42-23 TRANSISTOR 2SD01A-S Q502 8-729-42-23 TRANSISTOR 2SD01A-S Q503 8-729-42-22 TRANSISTOR 2SD01A-S Q504 8-729-42-23 TRANSISTOR 2SD01A-S Q504 8-729-42-23 TRANSISTOR 2SD01A-S Q505 8-729-42-23 TRANSISTOR 2SD01A-S Q505 8-729-42-23 TRANSISTOR 2SD01A-S Q506 8-729-42-23 TRANSISTOR 2SD01A-S Q507 8-729-42-23 TRANSISTOR 2SD01A-S Q508 8-7	O337	8-729-422-29	TRANSISTOR 2SD601A-S		Q439	8-729-216-22	TRANSISTOR 2SAT162-G	
Ğ341 8-729-920-39 TRANSISTOR IMTIUS Q44 8-729-422-29 TRANSISTOR 2SATI62-G Q44 8-729-920-39 TRANSISTOR IMTIUS Q44 8-729-221-62: TRANSISTOR 2SATI62-G Q44 8-729-920-39 TRANSISTOR SSD01A-S Q44 8-729-221-62: TRANSISTOR 2SATI62-G Q345 8-729-422-9 TRANSISTOR DATE (ALL) Q44 8-729-072-99 TRANSISTOR DTC144EKA-T146 Q347 8-729-072-97 TRANSISTOR DTC144EKA-T146 Q44 8-729-072-99 TRANSISTOR DTC144EKA-T146 Q348 8-729-022-97 TRANSISTOR SSD09A-R Q44 8-729-027-99 TRANSISTOR DTC144EKA-T146 Q349 8-729-022-97 TRANSISTOR SSD09A-R Q44 8-729-027-99 TRANSISTOR DTC144EKA-T146 Q349 8-729-422-97 TRANSISTOR SSD09A-R Q44 8-729-027-99 TRANSISTOR DTC144EKA-T146 Q350 8-729-422-9 TRANSISTOR SSD01A-S Q502 8-729-422-9 TRANSISTOR SSD01A-S Q353 8-729-422-9 TRANSISTOR SSD01A-S Q503 8-729-422-9 TRANSISTOR SSD01A-S Q354 8-729-422-9 TRANSISTOR SSD01A-S Q506 8-729-422-9 TRANSISTOR SSD01A-S Q355 8-729-422-9 TRANSISTOR SSD01A-S Q507 8-729-422-9 TRANSISTOR SSD01A-S Q356 8-729-422-9 TRANSISTOR SS	Q338							
G444 8-729-422-9 TRANSISTOR 25D601A-S G445 8-729-027-9 TRANSISTOR 25D601A-S G446 8-729-027-9 TRANSISTOR DTC144EKA-T146 G477 8-729-027-9 TRANSISTOR DTC144EKA-T146 G478 8-729-027-9 TRANSISTOR DTC144EKA-T146 G479 8-729-027-9 TRANSISTOR DTC144EKA-T146 G479	Q341	8-729-920-39	TRANSISTOR IMT1US		Q442	8-729-422-29	TRANSISTOR 2SD601A-S	
Gy45	Q342	8-729-920-39	TRANSISTOR IMT1US					
Ö346 8-729-422-29 TRANSISTOR 25D60IA-S Q446 8-729-027-59 TRANSISTOR DTC144EKA-T146 Q348 8-729-422-37 TRANSISTOR DTC144EKA-T146 Q448 8-729-027-59 TRANSISTOR DTC144EKA-T146 Q349 8-729-422-37 TRANSISTOR 25B709A-R Q448 8-729-027-59 TRANSISTOR DTC144EKA-T146 Q350 8-729-422-37 TRANSISTOR 25B709A-R Q500 8-729-422-37 TRANSISTOR 25B709A-R Q351 8-729-422-29 TRANSISTOR 25D60IA-S Q501 8-729-422-37 TRANSISTOR 25B709A-R Q354 8-729-422-29 TRANSISTOR 25D60IA-S Q506 8-729-422-29 TRANSISTOR 25D60IA-S Q355 8-729-422-29 TRANSISTOR 25D60IA-S Q506 8-729-422-29 TRANSISTOR 25D60IA-S Q355 8-729-422-29 TRANSISTOR 25D60IA-S Q506 8-729-422-29 TRANSISTOR 25D60IA-S Q357 8-729-422-37 TRANSISTOR 25D60IA-S Q509 8-729-422-37 TRANSISTOR 25D60IA-S Q358 8-729-422-37 TRANSISTOR 25D60IA-S Q509 8-729-422-37 TRANSISTOR 25D60IA-S Q350						9-720-027-50	TRANSISTOR DTC144EVA.T146	
Gardard Sample Control Contr	Q346	8-729-422-29	TRANSISTOR 2SD601A-S		O446	8-729-027-59	TRANSISTOR DTC144EKA-T146	
(349 8-729-422-37 TRANSISTOR 2SB709A-R (350 8-729-422-37 TRANSISTOR 2SB709A-R (351 8-729-422-37 TRANSISTOR 2SB709A-R (351 8-729-422-37 TRANSISTOR 2SD001A-S (352 8-729-422-37 TRANSISTOR 2SD001A-S (352 8-729-422-37 TRANSISTOR 2SD001A-S (353 8-729-422-37 TRANSISTOR 2SD001A-S (353 8-729-422-37 TRANSISTOR 2D001A-S (354 8-729-422-37 TRANSIS								
(351) 8-729-422-37 TRANSISTOR 2SB709A-R (351) 8-729-422-37 TRANSISTOR 2SD601A-S (352) 8-729-422-29 TRANSISTOR 2SD601A-S (353) 8-729-422-29 TRANSISTOR 2SD601A-S (353) 8-729-422-29 TRANSISTOR 2SD601A-S (355) 8-729-422-29 TRANSISTOR 2SD601A-S (356) 8-729-422-29 TRANSISTOR 2SD601A-S (356) 8-729-422-29 TRANSISTOR 2SD601A-S (357) 8-729-422-29 TRANSISTOR 2SD601A-S (356) 8-729-422-29 TRANSISTOR 2SD601A-S (357) 8-729-422-29 TRANSISTOR 2SD601A-S (357) 8-729-422-29 TRANSISTOR 2SD601A-S (358) 8-729-422-29 TRANSISTOR 2SD601A-S (358) 8-729-422-29 TRANSISTOR 2SD601A-S (358) 8-729-422-29 TRANSISTOR 2SD601A-S (358) 8-729-422-29 TRANSISTOR 2SD601A-S (351) 8-729-422-37 TRANSISTOR 2SD601A-S (351) 8-729-422-37 TRANSISTOR 2SD601A-S (351) 8-729-422-39 TRANSISTOR 2SD601A-S (352) 8-729-422-39 TRANSISTOR 2SD601A-S (353)	•	8-720-422-37	TPANSISTOP 2SR709A-R	į	Q449	8-729-027-59	TRANSISTOR DTC144EKA-T146	
\$\(\frac{0}{352} \) 8-729-422-29 TRANSISTOR 2SD60IA-S \\ \$\(\frac{0}{353} \) 8-729-422-29 TRANSISTOR 2SD60IA-S \\ \$\(\frac{0}{355} \) 8-729-422-29 TRANSISTOR 2SD60IA-S \\ \$\(\frac{0}{356} \) 8-729-422-29 TRANSISTOR 2SD60IA-S \\ \$\(\frac{0}{356} \) 8-729-422-29 TRANSISTOR 2SD60IA-S \\ \$\(\frac{0}{357} \) 8-729-422-29 TRANSISTOR 2SD60IA-S \\ \$\(\frac{0}{358} \) 8-729-422-29 TRANSISTOR 2SD60IA-S \\ \$\(\frac{0}{358} \) 8-729-422-29 TRANSISTOR 2SD60IA-S \\ \$\(\frac{0}{359} \) 8-729-422-37 TRANSISTOR 2SD60IA-S \\ \$\(\frac{0}{359} \) 8-729-422-37 TRANSISTOR 2SD60IA-S \\ \$\(\frac{0}{359} \) 8-729-422-39 TRANSISTOR 2SD60IA-S \\ \$\(\frac{0}{359	Q350	8-729-422-37	TRANSISTOR 2SB709A-R		Q500			
Q353 8-729-422-29 TRANSISTOR 2SD601A-S Q506 8-729-422-29 TRANSISTOR 2SD601A-S Q506 8-729-422-29 TRANSISTOR 2SD601A-S Q506 8-729-422-29 TRANSISTOR 2SD601A-S Q507 8-729-422-29 TRANSISTOR 2SD601A-S Q508 8-729-422-29 TRANSISTOR 2SD601A-S Q508 8-729-422-29 TRANSISTOR 2SD601A-S Q508 8-729-422-39 TRANSISTOR 2SD601A-S Q508 8-729-422-39 TRANSISTOR 2SD601A-S Q508 8-729-422-39 TRANSISTOR 2SD601A-S Q508 8-729-422-39 TRANSISTOR 2SD601A-S Q510 8-729-422-39 TRANSISTOR DTG144EKA-T146 Q514 8-729-422-39 TRANSISTOR 2SD601A-S Q510 8-729-422-39 TRANSISTOR DTG144EKA-T146 Q512 8-729-422-39 TRANSISTOR 2SD601A-S Q510 8-729-422-39 TRANSISTOR 2SD601A-S Q520 8-729-								
0354 8-729-422-29 TRANSISTOR 2SD601A-S 0355 8-729-422-37 TRANSISTOR 2SD601A-S 0356 8-729-027-59 TRANSISTOR 2SD601A-S 0357 8-729-422-29 TRANSISTOR 2SD601A-S 0358 8-729-422-29 TRANSISTOR 2SD601A-S 0358 8-729-422-29 TRANSISTOR 2SD601A-S 0359 8-729-422-37 TRANSISTOR 2SD601A-S 0360 8-729-422-37 TRANSISTOR 2SD601A-S 0361 8-729-422-37 TRANSISTOR 2SD601A-S 0362 8-729-027-38 TRANSISTOR 2SD601A-S 0363 8-729-422-39 TRANSISTOR 2SD601A-S 0364 8-729-027-39 TRANSISTOR 2SD601A-S 0365 8-729-027-39 TRANSISTOR 2SD601A-S 0366 8-729-422-39 TRANSISTOR 2SD601A-S 0367 8-729-027-39 TRANSISTOR 2SD601A-S 0368 8-729-422-37 TRANSISTOR 2SD601A-S 0369 8-729-422-39 0360 8-729-422-39 TRANSISTOR 2SD601A-S 0360 8-729-422-39 TRANSISTOR 2SD601A-S 0360 8-729-422-37 TRANSISTOR 2SD601A-S 0360 8-729-422-37 TRANSISTOR 2SD601A-S 0360 8-729-422-37 TRANSISTOR 2SD601A-S 0360 8-729-422-37 TRANSISTOR 2SD601A-S 0360 8-729-422-39 TRANSISTOR 2SD601A-S 0360 8-729-422-39 TRANSISTOR 2SD601A-S 0360 8-729-422-37 TRANSISTOR 2SD601A-S					Q505	8-729-422-29	TRANSISTOR 2SD601A-S	
\$\begin{align*} \begin{align*} \be								
Q510 8-729-027-29 TRANSISTOR 25B709A-R Q510 8-729-027-39 TRANSISTOR 25B709A-R Q520 8-729-027-39					O508			
S-729-422-37 TRANSISTOR 2SB709A-R Q513 S-729-422-29 TRANSISTOR 2SB709A-R Q514 S-729-422-29 TRANSISTOR DTD 144EKA-T146 Q513 S-729-422-29 TRANSISTOR DTD 144EKA-T146 Q514 S-729-422-29 TRANSISTOR DTD 144EKA-T146 Q515 S-729-422-29 TRANSISTOR DTD 144EKA-T146 Q516 S-729-422-29 TRANSISTOR DTD 144EKA-T146 Q516 S-729-422-37 TRANSISTOR DTD 144EKA-T146 Q516 S-729-422-37 TRANSISTOR DDA-R Q519 S-729-027-59 TRANSISTOR DTD 144EKA-T146 Q516 S-729-422-37 TRANSISTOR DDA-R Q520 S-729-027-59 TRANSISTOR DTD 144EKA-T146 Q522 S-729-027-59 TRANSISTOR DTD 144EKA-T146 Q523 S-729-027-59 TRANSISTOR DTD 144EKA-T146 Q524 S-729-020-07 TRANSISTOR DTD 144EKA-T146 Q525 S-729-020-07 TRANSISTOR DTD 144EKA					Q509 Q510			
0360 8-729-907-26 TRANSISTOR IMX1 Q513 8-729-122-03 TRANSISTOR SSA1220A-P	•							
\(\begin{array}{c} \) \(\partial_{366} \) \(\partial_{8-729-422-29} \) \(\partial_{8-729-422-29} \) \(\partial_{8-729-422-37} \) \(\partia						8-729-122-03	TRANSISTOR 2SA1220A-P	
Q363 8-729-422-29 TRANSISTOR 2SD601A-S Q516 8-729-027-59 TRANSISTOR DTC144EKA-T146 Q517 8-729-027-38 TRANSISTOR DTC144EKA-T146 Q518 8-729-027-59 TRANSISTOR 2SB709A-R Q519 8-729-027-59 TRANSISTOR DTC144EKA-T146 Q520 8-729-027-59 TRANSISTOR 2SB709A-R Q520 8-729-027-59 TRANSISTOR 2SB709A-R Q520 8-729-027-59 TRANSISTOR 2SD601A-S Q520 8-729-020-07 TRANSISTOR 2SD601A-S Q520					Q514 Q515			
Q364 8-729-027-59 TRANSISTOR DTC144EKA-T146 Q366 8-729-422-37 TRANSISTOR 2SB709A-R Q519 8-729-027-59 TRANSISTOR 2SB709A-R Q519 8-729-027-59 TRANSISTOR 2SD396K Q520 8-729-027-59 TRANSISTOR 2SD396K Q520 8-729-027-59 TRANSISTOR 2SD396K Q520 8-729-027-59 TRANSISTOR DTC144EKA-T146 Q522 8-729-422-29 TRANSISTOR 2SD396K Q523 8-729-027-59 TRANSISTOR DTC144EKA-T146 Q524 8-729-422-29 TRANSISTOR 2SD601A-S Q525 8-729-422-29 TRANSISTOR 2SD601A-S Q526 8-729-422-29 TRANSISTOR 2SD601A-S Q526 8-729-422-37 TRANSISTOR 2SD601A-S Q526 8-729-020-07 TRANSISTOR 2SD601A-S Q526 8-729-020-07 TRANSISTOR 2SD601A-S Q526 8-729-020-07 TRANSISTOR 2SC4686A(LBSONY) Q404 8-729-422-37 TRANSISTOR 2SB709A-R Q527 8-729-020-07 TRANSISTOR 2SC4686A(LBSONY) Q406 8-729-422-29 TRANSISTOR 2SB709A-R Q528 8-729-027-59 TRANSISTOR 2SD601A-S Q529 8-729-020-07 TRANSISTOR 2SC4686A(LBSONY) Q406 8-729-422-29 TRANSISTOR 2SD601A-S Q529 8-729-020-07 TRANSISTOR 2SC4686A(LBSONY) Q406 8-729-422-29 TRANSISTOR 2SD601A-S Q529 8-729-027-59 TRANSISTOR 2SC4686A(LBSONY) Q528 8-729-027-59 TRANSISTOR 2SC4686A(LBSONY) Q529 R529-027-59 TRANSISTOR 2SC4686A(LBSONY) Q52					Q516	8-729-027-59	TRANSISTOR DTC144EKA-T146	
0367 8-729-422-37 TRANSISTOR 2SB709A-R Q519 8-729-027-59 TRANSISTOR 2SB709A-R Q520 8-729-021-82 TRANSISTOR 2SD2396K Q522 8-729-021-82 TRANSISTOR 2SD601A-S Q522 8-729-021-82 TRANSISTOR 2SD601A-S Q523 8-729-021-82 TRANSISTOR 2SD601A-S Q523 8-729-021-82 TRANSISTOR 2SD601A-S Q524 8-729-022-99 TRANSISTOR 2SD601A-S Q524 8-729-022-99 TRANSISTOR 2SD601A-S Q525 8-729-022-97 TRANSISTOR 2SD601A-S Q526 8-729-020-07 TRANSISTOR 2SD601A-S Q526 8-729-020-07 TRANSISTOR 2SD601A-S Q526 8-729-020-07 TRANSISTOR 2SC4686A(LBSONY) Q527 8-729-020-07 TRANSISTOR 2SC4686A(LBSONY) Q528 8-729-020-07 TRANSISTOR 2SC4686A(LBSONY) Q528 8-729-020-07 TRANSISTOR 2SC4686A(LBSONY) Q528 8-729-020-07 TRANSISTOR 2SC4686A(LBSONY) Q529 8-729-020-07 TRANSISTOR 2SC4686A(LBSONY) Q529 8-729-020-07 TRANSISTOR 2SC4686A(LBSONY) Q528 8-729-020-07 TRANSISTOR 2SC4686A(LBSONY) Q529 8-729-020-07 TRANSISTOR 2SC4686A(LBSONY) Q529 8-729-020-07 TRANSISTOR 2SC4686A					-			
0368 0369 8-729-422-37 8-729-027-38 8-729-027-38 TRANSISTOR 2SB709A-R Q522 0520 8-729-022-29 RANSISTOR 2SD601A-S Q523 RANSISTOR 2SD601A-S Q523 0520 8-729-422-29 RANSISTOR 2SD601A-S Q523 0522 8-729-422-29 RANSISTOR 2SD601A-S Q524 0522 8-729-422-29 RANSISTOR 2SD601A-S Q525 0522 8-729-422-29 RANSISTOR 2SD601A-S Q526 0522 8-729-422-29 RANSISTOR 2SD601A-S Q526 0522 8-729-422-29 RANSISTOR 2SD601A-S Q526 0526 8-729-422-29 RANSISTOR 2SC4686A(LESONY) Q526 0526 8-729-020-07 RANSISTOR 2SC4686A(LESONY) Q527 0526 8-729-020-07 RANSISTOR 2SC4686A(LESONY) Q528 0529 8-729-020-07 RANSISTOR 2SC4686A(LESONY) Q528 0529 8-729-020-07 RANSISTOR 2SC4686A(LESONY) Q528 0529 8-729-020-07 RANSISTOR 2SC4686A(LESONY) Q528 0529 8-729-020-07 RANSISTOR 2SC4686A(LESONY) PARSISTOR 2SC4686A(LESONY) Q529 8-729-02					Q518 Q519			
Q523 8-729-422-9 TRANSISTOR 2SD601A-S Q373 8-729-027-59 TRANSISTOR DTC144EKA-T146 Q373 8-729-027-59 TRANSISTOR DTC144EKA-T146 Q401 8-729-422-29 TRANSISTOR 2SD601A-S Q402 8-729-422-29 TRANSISTOR 2SD601A-S Q403 8-729-027-59 TRANSISTOR 2SD601A-S Q404 8-729-422-37 TRANSISTOR DTC144EKA-T146 Q526 8-729-020-07 TRANSISTOR 2SB709A-R Q407 8-729-422-37 TRANSISTOR 2SB709A-R Q408 8-729-422-39 TRANSISTOR 2SB709A-R Q409 8-729-422-37 TRANSISTOR 2SB709A-R Q409 8-729-422-37 TRANSISTOR 2SB709A-R Q410 8-729-422-37 TRANSISTOR 2SB709A-R Q411 8-729-422-37 TRANSISTOR 2SB709A-R Q412 8-729-141-53 TRANSISTOR 2SB709A-R Q413 8-729-141-53 TRANSISTOR 2SB709A-R Q414 8-729-422-37 TRANSISTOR 2SB709A-R Q415 8-729-422-37 TRANSISTOR 2SB709A-R Q416 8-729-422-37 TRANSISTOR 2SB709A-R Q417 8-729-422-37 TRANSISTOR 2SB709A-R Q418 8-729-422-37 TRANSISTOR 2SB709A-R Q419 8-729-422-37 TRANSISTOR 2SB709A-R Q410 8-729-422-37 TRANSISTOR 2SB709A-R Q411 8-729-422-37 TRANSISTOR 2SB709A-R Q412 8-729-422-37 TRANSISTOR 2SB709A-R Q413 8-729-422-37 TRANSISTOR 2SB709A-R Q414 8-729-422-37 TRANSISTOR 2SB709A-R Q415 8-729-422-37 TRANSISTOR 2SB709A-R Q416 8-729-422-37 TRANSISTOR 2SB709A-R Q417 8-729-422-37 TRANSISTOR 2SB709A-R Q418 8-729-422-37 TRANSISTOR 2SB709A-R Q419 8-729-422-37 TRANSISTOR 2SB709A-R Q410 8-729-422-37 TRANSISTOR 2SB709A-R Q411 8-729-422-37 TRANSISTOR 2SB709A-R Q412 8-729-422-37 TRANSISTOR 2SB709A-R Q414 8-729-422-37 TRANSISTOR 2SB709A-R Q415 8-729-422-37 TRANSISTOR 2SB709A-R Q416 8-729-422-37 TRANSISTOR 2SB709A-R Q417 8-729-422-37 TRANSISTOR 2SB709A-R R101 1-216-025-91 METAL GLAZE 100 % 1/10W Q417 8-729-422-37 TRANSISTOR 2SB709A-R R102 1-216-073-00 METAL GLAZE 100 % 1/10W Q417 8-729-422-37 TRANSISTOR 2SB709A-R R104 1-216-073-00 METAL GLAZE 10K % 1/10W	O368	8-729-422-37	TRANSISTOR 2SB709A-R		O520	8-729-021-82	TRANSISTOR 2SD2396K	
Q373 8-729-027-59 TRANSISTOR DTC144EKA-T146 Q524 8-729-422-29 TRANSISTOR 2SD601A-S Q525 8-729-422-37 TRANSISTOR 2SD601A-S Q526 8-729-020-07 TRANSISTOR 2SD601A-S Q526 8-729-020-07 TRANSISTOR 2SD601A-S Q526 8-729-020-07 TRANSISTOR 2SC4686A(LBSONY) Q403 8-729-422-37 TRANSISTOR 2SB709A-R Q404 8-729-422-37 TRANSISTOR 2SB709A-R Q405 8-729-422-29 TRANSISTOR 2SB709A-R Q406 8-729-422-29 TRANSISTOR 2SD601A-S Q407 8-729-422-37 TRANSISTOR 2SD601A-S Q528 8-729-020-07 TRANSISTOR 2SA1407-D Q408 8-729-422-37 TRANSISTOR 2SD601A-S Q528 8-729-020-759 TRANSISTOR 2SA1407-D Q408 8-729-422-37 TRANSISTOR 2SB709A-R Q530 8-729-027-59 TRANSISTOR DTC144EKA-71-46 Q531 8-729-027-59 TRANSIST								
Q401 8-729-422-29 TRANSISTOR 2SD601A-S Q525 8-729-422-37 TRANSISTOR 2SD601A-S Q526 8-729-020-07 TRANSISTOR 2SD60A-R (20M4U/E/A) (20M4U/E/A	Q372 Q373				0524	8-729-422-29	TRANSISTOR 2SD601A-S	
Q403 8-729-027-59 TRANSISTOR DTC144EKA-T146 Q527 8-729-020-07 TRANSISTOR 2SC4686A(LBSONY) Q404 8-729-422-37 TRANSISTOR 2SB709A-R Q528 8-729-020-07 TRANSISTOR 2SC4686A(LBSONY) Q405 8-729-422-29 TRANSISTOR 2SD601A-S Q528 8-729-802-71 TRANSISTOR 2SA1407-D Q406 8-729-422-29 TRANSISTOR 2SD601A-S Q529 8-729-027-59 TRANSISTOR DTC144EKA-T146 Q530 8-729-027-59 TRANSISTOR DTC144EKA-T146 Q530 8-729-027-59 TRANSISTOR DTC144EKA-T146 Q531 8-7	Q401	8-729-422-29	TRANSISTOR 2SD601A-S		Q525	8-729-422-37	TRANSISTOR 2SB709A-R	10
Q404 8-729-422-37 TRANSISTOR 2SB709A-R Q405 8-729-422-37 TRANSISTOR 2SB709A-R Q406 8-729-422-29 TRANSISTOR 2SD601A-S Q407 8-729-422-29 TRANSISTOR 2SD601A-S Q408 8-729-422-37 TRANSISTOR 2SB709A-R Q409 8-729-422-37 TRANSISTOR 2SB709A-R Q410 8-729-907-26 TRANSISTOR 2SB709A-R Q411 8-729-422-29 TRANSISTOR 2SD601A-S Q412 8-729-141-53 TRANSISTOR 2SD601A-S Q413 8-729-141-53 TRANSISTOR 2SM1162-G Q414 8-729-422-37 TRANSISTOR 2SB709A-R Q415 8-729-422-37 TRANSISTOR 2SB709A-R Q416 8-729-422-37 TRANSISTOR 2SB709A-R Q417 8-729-422-37 TRANSISTOR 2SB709A-R Q418 8-729-422-37 TRANSISTOR 2SB709A-R Q419 8-729-422-37 TRANSISTOR 2SB709A-R Q410 8-729-422-37 TRANSISTOR 2SB709A-R Q411 8-729-422-37 TRANSISTOR 2SB709A-R Q412 8-729-422-37 TRANSISTOR 2SB709A-R Q413 8-729-422-37 TRANSISTOR 2SB709A-R Q414 8-729-422-37 TRANSISTOR 2SB709A-R Q415 8-729-422-37 TRANSISTOR 2SB709A-R Q416 8-729-422-37 TRANSISTOR 2SB709A-R Q417 8-729-422-37 TRANSISTOR 2SB709A-R Q418 8-729-422-37 TRANSISTOR 2SB709A-R Q419 8-729-422-37 TRANSISTOR 2SB709A-R Q410 8-729-422-37 TRANSISTOR 2SB709A-R Q411 8-729-422-37 TRANSISTOR 2SB709A-R Q412 8-729-422-37 TRANSISTOR 2SB709A-R Q414 8-729-422-37 TRANSISTOR 2SB709A-R Q415 8-729-422-37 TRANSISTOR 2SB709A-R Q416 8-729-422-37 TRANSISTOR 2SB709A-R Q417 8-729-422-37 TRANSISTOR 2SB709A-R Q418 8-729-422-37 TRANSISTOR 2SB709A-R Q419 8-729-422-37 TRANSISTOR 2SB709A-R Q410 R-729-422-37					_		• (20M4U/E/A)
Q405 8-729-422-37 TRANSISTOR 2SB709A-R Q406 8-729-422-29 TRANSISTOR 2SD601A-S Q407 8-729-422-37 TRANSISTOR 2SD601A-S Q408 8-729-422-37 TRANSISTOR 2SB709A-R Q409 8-729-422-37 TRANSISTOR 2SB709A-R Q410 8-729-92-29 TRANSISTOR 2SB709A-R Q411 8-729-422-29 TRANSISTOR 2SD601A-S Q412 8-729-141-53 TRANSISTOR 2SM1162-G Q413 8-729-141-53 TRANSISTOR 2SM1162-G Q414 8-729-422-37 TRANSISTOR 2SM162-G Q415 8-729-422-37 TRANSISTOR 2SB709A-R Q416 8-729-422-37 TRANSISTOR 2SB709A-R Q417 8-729-422-37 TRANSISTOR 2SB709A-R Q418 8-729-422-37 TRANSISTOR 2SB709A-R Q419 8-729-422-37 TRANSISTOR 2SB709A-R Q410 8-729-422-37 TRANSISTOR 2SB709A-R Q411 8-729-422-37 TRANSISTOR 2SB709A-R Q412 8-729-422-37 TRANSISTOR 2SB709A-R Q413 8-729-422-37 TRANSISTOR 2SB709A-R Q414 8-729-422-37 TRANSISTOR 2SB709A-R Q415 8-729-422-37 TRANSISTOR 2SB709A-R Q416 8-729-422-37 TRANSISTOR 2SB709A-R Q417 8-729-422-37 TRANSISTOR 2SB709A-R Q418 8-729-422-37 TRANSISTOR 2SB709A-R Q419 8-729-422-37 TRANSISTOR 2SB709A-R Q410 8-729-422-37 TRANSISTOR 2SB709A-R Q411 8-729-422-37 TRANSISTOR 2SB709A-R Q412 8-729-422-37 TRANSISTOR 2SB709A-R Q414 8-729-422-37 TRANSISTOR 2SB709A-R Q415 8-729-422-37 TRANSISTOR 2SB709A-R Q416 8-729-422-37 TRANSISTOR 2SB709A-R Q417 8-729-422-37 TRANSISTOR 2SB709A-R Q418 8-729-422-37 TRANSISTOR 2SB709A-R Q419 8-729-422-37 TRANSISTOR 2SB709A-R Q410 R-729-422-37 TR	0404	8-729-422-37	TRANSISTOR 2SB709A-R	İ	Q527	8-729-020-07		
Q407 8-729-422-29 TRANSISTOR 2SD601A-S Q529 8-729-027-59 TRANSISTOR DTC144EKA-[146] Q408 8-729-422-37 TRANSISTOR 2SB709A-R Q530 8-729-027-59 TRANSISTOR DTC144EKA-[146] Q409 8-729-422-37 TRANSISTOR 2SB709A-R Q531 8-729-216-22 TRANSISTOR IMX1 Q410 8-729-907-26 TRANSISTOR 2SD601A-S Q532 8-729-927-31 TRANSISTOR IMX1 Q411 8-729-422-29 TRANSISTOR 2SD601A-S Q2501 8-729-422-29 TRANSISTOR 2SD601A-S Q412 8-729-141-53 TRANSISTOR 2SB709A-R R101 1-216-025-91 METAL GLAZE 100 % 1/10W Q414 8-729-422-37 TRANSISTOR 2SB709A-R R102 1-216-025-91 METAL GLAZE 100 % 1/10W Q416 8-729-422-37 TRANSISTOR 2SB709A-R R103 1-216-025-91 METAL GLAZE 100 % 1/10W Q417 8-729-422-37 TRANSISTOR 2SB709A-R R104 1-216-025-91 METAL GLAZE 10K % 1/10W	Q405	8-729-422-37	TRANSISTOR 2SB709A-R		Q528	8-729-802-71		,
Q409 8-729-422-37 TRANSISTOR 2SB709A-R Q410 8-729-422-37 TRANSISTOR 2SB709A-R Q411 8-729-422-29 TRANSISTOR 2SD601A-S Q412 8-729-216-22 TRANSISTOR 2SD601A-S Q413 8-729-141-53 TRANSISTOR 2SH162-G Q413 8-729-422-37 TRANSISTOR 2SB709A-R Q414 8-729-422-37 TRANSISTOR 2SB709A-R Q415 8-729-422-37 TRANSISTOR 2SB709A-R Q416 8-729-422-37 TRANSISTOR 2SB709A-R Q417 8-729-422-37 TRANSISTOR 2SB709A-R Q418 8-729-422-37 TRANSISTOR 2SB709A-R Q419 8-729-422-37 TRANSISTOR 2SB709A-R Q410 8-729-422-37 TRANSISTOR 2SB709A-R Q411 8-729-422-37 TRANSISTOR 2SB709A-R Q412 8-729-422-37 TRANSISTOR 2SB709A-R Q413 8-729-422-37 TRANSISTOR 2SB709A-R Q414 8-729-422-37 TRANSISTOR 2SB709A-R Q415 8-729-422-37 TRANSISTOR 2SB709A-R Q416 8-729-422-37 TRANSISTOR 2SB709A-R Q417 8-729-422-37 TRANSISTOR 2SB709A-R Q418 8-729-422-37 TRANSISTOR 2SB709A-R Q419 R-729-422-37 TRANSISTOR 2SB709A-R Q410 Q531 8-729-216-22 TRANSISTOR 2SD601A-S Q2501 8-729-422-29 TRANSISTOR 2SD601A-S Q2501 8-729-422-29 TRANSISTOR 2SD601A-S Q2501 R-729-422-29 TRANSI	Q407	8-729-422-29	TRANSISTOR 2SD601A-S	1				
Q409 8-729-422-37 TRANSISTOR 2SB709A-R Q410 8-729-907-26 TRANSISTOR IMX1 Q411 8-729-422-29 TRANSISTOR 2SD601A-S Q412 8-729-216-22 TRANSISTOR 2SA1162-G Q413 8-729-141-53 TRANSISTOR 2SK94-X2X3X4 Q414 8-729-422-37 TRANSISTOR 2SB709A-R Q415 8-729-422-37 TRANSISTOR 2SB709A-R Q416 8-729-422-37 TRANSISTOR 2SB709A-R Q417 8-729-422-37 TRANSISTOR 2SB709A-R Q417 8-729-422-37 TRANSISTOR 2SB709A-R Q418 8-729-422-37 TRANSISTOR 2SB709A-R Q419 8-729-422-37 TRANSISTOR 2SB709A-R Q410 8-729-422-37 TRANSISTOR 2SB709A-R Q411 R101 1-216-025-91 METAL GLAZE 100 % 1/10W Q412 8-729-422-37 TRANSISTOR 2SB709A-R Q413 8-729-422-37 TRANSISTOR 2SB709A-R Q414 8-729-422-37 TRANSISTOR 2SB709A-R Q415 8-729-422-37 TRANSISTOR 2SB709A-R Q416 8-729-422-37 TRANSISTOR 2SB709A-R Q417 8-729-422-37 TRANSISTOR 2SB709A-R Q418 R101 1-216-025-91 METAL GLAZE 100 % 1/10W Q419 R103 1-216-025-91 METAL GLAZE 100 % 1/10W Q419 R104 1-216-073-00 METAL GLAZE 10K % 1/10W	3			***************************************	Q531			J/E/A)
Q411 8-729-422-29 TRANSISTOR 2SD601A-S Q412 8-729-216-22 TRANSISTOR 2SA1162-G Q413 8-729-141-53 TRANSISTOR 2SK94-X2X3X4 Q414 8-729-422-37 TRANSISTOR 2SB709A-R R101 1-216-025-91 METAL GLAZE 100 % 1/10W Q416 8-729-422-37 TRANSISTOR 2SB709A-R R102 1-216-025-91 METAL GLAZE 100 % 1/10W Q417 8-729-422-37 TRANSISTOR 2SB709A-R R103 1-216-025-91 METAL GLAZE 100 % 1/10W Q417 8-729-422-37 TRANSISTOR 2SB709A-R R104 1-216-073-00 METAL GLAZE 10K % 1/10W	Q409 Q410				Q532			A)
Q413 8-729-141-53 TRANSISTOR 2SK94-X2X3X4 CRESISTOR> Q414 8-729-422-37 TRANSISTOR 2SB709A-R R101 1-216-025-91 METAL GLAZE 100 % 1/10W Q415 8-729-422-37 TRANSISTOR 2SB709A-R R102 1-216-025-91 METAL GLAZE 100 % 1/10W Q416 8-729-422-37 TRANSISTOR 2SB709A-R R103 1-216-025-91 METAL GLAZE 100 % 1/10W Q417 8-729-422-37 TRANSISTOR 2SB709A-R R104 1-216-073-00 METAL GLAZE 10K % 1/10W	Q411	8-729-422-29	TRANSISTOR 2SD601A-S					
Q415 8-729-422-37 TRANSISTOR 2SB709A-R R102 1-216-025-91 METAL GLAZE 100 % 1/10W Q416 8-729-422-37 TRANSISTOR 2SB709A-R R103 1-216-025-91 METAL GLAZE 100 % 1/10W Q417 8-729-422-37 TRANSISTOR 2SB709A-R R104 1-216-073-00 METAL GLAZE 10K % 1/10W							<resistor></resistor>	
Q416 8-729-422-37 TRANSISTOR 2SB709A-R R103 1-216-025-91 METAL GLAZE 100				4 0 0				1/10 W
Q417 8-729-422-37 TRANSISTOR 2SB709A-R R104 1-216-073-00 METAL GLAZE 10K % 1/10W								
Q+10 0-723-120-20 1KANSISTON 23C1023-L3L0 [KIU3 1-210-U39-UU METAL GLAZE 2./K % 1/10W	Q417	8-729-422-37	TRANSISTOR 2SB709A-R	9	R104	1-216-073-00	METAL GLAZE 10K 5%	1/10W
	Q+10	0-123-120-28	I MAINDIO I ON ADCIUAD-LDLO	•	KIUJ	1-210-039-00	WEIAL GLAZE 2./K %	1/10W



REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION		R	EMARK
R106		METAL GLAZE		% ov.	1/10W	R313	1-216-648-11	METAL CHIP	750	0.50%	1/10W
R107 R108		METAL GLAZE		% %	1/10W 1/10W	R314	1-216-099-00	METAL GLAZE	120K	5%	1/10W
R109		METAL GLAZE		%	1/10W	R315	1-216-099-00	METAL GLAZE	120K	5%	1/10W
R110	1-216-073-00	METAL GLAZE	10K 5	%	1/10W	R316		METAL GLAZE		5%	1/10W
R113	1-216-085-00	METAL GLAZE	33K 5	%	1/10W	R317 R318		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R117		METAL GLAZE		%	1/10W	RSTO	1 210 047 71	ETTE GETEE	***		
R119		METAL GLAZE		%	1/10W	R319		METAL GLAZE		5%	1/10W
R124 R130		CONDUCTOR, CI METAL GLAZE		%	1/10W	R320 R321		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
K130	1-210-055-00	METAL OLALL	12012 3	~	1/1011	R322		METAL GLAZE		5%	1/10W
R132		METAL GLAZE		% ~	1/10W	R323	1-216-109-00	METAL GLAZE	330K	5%	1/10W
R133 R134		METAL GLAZE		% %	1/10W 1/10W	R324	1-216-101-00	METAL GLAZE	150K	5%	1/10W
R135		METAL GLAZE		%	1/10W	R325		METAL GLAZE		5%	1/10W
R137	1-216-065-00	METAL GLAZE	4.7K 5	%	1/10W	R326		METAL GLAZE		5%	1/10W
R140	1-216-033-00	METAL GLAZE	220 5	%	1/10W	R328 R329		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R141		METAL GLAZE		%	1/10W	14323	1 210 033 00	DITE ODI ED	1.016		
R144		CONDUCTOR, CI		or	1/1007	R330		METAL GLAZE		5%	1/10W
R149 R151		METAL GLAZE		% %	1/10W 1/10W	R331 R332		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
KIJI	1-210-001-00	METAL OBJELL	J.J.K J	,,	1,1011	R333		METAL GLAZE		5%	1/10W
R154		METAL GLAZE		%	1/10W	R334	1-216-093-00	METAL GLAZE	68K	5%	1/10W
R155 R157		METAL GLAZE		% %	1/10W 1/10W	R335	1-216-083-00	METAL GLAZE	27K	5%	1/10W
R158		CONDUCTOR, C			272017	R336	1-216-065-00	METAL GLAZE	4.7K	5%	1/10W
R159	1-216-063-91	METAL GLAZE	3.9K 5	%	1/10W	R337		METAL GLAZE		5%	1/10W 1/10W
R160	1-216-061-00	METAL GLAZE	3 3K 5	%	1/10W	R338 R339		METAL GLAZE METAL GLAZE		5% 5%	1/10W
R162		METAL GLAZE		%	1/10W	Ross	1 210 071 00		O.D.E.	570	
R163		METAL GLAZE		%	1/10W	R340		METAL GLAZE		5%	1/10W
R164 R165		METAL GLAZE CONDUCTOR, C		%	1/10W	R341 R342		METAL CHIP METAL GLAZE	8.2K 4.7K	0.50% 5%	1/10W 1/10W
11105	1 210-275-71	CONDUCTOR, C.				R343		METAL GLAZE		5%	1/10W
R167		METAL GLAZE		% ar	1/10W	R344	1-216-099-00	METAL GLAZE	120K	5%	1/10W
R168 R169		METAL GLAZE METAL GLAZE		% %	1/10W 1/10W	R345	1-216-063-91	METAL GLAZE	3.9K	5%	1/10W
R171		METAL GLAZE		%	1/10W	R346	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W
R172	1-216-295-91	CONDUCTOR, C	HIP			R347		METAL GLAZE		5%	1/10W 1/10W
R177	1-216-214-00	METAL GLAZE	4.7K 5	%	1/8W	R348 R349		METAL GLAZE METAL CHIP	62K	5% 0.50%	1/10W
R181	1-216-065-00	METAL GLAZE	4.7K 5	%	1/10W						
R184 R185				.50% %	1/10W 1/10W	R350 R351		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R187		METAL GLAZE METAL GLAZE		%	1/10W	R352		METAL CHIP	10K	0.50%	1/10W
D.100				~	4 44 0331	R353		METAL GLAZE		5%	1/10W
R189 R190		METAL GLAZE METAL GLAZE		% %	1/10W 1/10W	R354	1-216-119-00	METAL GLAZE	820K	5%	1/10W
R192		METAL GLAZE		%	1/10W	R355	1-216-059-00	METAL GLAZE	2.7K	5%	1/10W
R195		METAL GLAZE		%	1/10W	R356		METAL GLAZE		5%	1/10W
R197	1-216-061-00	METAL GLAZE	3.3K 5	%	1/10W	R357 R358		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R199	1-216-295-91	CONDUCTOR, C	HIP			R359		METAL GLAZE		5%	1/10W
R200				.50%	1/10W		1 01/ 000 00	METAL OLAGE	200	e 01	1/1037
R201 R202	1-216-049-91	METAL GLAZE		% %	1/10W 1/4W F	R360 R361		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R203	1-260-095-11			%	1/2W	R362	1-216-067-00	METAL GLAZE	5.6K	5%	1/10W
R204	1 360 070 11	CARRON	4.7 5	OL.	1 /2337	R363 R364		METAL GLAZE		5%	1/10W 1/10W
R204 R205	1-260-072-11			% .50%	1/2W 1/10W	K304	1-210-113-00	METAL GLAZE	4/UK	5%	1/10W
R206		METAL GLAZE		%	1/10W	R366		METAL GLAZE		5%	1/10W
R207		METAL GLAZE		% «	1/10W	R367		METAL GLAZE		5%	1/10W 1/10W
R208	1-210-003-00	METAL GLAZE	4./K 3	%	1/10W	R368 R371		METAL GLAZE METAL GLAZE		5% 5%	1/10W
R209		METAL GLAZE		%	1/10W	R372		METAL GLAZE		5%	1/10W
R210 R211		METAL GLAZE		% oz	1/10W 1/4W F	R373	1-216-645 11	METAL CHIP	560	0.50%	1/10W
R237	1-249-393-11 1-216-089-91	METAL GLAZE		% %	1/4W F 1/10W	R374		METAL CHIP	680	0.50%	1/10W
R301		METAL GLAZE		%	1/10W	R375	1-216-053-00	METAL GLAZE	1.5K	5%	1/10W
R302	1.716 025 01	METAL GLAZE	100 5	%	1/10W	R376 R378		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R303		METAL GLAZE		70 %	1/10W	W210	1-210-114-00	WILL I AL ULAGE	2101	3 70	
R304	1-216-025-91	METAL GLAZE	100 5	%	1/10W	R379		METAL GLAZE		5%	1/10W
R305 R306		CONDUCTOR, C				R380 R381		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
	410-273-71	COMPOCION, C				R382		METAL GLAZE		5%	1/10W
R307		METAL GLAZE		%	1/10W	R383	1-216-061-00	METAL GLAZE	3.3K	5%	1/10W
R308 R311		METAL GLAZE METAL GLAZE		% %	1/10W 1/10W	R384	1-216-073-00	METAL GLAZE	10K	5%	1/10W
R312		METAL GLAZE		%	1/10W	R385		METAL GLAZE		5%	1/10W



REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION		1	REMARK
R386		METAL GLAZE		5%	1/10W	R460	1-216-295-91	CONDUCTOR, O	CHIP		
R387 R388		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R462	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
7400		A COURT OF THE COU	000	0.500	1/1/011/	R463		METAL GLAZE		5%	1/10W
R389 R390	1-216-649-11	METAL CHIP	820 10	0.50% 5%	1/10W 1/4W F	R464 R465		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R391		METAL GLAZE		5%	1/10W	R466		METAL GLAZE		5%	1/10W
R393	1-216-073-00	METAL GLAZE	10K	5%	1/10W	D.465			43.6		4 /4 0337
R394	1-216-083-00	METAL GLAZE	27K	5%	1/10W	R467 R468		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R395	1-216-651-11	METAL CHIP	1 K	0.50%	1/10W	R469		METAL GLAZE		5%	1/10W
R396	1-216-113-00	METAL GLAZE		5%	1/10W	R470	1-216-069-00	METAL GLAZE	6.8K	5%	1/10W
R397		METAL GLAZE		5%	1/10W	R471	1-216-109-00	METAL GLAZE	330K	5%	1/10W
R398 R399		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R472	1-216-077-00	METAL GLAZE	15K	5%	1/10W
ALD 7 7	1 210 111 > 1		0,011			R473		METAL GLAZE		5%	1/10W
R400		METAL GLAZE		5%	1/10W	R474		METAL CHIP	820	0.50%	1/10W
R401 R402		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R475 R476		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R403		METAL GLAZE		5%	1/10W	26470	1-210-001-00	METAL CLALL	J.J.L.	370	1/10 11
R404	1-216-029-00	METAL GLAZE	150	5%	1/10W	R477		METAL GLAZE		5%	1/10W
R405	1.216.121.01	METAL GLAZE	1M	5%	1/10W	R478 R479		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R406		METAL GLAZE		5%	1/10W	R480		METAL GLAZE		5%	1/10W
R407	1-216-085-00	METAL GLAZE	33K	5%	1/10W	R481		METAL GLAZE		5%	1/10W
R408		METAL CHIP	39K	0.50% 5%	1/10W 1/10W	R482	1.216.057.00	METAL GLAZE	2.21/	5%	1/10W
R410	1-210-009-00	METAL GLAZE	U.OK	370	1/10W	R483		METAL GLAZE		5%	1/10W
R411		METAL GLAZE		5%	1/10W	R484		METAL CHIP	1K	0.50%	1/10W
R412 R413		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R485 R486		METAL GLAZE METAL CHIP	220 18K	5% 0, 50 %	1/10W 1/10W
R414		METAL GLAZE		5%	1/10W	K400	1-210-001-11	METAL CHIP	101	0.30%	1/10 **
			***********		0M4U/E/A)	R487		METAL CHIP	1.2K	0.50%	1/10W
R414	1-216-295-91	CONDUCTOR, C	:HIP (20M2	2U/E)		R488 R489		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R416	1-216-113-00	METAL GLAZE	470K	5%	1/10W	R490		METAL GLAZE		5%	1/10W
R417		METAL CHIP	3.9K	0.50%	1/10W	R491	1-216-063-91	METAL GLAZE	3.9K	5%	1/10 W
R418 R420		METAL CHIP METAL GLAZE	4.7K 220K	0.50% 5%	1/10W 1/10W	R492	1-216-085-00	METAL GLAZE	33K	5%	1/10 W
11420	1-210-105-71	METTE OF ISE			0M4U/E/A)			CONDUCTOR, O		5,0	1/10 11
R422	1-216-073-00	METAL GLAZE	10K	5%	1/10W	R494		METAL CHIP	75K	0.50%	1/10W
R423	1-216-073-00	METAL GLAZE	10K	5%	1/10W	R495 R496		METAL CHIP METAL GLAZE	1K 10K	0,5 0% 5%	1/10W 1/10W
R424		METAL GLAZE		5%	1/10W				-0	0,0	
R425		METAL GLAZE		5%	1/10W	R497		METAL CHIP	1.2K	0.50%	1/10W
R426 R427		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R498 R499		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
						R500	1-216-689-11	METAL GLAZE	39K	5%	1/10W
R428		METAL GLAZE		5% 5%	1/10W 1/10W	R501	1-216-077-00	METAL GLAZE	15K	5%	1/10W
R429 R430		METAL GLAZE METAL GLAZE		5%	1/10W 1/10W	R502	1-216-677-11	METAL CHIP	12K	0.50%	1/10 W
R431	1-216-097-91	METAL GLAZE	100K	5%	1/10W	R503	1-216-677-11	METAL CHIP	12K	0.50%	1/10W
R432	1-216-089-91	METAL GLAZE	47K	5%	1/10W	R504 R505	1-216-111-91	METAL GLAZE METAL GLAZE	390K	5%	1/10W
R434	1-216-109-00	METAL GLAZE	330K	5%	1/10W	R506		METAL GLAZE		5% 5%	1/10 W 1/10 W
R435	1-216-105-91	METAL GLAZE	220K	5%	1/10W						
R436 R437		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R507 R508		METAL GLAZE METAL GLAZE		5%	1/10 W 1/10 W
R438		METAL GLAZE		5%	1/10W	R509		METAL GLAZE		5% 5%	1/10W
						R510	1-216-097-91	METAL GLAZE	100K	5%	1/10W
R439 R440		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R511	1-216-099-00	METAL GLAZE	120K	5%	1/10 W
R441		METAL CHIP	560	0.50%	1/10W	R512	1-216-055-00	METAL GLAZE	1.8K	5%	1/10 W
R442		METAL CHIP	680	0.50%	1/10W	R513		CONDUCTOR, C			
R443	1-216-049-91	METAL GLAZE	IK	5%	1/10W	R514 R515		CONDUCTOR, C METAL CHIP	HIP 10K	050%	1/10 W
R444	1-216-105-91	METAL GLAZE	220K	5%	1/10W	R516		METAL GLAZE		5%	1/10W
R445	1-216-095-00	METAL GLAZE	82K	5%	1/10W						
R447 R448		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R517 R518	1-214-896-81 1-260-123-11		20K 100K	1%	1/2W
R449		METAL GLAZE		5%	1/10W	R519		METAL GLAZE		5% 5%	1/2W 1/10W
					į	R520	1-249-423-11	CARBON	3.3K	5%	1/4W F
R450 R451		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R521	1-216-065-00	METAL GLAZE	4.7K	5%	1/10W
R452		METAL CHIP		0.50%	1/10W	R523	1-215-892-11	METAL OXIDE	1K	5%	2W F
R453		METAL GLAZE		5%	1/10W	R524	1-216-093-00	METAL GLAZE	68K	5%	1/10 W
R455	1-216-085-00	METAL GLAZE	53K	5%	1/10W	R525 R526		METAL GLAZE METAL GLAZE		5% 5%	1/10 W 1/10 W
R456	1-216-053-00	METAL GLAZE	1.5K	5%	1/10W	R527		METAL GLAZE		5%	1/10W 1/10W
R457		METAL GLAZE		5%	1/10W						
R458 R459		METAL GLAZE METAL CHIP	470K 820	5% 0.50%	1/10W 1/10W	R528 R529		METAL GLAZE METAL GLAZE		5% 5%	1/10 W 1/10 W
	2 2 2 0 7 11			2.3070			5 005-51			- 0	./10**



REF. NO.	PART NO.	DESCRIPTION		Į	REMARK	REF. NO.	PART NO.	DESCRIPTION		F	REMARK
R530		METAL OXIDE		5% 5%	2W F 1/10W	R592 R593	1-247-688-11	CARBON METAL CHIP	10 680	5% 0.50%	1/4W F 1/10W
R531 R532		METAL GLAZE METAL OXIDE		5%	3W F	R594	1-260-104-91		2.7K	5%	1/2W
R533	1-247-723-71	CARBON METAL GLAZE	6.8K	5% 5%	1/4W F 1/10W	R595 R596		METAL GLAZE		5% 1%	1/10W 1/4W
R534 R535	1-249-448-11	CARBON	1.2	5%	1/4W F	R597	1-249-417-11	CARBON	1K	5%	1/4W F
R536 R537		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R598		METAL GLAZE		5%	1/10W
R539		METAL GLAZE		5%	1/10W	R599 R1103	1-216-077-00	METAL CHIP METAL GLAZE		0.50% 5%	1/10W 1/10W
R540 R541	1-216-113-00 1-249-383-11	METAL GLAZE	470K 1.5	5% 5%	1/10W 1/4W F	R1104 R1105		METAL CHIP METAL GLAZE	100K 10K	0.50% 5%	1/10W 1/10W
R542 R543		METAL GLAZE		5% 5%	1/10W 1/4W F	R1106		METAL GLAZE		5%	1/10W
					1/10W	R1107 R1108		METAL GLAZE METAL CHIP	2.7K 18K	5% 0.50%	1/10W 1/10W
R544 R545	1-216-073-00	METAL GLAZE METAL GLAZE	10K	5% 5%	1/10W	R1111	1-216-065-00	METAL GLAZE	4.7K	5%	1/10W
R546 R547	1-249-425-11 1-216-091-00	CARBON METAL GLAZE	4.7K 56K	5% 5%	1/4W F 1/10W	R1112 R1113		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R548		METAL GLAZE		5%	1/10W	R1114	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R549		METAL CHIP	12K	0.50%	1/10W 1/10W	R1115 R1116	1-216-049-91	METAL GLAZE METAL CHIP		5% 0.50%	1/10W 1/10W
R550 R551		METAL GLAZE METAL GLAZE		5% 5%	1/10W	R1117	1-216-069-00	METAL GLAZE	6.8K	5%	1/10W
R552 R553		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R1118	1-216-113-00	METAL GLAZE	470K	5%	1/10W
R554		METAL GLAZE		5%	1/10W	R1119 R1120		METAL CHIP METAL GLAZE	62K 47K	0.50% 5%	1/10W 1/10W
R555	1-216-692-11	METAL CHIP	51K	0.50%	1/10W	R1123	1-216-071-00	METAL GLAZE	8.2K	5%	1/10W
R556 R558		METAL OXIDE METAL OXIDE		5% 5%	2W F 1W F	R1124 R1125		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R559	1-216-109-00	METAL GLAZE	330K	5%	1/10W	R1126	1-216-041-00	METAL GLAZE	470	5%	1/10W
R560		METAL GLAZE		5% 5%	1/10W 1/10W	R1128 R1129	1-216-065-00	METAL GLAZE METAL GLAZE	4.7K	5% 5%	1/10W 1/10W
R561 R562	1-247-692-71	METAL GLAZE CARBON	22	5%	1/4W F	R1130	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R562	1-247-696-11	CARBON	47	5%	(20M2U/E) 1/4W F	R1131		METAL GLAZE		5%	1/10W
R563	1-216-017-91	METAL GLAZE	47	5% (2)	0M4U/E/A) 1/10W	R1132 R1133		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R564		METAL GLAZE		5%	1/10W	R1134 R1136		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R565 R566	1-216-033-00	METAL GLAZE		5% 0.50%	1/10W 1/10W	R1137		METAL GLAZE		5%	1/10W
		METAL CHIP			(20M2U/E)	R1138		METAL GLAZE		5%	1/10W
R566		METAL CHIP	47K		1/10W 0M4U/E/A)		1-216-653-11	METAL GLAZE METAL CHIP	1.2K	5% 0.50%	1/10W 1/10W
R567	1-216-081-00	METAL GLAZE	22K	5%	1/10W	R1141 R1142		METAL GLAZE METAL CHIP	10K 1.2K	5% 0.50%	1/10W 1/10W
R568 R569	1-216-073-00 1-260-119-11	METAL GLAZE	10K 47K	5% 5%	1/10W 1/2W	R1143	1-216-653-11	METAL CHIP	1.2K	0.50%	1/10W
R571	1-216-065-00	METAL GLAZE	4.7K	5%	1/10W	R1144	1-216-073-00	METAL GLAZE	10K	5%	1/10W
R572 R573		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R1145 R1146	1-216-057-00	METAL GLAZE METAL GLAZE	2.2K	5% 5%	1/10W 1/10W
R574	1-216-089-91	METAL GLAZE	47K	5%	1/10 W	R1147		METAL GLAZE		5%	1/10W
R575	1-249-383-11		1.5	5% (2	0M4U/E/A) 1/4W F	R1150 R1151		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R576	1-216-101-00	METAL GLAZE	150K	5%	1/10W	R1155	1-216-133-00	METAL GLAZE	3.3M	5%	1/10W
R577		METAL GLAZE	10K	5% (2	1/10W 0M4U/E/A)	R1161 R1162		METAL CHIP METAL CHIP	1 M 470K	0.50% 0.50%	1/10W 1/10W
R578	1-216-693-11	METAL CHIP	56K	0.50%	1/10W	R1163	1-216-033-00	METAL GLAZE	220	5%	1/10W
R580 R581		METAL GLAZE		5% 5%	1/10W 1/10W	R1164 R1165	1-216-049-91	METAL GLAZE METAL GLAZE	1K	5% 5%	1/10W 1/10W
		METAL GLAZE		(2	0M4U/E/A)	R1167	1-216-097-91	METAL GLAZE	100K	5%	1/10W 1/10W
R582 R583		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R1168		METAL GLAZE		5%	
R584	1-216-063-91	METAL GLAZE	3.9K	5% (2	1/10W 0 M4U/E /A)	R1169 R1170		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R584	1_716 072 00	METAL GLAZE	10K	5%	1/10W	R1171 R1172	1-216-085-00	METAL GLAZE METAL GLAZE	33K	5% 5%	1/10W 1/10W
					(20M2U/E)			CONDUCTOR, C		570	
R585 R586		METAL GLAZE METAL CHIP	220 30K	5% 0.50%	1/10W 1/10W	R1174		METAL GLAZE		5%	1/10W
R587 R588	1-216-675-11	METAL CHIP METAL GLAZE	10K 15K	0.50% 5%	1/10W 1/10W	R1177 R1179		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
					1/10W	R1180	1-216-089-91	METAL GLAZE	47K	5% 5%	1/10W 1/10W
R589 R590	1-216-081-00	METAL GLAZE METAL GLAZE	22K	5% 5%	1/10W	R1182		METAL GLAZE			
R591	1-216-683-11	METAL CHIP	22K	0.50%	1/10W	R1183 R1184		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W



REF. NO.	PART NO.	DESCRIPTION		REMARK	REF. NO.	PART NO.	DESCRIPTION		j	REMARK
R1185 R1186 R1187	1-216-131-11	METAL GLAZE 8.2K METAL GLAZE 2.7M METAL GLAZE 8.2K	5% 5% 5%	1/10W 1/10W 1/10W	R1357 R1358 R1359 R1360	1-216-071-00 1-216-099-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	8.2K 120K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W
R1188 R1189		METAL GLAZE 2.7M METAL GLAZE 8.2K	5% 5%	1/10W 1/10W	R1361		METAL GLAZE		5%	1/10W
R1190 R1191		METAL GLAZE 2.7M METAL GLAZE 8.2K	5% 5%	1/10W 1/10W	R1362 R1363		METAL CHIP METAL GLAZE	11K 470K	0.50% 5%	1/10W 1/10W
R1192		METAL GLAZE 2.7M	5%	1/10W	R1364	1-216-073-00	METAL GLAZE	10K	5%	1/10W
R1193		METAL GLAZE 100	5%	1/10W	R1365 R1366		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R1194 R1195		METAL GLAZE 33K METAL GLAZE 100	5% 5%	1/10W 1/10W	R1367	1-216-660-11	METAL CHIP	2.4K	0.50%	1/10W
R1196 R1197		METAL GLAZE 33K METAL GLAZE 100	5% 5%	1/10W 1/10W	R1368 R1369		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R1198		METAL GLAZE 33K	5%	1/10W	R1370 R1371	1-216-105-91	METAL GLAZE METAL GLAZE	220K	5% 5%	1/10W 1/10W
R1301	1-216-029-00	METAL GLAZE 150	5%	1/10W						
R1302 R1303		METAL GLAZE 150 METAL GLAZE 390	5% 5%	1/10W 1/10W	R1372 R1373		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R1304	1-216-689-11	METAL GLAZE 39K	5%	1/10W	R1374 R1375		METAL GLAZE METAL CHIP	150K 560	5% 0.50%	1/10W 1/10W
R1305		METAL GLAZE 220	5%	1/10W	R1376		METAL CHIP	680	0.50%	1/10W
R1306 R1307		METAL CHIP 560 METAL GLAZE 56K	0.50% 5%	1/10W 1/10W	R1377		METAL GLAZE		5%	1/10W
R1308 R1309		METAL CHIP 560 METAL GLAZE 100	0.50% 5%	1/10W 1/10W	R1378 R1379		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R1311		METAL GLAZE 47K	5%	1/10W	R1380 R1381	1-216-645-11	METAL CHIP	560	0.50%	1/10W
R1312	1-216-027-00	METAL GLAZE 120	5%	1/10W			METAL CHIP	680	0.50%	1/10W
R1313 R1314		METAL GLAZE 100K METAL GLAZE 22K	5% 5%	1/10W 1/10W	R1382 R1383		METAL GLAZE METAL CHIP	10K 18K	5% 0.50%	1/10W 1/10W
R1315	1-216-025-91	METAL GLAZE 100	5%	1/10W	R1384 R1385		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R1316		METAL GLAZE 4.7K	5%	1/10W	R1386		METAL GLAZE		5%	1/10W
R1317 R1318	1-216-089-91	METAL GLAZE 220 METAL GLAZE 47K	5% 5%	1/10W 1/10W	R1387		METAL CHIP	1.2K	0.50%	1/10W
R1319 R1320		METAL GLAZE 33K METAL GLAZE 2.2K	5% 5%	1/10W 1/10W	R1388 R1389		METAL CHIP METAL CHIP	39K 2K	0.50% 0.50%	1/10W 1/10W
R1321		METAL CHIP 820	0.50%	1/10W	R1390 R1391	1-216-647-11	METAL CHIP METAL GLAZE	680	0.50% 5%	1/10W 1/10W
R1322	1-216-057-00	METAL GLAZE 2.2K	5%	1/10W	1					
R1324 R1325	1-216-652-11	METAL CHIP 1.1K	5% 0.50%		R1392 R1393	1-216-063-91	METAL GLAZE METAL GLAZE	3.9K	5% 5%	1/10W 1/10W
R1326	1-216-073-00	METAL GLAZE 10K	5%	1/10W	R1394 R1395		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R1327 R1328		METAL GLAZE 10K METAL GLAZE 1.5M	5% 5%	1/10W 1/10W	R1396	1-216-071-00	METAL GLAZE	8.2K	5%	1/10W
R1329	1-216-103-00	METAL GLAZE 180K METAL GLAZE 22K	5% 5%	1/10W	R1397		METAL GLAZE		5%	1/10W
R1330 R1331		METAL CHIP 15K	0.50%	1/10W 1/10W	R1399 R1401	1-216-085-00	METAL GLAZE METAL GLAZE	33K	5% 5%	1/10 W 1/10 W
R1332	1-216-671-11	METAL CHIP 6.8K	0.50%	1/10W	R1402 R1403		CONDUCTOR, C METAL CHIP	HIP 1K	0.50%	1/10W
R1333 R1334		METAL GLAZE 1K METAL GLAZE 3.9K	5% 5%	1/10W 1/10W	R1404	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R1335 R1336	1-249-401-11		5% 5%	1/4W F 1/10W	R1405 R1406	1-216-071-00	METAL GLAZE	8.2K	5% 0.50%	1/10W
					R1407	1-216-063-91	METAL GLAZE		5%	1/10W 1/10W
R1337 R1338	1-216-647-11	METAL GLAZE 3.3K METAL CHIP 680	5% 0.50%	1/10W 1/10W	R1408		METAL GLAZE		5%	1/10W
R1339 R1340		METAL GLAZE 220 METAL GLAZE 220	5% 5%	1/10W 1/10W	R1409 R1410		CONDUCTOR, C METAL GLAZE		5%	1/10 W
R1341		METAL GLAZE 220	5%	1/10W	R1411 R1412	1-216-073-00	METAL GLAZE METAL GLAZE	10K	5%	1/10 W
R1342		METAL GLAZE 27K	5%	1/10W	R1413		METAL GLAZE		5% 5%	1/10 W 1/10 W
R1343 R1344		METAL GLAZE 330 METAL GLAZE 68K	5% 5%	1/10W 1/10W	R1414	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W
R1345 R1346		METAL GLAZE 330K METAL GLAZE 100K	5% 5%	1/10W 1/10W	R1415 R1416		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
					R1417	1-216-033-00	METAL GLAZE	220	5%	1/10W
R1347 R1348	1-216-071-00	METAL GLAZE 10K METAL GLAZE 8.2K	5% 5%	1/10W 1/10W	R1418		METAL GLAZE		5%	1/10W
R1349 R1350		METAL GLAZE 270 METAL GLAZE 10K	5% 5%	1/10W 1/10W	R1419 R1420		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R1351	1-216-033-00	METAL GLAZE 220	5%	1/10W	R1421 R1422	1-216-649-11		820		1/10W 1/10W
R1352 R1353		METAL GLAZE 4.7K METAL GLAZE 4.7K	5% 5%	1/10W 1/10W	R1423		METAL GLAZE		5%	1/10W
R1354	1-216-089-91	METAL GLAZE 47K	5%	1/10W	R1424		METAL GLAZE			1/10W
R1355 R1356		METAL GLAZE 220 METAL GLAZE 220K	5% 5%	1/10W 1/10W	R1425 R1426		METAL GLAZE METAL GLAZE		5% 5%	1/10 W 1/10 W
					R1427			18K		1/10W



 The components identified by in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.

Les composants identifies par une trame et une marque A sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The componants identified by shading and mark ∆ are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION		R	EMARK	REF. NO.	PART NO.	DESCRIPTION		P	REMARK
R1428		METAL GLAZE	2 217	5%	1/10W	R1500	1_216_640_11	METAL CHIP	820	0.50%	1/10W
		METAL CHIP	5.1K	0.50%	1/10W	R1501		METAL GLAZE		5%	1/10W
R1429 R1430		METAL CLAZE		5%	1/10W	R1502	1-260-105-11	CARBON	3.3K	5%	1/2W
R1431		METAL GLAZE		5%	1/10W	R1503		METAL GLAZE		5%	1/10W
R1432		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R1504 R1505	1-216-686-11	METAL CHIP	30K 10	0.50% 5%	1/10W 1/4W F
R1433	1-210-083-00	METAL GLAZE	33M.	370	1/10W	R1506		METAL GLAZE		5%	1/10W
R1434		METAL CHIP	560	0.50%	1/10W					((20M2U/E)
R1435 R1436		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R1506	1_216_040_01	METAL GLAZE	1K	5%	1/10W
R1430		METAL GLAZE		5%	1/10W	KIJOO	1-210-047-71	METAL GUALL	116		M4U/E/A)
R1438		METAL GLAZE		5%	1/10W	R1507		METAL GLAZE		5%	1/10W
R1439	1 216 050 00	METAL GLAZE	2 7V	5%	1/10W	R1508 R1509		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R1440		METAL GLAZE		5%	1/10W	R1510		METAL GLAZE		5%	1/10W
R1441		METAL GLAZE		5%	1/10W	D1511	1 01/ 0/0 11	METAL OWNE	0.0	E 01	1337 77
R1442 R1443		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R1511 R1512		METAL OXIDE METAL CHIP	680	5% 0.50%	1W F 1/10W
1/14-12	1-210-015-00	METAL GLAZE	33	570	171011	R1513	1-247-752-11		1K	5%	1/2W F
R1444		METAL GLAZE		5%	1/10W	R1514	1-247-711-11		680	5%	1/4W F 1W F
R1445 R1446		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R1515	1-210-350-11	METAL OXIDE	1.2	5%	IW F
R1447	1-216-081-00	METAL GLAZE	22K	5%	1/10W	R1516		METAL GLAZE		5%	1/10W
R1448	1-216-085-00	METAL GLAZE	33K	5%	1/10W	R1517 R1518		METAL GLAZE METAL OXIDE		5% 5%	1/10W 1W F
R1449	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W	R1519		METAL OXIDE		5%	iw F
R1450	1-216-129-00	METAL GLAZE	2.2M	5%	1/10W	R1520		METAL GLAZE		5%	1/10W
R1451		METAL GLAZE		5% 5%	1/10W 1/10W	R1521	1.216-020-00	METAL GLAZE	150	5%	1/10W
R1452 R1453		METAL GLAZE METAL GLAZE		5%	1/10W	R1523		METAL OXIDE		5%	iw F
						R1524		METAL OXIDE		5%	1W F
R1454		METAL GLAZE		5% 5%	1/10W 1/10W	R1525 R1526		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R1455 R1456		METAL GLAZE METAL GLAZE		5%	1/10W	K1320	1-210-009-91	METAL GLAZE	4716	5 70	
R1457	1-216-089-91	METAL GLAZE	47K	5%	1/10W	R1527	1-249-413-11		470	5%	1/4W F
R1458	1-216-085-00	METAL GLAZE	33K	5%	1/10W	R1528 R1529	1-215-869-11		1K 8.2K	5% 20%	1W F 1/2W
R1459	1-216-133-00	METAL GLAZE	3.3M	5%	1/10W	R1530	1-216-115-00	METAL GLAZE	560K	5%	1/10W
R1460		METAL GLAZE		5%	1/10W 1/10W	R1531	1-247-697-11	CARBON	56	5%	1/4W IF
R1461 R1462		METAL CHIP METAL CHIP	560 560	0.50% 0.50%	1/10W	R1532	1-216-059-00	METAL GLAZE	2.7K	5%	1/10W
R1463		METAL CHIP	560	0.50%	1/10W	R1533	1-249-414-11		560	5%	1/4W F
R1464	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W	R1534		METAL CHIP	2.2K	0.50%	1/10W 1/10W
R1465	1-216-097-91	METAL GLAZE	100K	5%	1/10W	R1537	1-249-389-11		4.7	5%	1/4W F
R1466 R1467		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R1538	1-216-073-00	METAL GLAZE	10K	5%	1/10W
R1468		METAL GLAZE		5%	1/10W	R1539		METAL GLAZE		5%	1/10W
D1460			0.017	-01	1 /4 0337	D1540	1 016 106 01	METAL CLASE	2201		M4U/E/A)
R1469 R1470		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R1540 R1541		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R1471		METAL GLAZE		5%	1/10W	R1542	1-247-692-71		22	5%	1/4W F
R1472		METAL GLAZE		5%	1/10W					(20)M4U/E/A)
R1473	1-216-081-00	METAL GLAZE	221	5%	1/10W	R1543	1-216-027-00	METAL GLAZE	120	5%	1/10W
R1475		METAL CHIP		0.50%	1/10W	R1547	1-216-393-00	METAL OXIDE	2.2	5%	3W F
R1476 R1477		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R1548 R1549	1-216-057-00	METAL GLAZE	2.2K 390	5% 5%	1/10W 1/2W
R1478		METAL GLAZE		5%	1/10W	R1550		METAL GLAZE		5%	1/10W
R1480	1-216-089-91	METAL GLAZE	47K	5%	1/10W	Diesi	1 240 202 11	CARRON	10	C 01.	1/4W F
R1481	1-216-115-00	METAL GLAZE	560K	5%	1/10W	R1551 R1552	1-249-393-11 1-216-091-00	METAL GLAZE	10 56 K	5% 5%	1/10W
R1482	1-216-089-91	METAL GLAZE	47K	5%	1/10W	R1553	1-216-091-00	METAL GLAZE	56K	5%	1/10W
R1483 R1484		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R1554 R1555		METAL GLAZE CONDUCTOR, C		5%	1/10W
R1485		METAL GLAZE		5%	1/10W	KIJJJ	1-210-295-91	CONDUCTOR, C			
						R1556		METAL GLAZE		5%	1/10W
R1486 R1487		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R1557 R1558	1-218-760-11	METAL CHIP CARBON	220K 10	0.50% 5%	1/10W 1/4W F
R1488	1-216-083-00	METAL GLAZE	27K	5%	1/10W	R1559	1-249-393-11	CARBON	10	5%	1/4W F
R1489		METAL GLAZE		5%	1/10W	R1560	1-216-049-91	METAL GLAZE	IK	5%	1/10W
R1490	1-210-035-00	METAL GLAZE	270	5%	1/10W	R1564	1-216-645-11	METAL CHIP	560		1/10W
R1491		METAL GLAZE		5%	1/10W				477		M4U/E/L)
R1492 R1493		METAL GLAZE METAL GLAZE		5% 5%	1/1 0W 1/1 0W	R1567 R1568		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R1494	1-216-081-00	METAL GLAZE	22K	5%	1/10W	R1569	1-216-073-00	METAL GLAZE	10K	5%	1/10W
R1495		METAL GLAZE		5%	1/10W	R1570	1-216-073-00	METAL GLAZE	10K	5%	1/10W
R1496	1-216-089-91	METAL GLAZE	47K	5%	1/10W	R1571	1-216-103-00	METAL GLAZE	180K	5%	1/10W
R1498	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W	R1572	1-216-101-00	METAL GLAZE	150K	5%	1/10W
R1499	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W	R1573	1-216-073-00	METAL GLAZE	IUK	5%	1/10W



REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION			REMARK
R1574 R1575		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R2331 R2332		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
		METAL GLAZE		5%	1/10W	R2333 R2334	1-216-089-91	METAL GLAZE METAL GLAZE	47K	5% 5%	1/10W 1/10W
R1576 R1577	1-216-025-91	METAL GLAZE	100	5%	1/10W	R2335		METAL GLAZE		5%	1/10W
R1578 R1579	1-216-689-11	METAL GLAZE METAL CHIP	39K	5% 0.50%		R2336		METAL GLAZE		5%	1/10W
R1580	1-216-083-00	METAL GLAZE	27K	5% (2	1/10W 20M4U/E/A)	R2337 R2338	1-216-073-00	METAL GLAZE METAL GLAZE	10K	5% 5%	1/10W 1/10W
R1581	1-208-612-11	METAL OXIDE	10M	5%	1W	R2339 R2340		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R1582	1-208-610-11	METAL OXIDE	2M	5%	20M4U/E/A) 1W	R2341	1-216-037-00	METAL GLAZE	330	5%	1/10W
R1583	1-212-998-00		470	5%	20M4U/E/A) 1/2W F	R2342 R2343		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R1584		METAL CHIP	9.1K	(2	20M4U/E/A) 1/10W		1-216-121-91	METAL GLAZE METAL CHIP		5% 0.50%	1/10W 1/10W
					20M4U/E/A) 1/10W	R2346		METAL GLAZE		5%	1/10W
R1585	1-210-055-00	METAL GLAZE	1.01		20M4U/E/A)	R2347	1-216-061-00	METAL GLAZE	3.3K	5%	1/10W
R1586	1-216-691-11	METAL CHIP	47K		1/10W	R2348 R2349	1-216-679-11	METAL GLAZE METAL CHIP	15K	5% 0.50%	1/10W 1/10W
R1587	1-216-057-00	METAL GLAZE	2.2K	5%	20M4U/E/A) 1/10W			METAL GLAZE		5%	1/10W
R1588	1-216-298-00	METAL GLAZE	2.2	5% (2	20M4U/E/A) 1/10W	R2351 R2352		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R1589	1-216-386-11	METAL OXIDE	0.56	5% - (2	20M4U/E/A) 3W F	R2353 R2354		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R1590	1-216-001-00	METAL GLAZE	10	5%	1/10W 20M4U/E/A)	R2358	1-216-025-91	METAL GLAZE	100	5%	1/10W
R1591	1-249-443-11	CARRON	0.47	5%	1/4W F	R2361 R2362		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R1592	1-247-760-11		4.7K		0M4U/E/A) 1/2W F	R2363 R2364	1-216-065-00	METAL GLAZE METAL GLAZE	4.7K	5% 5%	1/10W 1/10W
R1593	1-249-485-11		8.2		0M4U/E/A) 1/2W F	R2365		METAL CHIP	33K	0.50%	1/10W
R1594		METAL OXIDE			OM4U/E/A) IW F	R2366 R2367		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R1595		METAL GLAZE			0M4U/E/A) 1/10W		1-216-065-00	METAL GLAZE METAL CHIP		5% 0.5O%	1/10W 1/10W
R1596		METAL GLAZE		5%	1/10W	R2371		METAL GLAZE		5%	1/10W
R1597	1-216-073-00	METAL GLAZE	10K	5%	1/10W	R2372 R2374		METAL GLAZE		5%	1/10W 1/10W
R1598 R1599	1-202-830-00	METAL GLAZE SOLID	10K	5% 20%	1/10W 1/2W	R2375	1-216-089-91	METAL GLAZE METAL GLAZE	47K	5% 5%	1/10W
R2300	1-216-065-00	METAL GLAZE	4.7K	5%	0M4U/E/A) 1/10W	R2376 R2377		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R2301		METAL GLAZE		5%	1/10W	R2378		METAL GLAZE		5%	1/10W
R2302 R2303	1-216-093-00	METAL CHIP METAL GLAZE		0.50% 5%	1/10W 1/10W	R2379 R2380	1-216-089-91	METAL GLAZE METAL GLAZE	47K	5% 5%	1/10W 1/10W
R2304 R2305		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R2381 R2382		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R2306		METAL GLAZE		5%	1/10W	R2383		METAL GLAZE		5%	1/10W
R2307 R2308		METAL GLAZE METAL GLAZE		5% 5%	1/10 W 1/10 W	R2384 R2385		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R2309 R2310		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R2386 R2387		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R2311	1-216-073-00	METAL GLAZE	10K	5%	1/10W	R2388	1-216-073-00	METAL GLAZE	10K	5%	1/10W
R2312 R2313		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R2389 R2390		METAL GLAZE METAL CHIP	220 680	5% 050 %	1/10W 1/10W
R2314 R2315	1-216-645-11	METAL CHIP METAL CHIP	560 15K	0.50% 0.50%	1/10W 1/10W	R2391 R2392	1-216-647-11	METAL CHIP METAL GLAZE	680	050 % 5%	1/10W 1/10W
R2316		METAL GLAZE		5%	1/10W	R2393		METAL GLAZE		5%	1/10W
R2317	1-216-049-91	METAL GLAZE	1K	5%	1/10W	R2394	1-216-081-00	METAL GLAZE	22K	5%	1/10W
R2318 R2319	1-216-093-00	METAL GLAZE METAL GLAZE	68K.	5% 5%	1/10W 1/10W	R2396 R2397	1-216-113-00	METAL GLAZE METAL GLAZE	470K	5% 5%	1/10W 1/10W
R2320		METAL CHIP	12K	0.50%	1/10W	R2398		METAL GLAZE		5%	1/10W
R2321 R2322	1-216-065-00	METAL GLAZE METAL GLAZE	4.7K	5% 5%	1/10W 1/10W	R2399 R2501	1-216-083-00	METAL GLAZE METAL GLAZE	27K	5% 5%	1/10W 1/10W
R2323 R2324		METAL CHIP METAL GLAZE	22K 10K	0.50% 5%	1/10W 1/10W	R2502 R2503		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R2325	1-216-063-91	METAL GLAZE	3.9K	5%	1/10W	R2504		METAL GLAZE		5%	1/10W
R2326 R2327		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R2505 R2506		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R2328 R2329	1-216-049-91	METAL GLAZE METAL GLAZE	1K	5% 5%	1/10W 1/10W	R2506		METAL GLAZE			(20M2U/E) 1/10W
R2330		METAL GLAZE		5%	1/10W ¹)M4U/E/A)



Les composants identifies par une trame et une marque \(\frac{\Lambda}{\text{sont}}\) critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The components identified by shading and mark ∆ are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION		Ē	REMARK	REF. NO	PART NO.	DESCRIPTION]	REMARK
R2507	1-216-105-91	METAL GLAZE	220K	5%	1/10W	R3385		METAL GLAZE		5%	1/10W
R2507	1-216-109-00	METAL GLAZE	330K	5%	(20M2U/E) 1/10W	R3386 R3390		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
				(20)M4U/E/A)	R3394 R3395	1-216-089-91	METAL GLAZE METAL GLAZE	47K	5% 5%	1/10W 1/10W
R2551		METAL GLAZE		5%	1/10W						
R2552 R2553		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R3396 R3398		METAL GLAZE METAL CHIP	36K	5% 0.50%	1/10W 1/10W
R2555	1-216-055-00	METAL GLAZE	1.8 K	5% 5%	1/10W 1/10W	R4401 R4402		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W
R2556		METAL GLAZE				R4404		METAL GLAZE		5%	1/10W
R2557 R2558		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R4405	1-216-069-00	METAL GLAZE	6.8K	5%	1/10W
R2559	1-216-039-00	METAL GLAZE	390	5%	1/10W	R4407	1-216-061-00	METAL GLAZE	3.3K	5%	1/10W
R2560 R2561		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R4408 R4409	1-216-059-00	METAL GLAZE METAL GLAZE	2.7K	5% 5%	1/10W 1/10W
R2562	1-216-001-00	METAL GLAZE	10	5%	1/10W	R4410	1-216-059-00	METAL GLAZE	2.7K	5%	1/10W
R2563	1-249-421-11	CARBON	2.2K	5%	1/4W	R4411		METAL GLAZE		5%	1/10W
R3301 R3302		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R4412 R4413	1-216-295-91	METAL GLAZE CONDUCTOR, C	CHIP	5%	1/10W
R3303	1-216-065-00	METAL GLAZE	4.7K	5%	1/10W	R4414 R4415		CONDUCTOR, C			
R3304		METAL GLAZE		5%	1/10W						
R3305 R3306		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	R4416	1-210-293-91	CONDUCTOR, C	.nır		
R3308 R3309		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W			<variable re<="" td=""><td>SISTOR></td><td></td><td></td></variable>	SISTOR>		
						D. 1501	1 222 122 22			20	
R3310 R3311		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	RV501	1-223-102-00	RES, ADJ, WIRE	WOUND	20	
R3312 R3317		METAL GLAZE METAL CHIP	220K 10K	5% 0.50%	1/10W 1/10W			<transforme< td=""><td>D_</td><td></td><td></td></transforme<>	D_		
R3320		METAL GLAZE		5%	1/10W						
R3323	1-216-089-91	METAL GLAZE	47K	5%	1/10W	T300 T500	1-406-781-11 1-426-668-11	TRANSFORMER	, FERRITE	(HDT)	
R3333 R3334		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	T501 T501		TRANSFORMER RING, SHORT	ASSY, FL	YBACK	
R3335	1-216-113-00	METAL GLAZE	470K	5%	1/10W	T501		SCREW +BVTP	4X16 TYPE	E2 IT-3	
R3337	1-216-099-00	METAL GLAZE	120K	5%	1/10W	T502	1-413-059-00	TRANSFORMER	, FERRITE	(DFT)	
R3338 R3339		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	T503	1-460-017-11	TRANSFORMER		, ,	
R3340	1-216-099-00	METAL GLAZE	120K	5%	1/10W						
R3344 R3345		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W			<thermistor:< td=""><td>•</td><td></td><td></td></thermistor:<>	•		
R3346	1-216-025-91	METAL GLAZE	100	5%	1/10W	TH500	1-807-970-11	THERMISTOR			
R3347	1-216-025-91	METAL GLAZE	100	5%	1/10W			<test pin=""></test>			
R3348 R3349	1-216-025-91	METAL GLAZE METAL GLAZE	100	5% 5%	1/10W 1/10W						
R3350	1-216-117-00	METAL GLAZE	680K	5%	1/10W			CHIP, CHECKER CHIP, CHECKER			
R3351		METAL GLAZE		5%	1/10W	TP305	*1-535-877-22	CHIP, CHECKER	2		
R3353 R3355		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	TP306 TP307	*1-535-877-22	CHIP, CHECKER CHIP, CHECKER			
R3356 R3357		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	TP311	*1-535-877-22	CHIP, CHECKER			
						TP312	*1-535-877-22	CHIP, CHECKER	2		
R3358 R3359		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	TP401 TP402	* 1-535-877-22	CHIP, CHECKER CHIP, CHECKER	2		
R3360 R3361		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	TP403	* 1-535-877-22	CHIP, CHECKER	1		
R3362		METAL GLAZE		5%	1/10W	TP501 TP502		CHIP, CHECKER CHIP, CHECKER			
R3363		METAL GLAZE		5%	1/10W	TP503	*1-535-877-22	CHIP, CHECKER			
R3364 R3365		METAL GLAZE		5% 5%	1/10W 1/10W	TP504	*1-535-877-22	CHIP, CHECKER			
R3366 R3367	1-216-093-00	METAL GLAZE	68K	5%	1/10W 1/10W			<crystal></crystal>			
		METAL GLAZE		5%		W10-	1 550 155 15		1117		
R3368 R3369		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	X101 X300		VIBRATOR, CER VIBRATOR, CRY			
R3376 R3377	1-216-081-00	METAL GLAZE METAL GLAZE	22K	5% 5%	1/10W 1/10W	X300 X301	3-741-396-01	INSULATOR VIBRATOR, CRY			
R3378		METAL GLAZE METAL GLAZE		5%	1/10W	X301		INSULATOR	SIAL		
R3379	1-216-107-00	METAL GLAZE	270K	5%	1/10W						
R3381 R3382	1-216-041-00	METAL GLAZE		5% 0.50%	1/10W 1/10W	*****	*****	*******		******	****
R3383	1-216-069-00	METAL GLAZE	6.8K	5%	1/10W						
R3384	1-216-063-91	METAL GLAZE	3.9K	5%	1/10W						



REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION		!	REMARI	<u>K</u>
		G BOARD, CO	******			D616 D617 D618	8-719-110-44	DIODE ERA15-0 DIODE RD16ES DIODE EGP20G	B1			
	* 4-374-846-11 4-382-854-11	HOLDER, FUSE COVER, CAPAC SCREW (M3X10 RUBBER, SILIC	CITOR, CAP (), P, SW (+)		')			<ferrite bea<="" td=""><td>D></td><td></td><td></td><td></td></ferrite>	D>			
		<capacitor></capacitor>				FB601 FB602 FB603 FB604	1-410-396-41 1-410-396-41	FERRITE BEAD FERRITE BEAD FERRITE BEAD FERRITE BEAD	INDUCTO	OR 0.45U OR 0.45U	H H	
C602 C603	1-130-711-00 1-130-711-00			20% 20%	250V 250V	FB605	1-410-396-41	FERRITE BEAD	INDUCTO	R 0.45U	H	
C604 C605 C606	1-113-924-11 1-113-924-11 1-113-924-11	CERAMIC CERAMIC CERAMIC	0.0047MF 0.0047MF 0.0047MF	20% 20%	250V 250V 250V 250V	FB606 FB607 FB608 FB609	1-410-396-41 1-410-397-21 1-410-397-21	FERRITE BEAD FERRITE BEAD FERRITE BEAD FERRITE BEAD	INDUCTO INDUCTO	OR 0.45U OR 1.1UH OR 1.1UH	H I I	
C607 C608	1-113-924-11 1-113-924-11		0.0047MF : 0.0047MF :		250V 250V	FB610	1-410-397-21	FERRITE BEAD	INDUCTO	OR 1.1UH	Į	
C609 C610 C611	1-113-924-11 1-113-924-11 1-113-924-11	CERAMIC CERAMIC	0.0047MF 0.0047MF 0.0047MF	20% 20%	250V 250V 250V	FB611 FB612 FB613	1-410-397-21	FERRITE BEAD FERRITE BEAD FERRITE BEAD	INDUCTO	R 1.1UH	Ī	
C612 C613	1-137-484-11 1-137-484-11			10% 10%	630V 630V			<ic></ic>				
C614 C615	1-129-718-00 1-136-619-11	FILM		10%	630V 2KV	IC601	4-058-250-01	SHEET, INSULA	TING			
C616 C617 C618	1-107-909-11 1-107-430-91 1-107-906-11	ELECT CERAMIC	47MF : 0.0033MF	20%	35V 1KV 50V	IC601 IC602 IC603 IC604	8-749-925-03 8-749-010-47	IC STR-M6524 IC STR-S3115 IC NJM78M05FA				
C619 C621	1-107-911-11 1-117-791-11	ELECT	220MF	20% 20%	50V 160V	IC605	8-759-231-58					
C622	1-102-038-00		0.001MF	2010	500V	10005	0-737-231-30	10 171/0125				
C623	1-107-900-51		4700MF 0.001MF	20%	35V 500V			<coil></coil>				
C624 C625 C626 C627	1-102-038-00 1-107-900-51 1-102-038-00 1-107-900-51	ELECT CERAMIC	4700MF 0.001MF	20% 20%	35V 500V 35V	L601 L1601 L1602 L2601	1-410-679-31	COIL, CHOKE 2 INDUCTOR 270 COIL, CHOKE COIL (WITH CO	UH			
C628 C629 C630	1-102-038-00 1-107-891-11 1-126-964-11 1-136-853-11	ELECT ELECT	10MF	20% 20% 5%	500V 25V 50V 200V			<photo coup<="" td=""><td></td><td></td><td></td><td></td></photo>				
C631 C632	1-107-492-11			20%	160V	PH601	8-749-923-50	PHOTO COUPLI	ER PC111Y	'S		
C633 C634 C636	1-107-885-11 1-107-911-11 1-107-909-11	ELECT ELECT	220MF 47MF	20% 20% 20%	16V 50V 50V			<transistor< td=""><td></td><td></td><td></td><td></td></transistor<>				
C637 C638	1-107-910-11 1-137-484-11			20% 10%	50V 630V	Q601 Q603		TRANSISTOR 2				
C2601	1-102-038-00	CERAMIC	0.001MF		500V			<resistor></resistor>				
		<connector></connector>	•			R601 R602	1-202-719-00 1-216-491-11	SOLID METAL OXIDE	1M 56K	2)% 5%	1/2W 3W	F
CN601 CN602 CN603 CN605	*1-695-561-11 *1-508-765-00	PIN, CONNECTO PIN, CONNECTO PIN, CONNECTO PIN, CONNECTO	OR (PC BOA OR (5mm P1)	RD) 7: ICH) 3	P P	R603 R604 R605	1-216-490-11 1-249-418-11 1-249-415-11		39K 1.2K 680	5% 5% 5%	3W 1/4W 1/4W	F
CN606		PLUG, CONNEC				R606 R607	1-207-642-00 1-249-426-11	WIREWOUND	0.15 5.6K	1)% 5%	3W 1/4W	F
CN607 CN609		PLUG, CONNECTO		ГСН) 2	P.P	R608 R609 R610	1-249-428-11 1-249-428-11 1-249-428-11	CARBON CARBON	8.2K 8.2K 8.2K	5% 5% 5%	1/4W 1/4W 1/4W	
		<diode></diode>				R611 R612	1-249-417-11 1-249-404-00		1K 82	5% 5%	1/4W 1/4W	F
D601 D605 D606	8-719-979-85 8-719-988-55	DIODE D4SB60I DIODE EGP20G DIODE RGP15K	-6179			R612 R613 R614 R615	1-249-419-11 1-249-385-11 1-202-727-00	CARBON CARBON	1.5K 2.2 4.7M	5% 5% 11%	1/4W	F
D607 D608		DIODE RU-3AM DIODE 1SS119-2				R617	1-202-933-61		0.1	11%	1/2W	F
D609		DIODE RU-3AM	I			R618 R619	1-202-933-61	FUSIBLE	0.1	11%	1/2W 1/2W	F
D610 D612	8-719-045-48	DIODE D5L60 DIODE FML-G1	28			R620 R621	1-202-933-61 1-215-877-11	FUSIBLE METAL OXIDE	0.1 22K	11% 5%	1/2W 1W	F F
D613 D614 D615	8-719-045-48	DIODE EGP20G DIODE FML-G19 DIODE EGP20G	2S			R622 R623 R626	1-249-401-11 1-249-417-11 1-247-895-91	CARBON	47 1K 470K	55 55 55	1/4W 1/4W 1/4W	F
DOLO	0-117-717-03	D1000 E01 200				AV&U	2-271-075-71	J. 141.15 C/4	VIOIL	J-10	A7 - F TT	



REF. NO.	PART NO.	DESCRIPTION			REMARK	.	REF. NO.	PART NO.	DESCRIPTION			REMARI	<u> </u>
R627 R628		METAL OXIDE METAL OXIDE		5% 5%	3W 3W	F F	CN702 CN703 CN704	1-695-915-11	PIN, CONNECTO TAB (CONTACT TAB (CONTACT	(1)		SP.	
R629 R630 R631	1-249-412-11	METAL OXIDE CARBON	390	10% 5% 5%	1/2W 3W 1/4W	F F			<diode></diode>		ŕ		
R632 R1602	1-249-401-11 1-202-842-11		47 220K	5% 20%	1/4W 1/2W	F	D701 D702		DIODE 1SS119-2 DIODE 1SS119-2				
R1603	1-202-842-11	SOLID	220K	20%	1/2W		D703 D704 D705	8-719-911-19 8-719-911-19	DIODE ISS119-2 DIODE ISS119-2 DIODE ISS119-2	25 25			
		<relay></relay>					D706		DIODE 1SS119-2	25			
RY601	1-515-738-11		_				D707 D708 D709	8-719-901-83 8-719-901-83	DIODE 1SS83 DIODE 1SS83 DIODE 1SS83				
		<transforme< td=""><td></td><td></td><td></td><td></td><td>D713</td><td></td><td>DIODE 18883</td><td></td><td></td><td></td><td></td></transforme<>					D713		DIODE 18883				
T601 T602 T603	1-426-716-11	TRANSFORMER TRANSFORMER TRANSFORMER	, LINE FIL	TER (I	LFT)		D715 D716 D717	8-719-901-83	DIODE 1SS83 DIODE 1SS83 DIODE 1SS83				
		<thermistor:< td=""><td>></td><td></td><td></td><td></td><td></td><td></td><td><jack></jack></td><td></td><td></td><td></td><td></td></thermistor:<>	>						<jack></jack>				
THP601	1-808-059-31	THERMISTOR, I	POSITIVE				J701 J701		SOCKET, PICTU SOCKET, PICTU				
		<test pin=""></test>							<coil></coil>				
TP1601	. 1-536-354-00	POST PIN					L702		INDUCTOR 22U				
		<varistor></varistor>					L703 L704	1-408-608-31	INDUCTOR 27U INDUCTOR 27U	H	(C)		
	1-809-942-71				•		L705 L705		INDUCTOR 27U INDUCTOR 39U				
VDR602	1-809-942-71	VARISTOR					L706	1-410-667-31	INDUCTOR 22U	Н			
******	********	********	******	*****	*****	k aju			<transistor></transistor>				
	* A-1331-628-A	C BOARD, CO	MPLETE (I	PVM-20	OM4U/E/A	.)	O701	8-729-119-78	TRANSISTOR 2		FE		
	* A-1331-630-A	A C BOARD, CO		PVM-20	DM2U/E)		Q702 Q703 Q704	8-729-119-78 8-729-119-78 8-729-200-17	TRANSISTOR 2: TRANSISTOR 2: TRANSISTOR 2: TRANSISTOR 2:	SC2785-HI SC2785-HI SA1091-O	FE		
	7-682-949-01	SCREW +PSW 3	X10				Q705		TRANSISTOR 2				
		<capacitor></capacitor>					Q706 Q710 Q711	8-729-200-17	TRANSISTOR 2: TRANSISTOR 2:	SA1091-O			
C701 C702	1-102-116-00 1-102-116-00	CERAMIC	680PF 680PF	10% 10%	50V 50V		Q712 Q713	8-729-200-17	TRANSISTOR 2: TRANSISTOR 2:	SA1091-O			
C703 C704	1-102-116-00 1-102-121-00	CERAMIC	680PF 0.0022MF	10%	50V 50V		Q714 Q715		TRANSISTOR 2				
C705	1-104-665-11		100MF	20%	16V		Q716 Q717		TRANSISTOR 25 TRANSISTOR 25				
C706 C707	1-102-074-00 1-162-116-00	CERAMIC	0.001MF 680PF	10% 10%	50V 2KV								
C708 C710	1-136-601-11 1-101-880-00	CERAMIC	0.01 MF 47PF	10% 5%	630V 50V				<resistor></resistor>			4 /4777	
C711	1-101-880-00		47PF	5%	50V		R702 R704	1-247-897-11 1-215-404-00	METAL	560K 200	5% 1%	1/4W 1/4W	
C712 C714	1-101-880-00 1-102-976-00	CERAMIC	47PF 180PF	5% 5%	50V 50V		R705 R706	1-215-404-00 1-215-404-00	METAL	200	1% 1%	1/4W 1/4W 1/4W	
C715 C716 C724	1-102-976-00 1-102-976-00	CERAMIC	180PF 180PF	5% 5% 20%	50V 50V 100V		R707 R708	1-249-429-11		10K 10K	5% 5%	1/4W	
C/24	1-107-929-11	ELEC I	10MF	2070	(20M2U	Œ)	R709 R710	1-249-429-11 1-215-388-00	CARBON	10K 43	5% 1%	1/4W 1/4W	
C726 C733	1-107-662-11 1-107-652-11		22MF 10MF	20% 20%	250V 250V		R711 R712	1-215-390-00 1-215-388-00	METAL	51 43	1% 1%	1/4W 1/4W	
C734 C737	1-101-888-00 1-102-934-00	CERAMIC	68PF 1PF	5%	50V F 50V		R715	1-202-818-00		1K	20%	1/2W	
C740	1-162-114-00		0.0047MF		2KV 20M4U/E/	A)	R716 R717	1-202-818-00	METAL OXIDE SOLID	1K	5% 20%	1/2W	
							R718 R719	1-216-486-00 1-202-818-00	METAL OXIDE SOLID	8.2K 1K	5% 20%	3W 1/2W	F
CN 201		<connector></connector>					R720		METAL OXIDE		5%	3W	F
CN701	T 1-564-511-11	PLUG, CONNEC	TOR 8P				R722	1-202-883-11	20LID	680K	20%	1/2W	

The components identified by shading and mark ∆ are critical for safety.
Replace only with part number specified.

Les composants identifies par une trame et une marque Λ sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.



REF. NO.	PART NO.	DESCRIPTION			REMARK	. !	REF. NO.	PART NO.	DESCRIPTION			REMARK
R723 R724	1-202-838-00 1-202-842-11	SOLID	100K 220K	20% 20%	1/2W 1/2W		R2137 R2138	1-249-414-11 1-249-414-11		560 560	5% 5%	1/4W 1/4W
R725	1-202-838-00		100K	20%	1/2W		R2139	1-249-414-11 1-249-414-11		560 560	5% 5%	1/4W 1/4W
R726	1-202-846-00		470K	20%	1/2W (20M2U/	Æ)	R2140 R2141	1-249-414-11	CARBON	560	5%	1/4W
R728	1-202-837-00	SOLID	82K	20%	1/2W (20M2U/	Æ)	R2142 R2143	1-249-414-11 1-249-414-11		560 560	5% 5%	1/4W 1/4W
R729	1-202-549-00	SOLID	100	20%	1/2W (20M2U/	Æ)	R2144	1-249-414-11	CARBON	560	5%	1/4W
R731 R732	1-247-815-91 1-247-815-91		220 220	5% 5%	1/4W 1/4W		R2145 R2147	1-249-414-11 1-215-427-00		560 1.8K	5% 1%	1/4W 1/4W
							R2148 R2149	1-215-419-00 1-215-414-00	METAL	820 510	1% 1%	1/4W 1/4W
R733 R734	1-247-815-91 1-249-409-11		220 220	5% 5%	1/4W 1/4W	F	R2149					
R735	1-249-409-11		220 220	5% 5%		F	R2150 R2151	1-215-409-00 1-215-407-00		330 270	1% 1%	1/4W 1/4W
R736 R737	1-249-409-11 1-247-807-31		100	5%	1/4W		R2152	1-215-404-00	METAL	200	1%	1/4W
			100	E 01	1 /4337	i	R2153 R2154	1-215-401-11 1-215-399-00		150 120	1% 1%	1/4W 1/4W
R738 R739	1-247-807-31 1-247-807-31		100 100	5% 5%	1/4W 1/4W		K2154	1-213-399-00	METAL	120	170	1/4 **
R740	1-249-433-11	CARBON	22K	5%	1/4W	F	R2155	1-215-397-00		100	1%	1/4W
R741	1-249-433-11 1-249-433-11		22K 22K	5% 5%		F	R2156 R2157	1-215-421-00 1-215-416-00		1K 620	1% 1%	1/4W 1/4W
R742	1-249-433-11	CARBON	22K	370	1/4 11	•	R2158	1-215-410-00		360	1%	1/4W
R744	1-247-843-11		3.3K	5%	1/4W		R2159	1-215-405-00	METAL	220	1%	1/4W
R745 R746	1-249-429-11	CARBON METAL OXIDE	10K 47K	5% 5%	1/4W 1W	F	R2160	1-215-421-00	METAL	1K	1%	1/4W
R747	1-247-725-11	CARBON	10K	5%	1/4W	F	RELOG	1 215 421 00				
R748	1-249-923-11	CARBON	1 K	5%	1/4W	F			<variable re<="" td=""><td>~GOTOIS</td><td></td><td></td></variable>	~GOTOIS		
R749	1-215-902-11	METAL OXIDE	47K	5%	2W	F			VARIABLE RE	5151 OK>		
R751	1-247-887-00	CARBON	220K	5%	1/4W		RV2101		RES, VAR, CAR			
R752 R753	1-247-887-00 1-247-887-00		220K 220K	5% 5%	1/4W 1/4W		RV2103 RV2105	1-225-385-11	RES, VAR, CAR RES, VAR, CAR	BON 20K BON 20K		
R754	1-247-863-91		22K	5%	1/4W		RV2109	1-225-385-11	RES, VAR, CAR	BON 20K		
7755	1 240 424 11	CARRON	27K	5%	1/4W		RV2113	1-225-385-11	RES, VAR, CAR	BON 20K		
R755 R756	1-249-434-11 1-249-440-11		82K	5%	1/4W		RV2117	1-241-238-21	RES, VAR, CAR	BON 20K		
R760	1-249-400-11		39	5%	1/4W	F						
									<switch></switch>			
		<variable re<="" td=""><td>SISTOR></td><td></td><td></td><td></td><td>S2101</td><td>1 570 101 41</td><td>SWITCH, KEY E</td><td>OAPD</td><td></td><td></td></variable>	SISTOR>				S2101	1 570 101 41	SWITCH, KEY E	OAPD		
RV708	1-241-714-11	RES, ADJ, META	AL FILM 1	10M			S2101		SWITCH, KEY B			
RV709		RES, ADJ, META					S2103		SWITCH, KEY B			
							S2104 S2105		SWITCH, KEY B SWITCH, KEY B			
		<spark gap=""></spark>						1 570 060 11	CWITCH PEVE	OARD		*
SG701	1-519-422-11	GAP, SPARK (20	MATI/E/A)			i	S2106 S2107		SWITCH, KEY B SWITCH, KEY B			
SG702		GAP, SPARK (20				ı	S2108	1-570-101-41	SWITCH, KEY B	OARD		
SG703	1-519-422-11	GAP, SPARK (20)M4U/E/A)				S2109 S2110		SWITCH, KEY B SWITCH, KEY B			
SG704	1-519-422-11	GAP, SPARK (20)M4U/E/A)			l	32110	1-3/0-101-41	SWITCH, KET B	UAKD		
							S2111		SWITCH, KEY B			
******	*****	******	******	*****	******	**	S2112 S2113		SWITCH, KEY B SWITCH, KEY B			
							S2114	1-570-969-11	SWITCH, KEY B	OARD		
	* A-1372-302-A	H BOARD, CO	MPLETE *******									
									******	****	خوجها بدنوطون	
	* 4-348-208-00	HOLDER, LED					*****	*********	******	***	to de tales and de	****
							:	* A-1388-193-A	JBOARD, COM			
		<connector></connector>	•						******	******		
CN105	* 1-564-527-11	PLUG, CONNEC	TOR 12P									
CN106	* 1-564-526-11	PLUG, CONNEC	TOR 11P			Ì			<connector></connector>	•		
							CN608	* 1-695-561-11	PIN, CONNECTO	OR (PC BO	ARD)	7P
		<diode></diode>										
D2102	8-719-920-05	DIODE SLP2810	-50						<switch></switch>			
D2103		DIODE TLY123	77				PZ01 /	N 1 602 031 11	COUPPORT DISCLE	A C BOW	66	
D2104	0-114-431-33	DIODE 1SS133T	-11				S601 Z	0.1-072-721-11	SWITCH, PUSH	,a.c.ruw	A)E)	
		DECICTOR.										
		<resistor></resistor>					******	*******	******	******	k * * * * * * * * * * * * * * * * * * *	*****
R2101	1-249-419-11		1.5K	5%	1/4W	j						
R2107 R2136	1-249-430-11 1-249-414-11		12K 560	5% 5%	1/4W 1/4W	ı						
K2130	* *** ********************************	J. 1112 (J. 1	200	2 /	-, -, -,							



Les composants identifies par une trame et une marque \(\Lambda\) sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The componants identified by shading and mark ∆ are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION			REMARK
	* A-1390-704-A	X BOARD, CO				C2404 C2405	1-104-396-11 1-124-589-11		10MF 47MF	20% 20%	16V 16V
		<connector:< td=""><td></td><td></td><td></td><td>C2406 C2407</td><td>1-104-396-11 1-104-396-11</td><td></td><td>10MF 10MF</td><td>20% 20%</td><td>16V 16V</td></connector:<>				C2406 C2407	1-104-396-11 1-104-396-11		10MF 10MF	20% 20%	16V 16V
		COMILETOIO				C2408	1-104-396-11		10MF	20%	16V
CN108	*1-564-518-11	PLUG, CONNEC	TOR 3P			C2409	1-124-234-00	ELECT	22MF	20%	16V
						C2410	1-163-033-91	CERAMIC CHIP			50V
		<diode></diode>				C2411 C2412	1-104-396-11 1-104-396-11	ELECT	10MF 10MF	20% 20%	16V 16V
D001		DIODE SEL3810				C2413		CERAMIC CHIP		5%	50V
D002 D003		DIODE SEL3810				C2414 C2415	1-126-301-11	CERAMIC CHIP	1MF	20%	50V 50V
D004		DIODE SEL3810				C2416	1-124-589-11		47MF	20%	16V
						C2418		CERAMIC CHIP		2070	50V
						C2422	1-124-234-00		22MF	20%	16V
******	*****	******	*****	******	******	C2423	1-124-234-00		22MF	20%	16V
	* A -1300-705- A	S BOARD, CO	MPI ETE			C2424	1-163-033-91	CERAMIC CHIP	0.022MF		50V
	W-1390-103-N	*******				C2425	1-124-589-11	ELECT	47MF	20%	16V
			(PV	M-20M	(2U/20M4U)		1-124-589-11		47MF	20%	16V
						C2427	1-124-234-00		22MF	20%	16V
		<capacitor></capacitor>				C2428 C2429	1-163-033-91	CERAMIC CHIP	0.022MF 22MF	20%	50V 16V
C805	1-102-978-00	CERAMIC	220PF	5%	50V	C2429	1-124-234-00	ELEC I	ZZIVIF	20%	104
C806	1-136-165-00		0.1MF	5%	50V	C2430	1-163-033-91	CERAMIC CHIP	0.022MF		50V
C807	1-130-477-00		0.0033MF		50V	C2431	1-124-234-00		22MF	20%	16V
C810	1-136-165-00		0.1MF	5%	50V	C2432	1-124-234-00		22MF	20%	16V 50V
C811	1-136-165-00	FILM	0.1MF	5%	50V	C2433 C2434	1-124-463-00	CERAMIC CHIP	0.022MF 0.1MF	20%	50V
C812	1-136-495-11	FILM	0.068MF	5%	50V	02101	1 121 100 00		0121/12	-0,0	
C813	1-124-261-00		10MF	20%	50V	C2435		CERAMIC CHIP			50V
C818	1-136-165-00	FILM	0.1MF	5%	50V	C2436 C2437	1-124-234-00	CERAMIC CHIP	22MF	20%	16V 50V
						C2437	1-124-234-00		22MF	20%	16V
		<connector:< td=""><td>•</td><td></td><td></td><td>C2439</td><td>1-124-234-00</td><td></td><td>22MF</td><td>20%</td><td>16V</td></connector:<>	•			C2439	1-124-234-00		22MF	20%	16V
CN801	*1-573-896-11	SOCKET, CONN	ECTOR 12	P		C2440	1-163-033-91	CERAMIC CHIP	0.022MF		50V
Q11001	1 575-656-11	bocker, com	LOI OIL IL	•		C2441	1-124-234-00	ELECT	22MF	20%	16V
						C2442	1-124-234-00		22MF	20%	16V
		<coil></coil>				C2443 C2444	1-124-234-00 1-124-234-00		22MF 22MF	20% 20%	16V 16V
L801	1-410-470-11	INDUCTOR 10U	Н			C2444	1-124-234-00	ELECT	221111	20%	101
						C2445		CERAMIC CHIP			50V
		PECICEOP.				C2446		CERAMIC CHIP		200	50V 16V
		<resistor></resistor>				C2447 C2448	1-124-234-00 1-124-234-00		22MF 22MF	20% 20%	16V
R802	1-249-435-11	CARBON	33K	5%	1/4W	C2449	1-124-234-00		22MF	20%	16V
R803	1-247-863-91	CARBON	22K	5%	1/4W				***		4.577
R804 R805	1-215-454-00		24K 47K	1% 1%	1/4W 1/4W	C2450 C2451	1-124-234-00 1-124-589-11		22MF 47MF	20% 20%	16V 16V
R808	1-215-461-00 1-249-417-11		1K	5%	1/4W	C2452	1-124-589-11	ELECT	47MF	20%	16V
						C2454	1-126-163-11	ELECT	4.7MF	20%	25V
R812	1-249-417-11		1K	5%	1/4W	C2461	1-165-319-11	CERAMIC CHIP	0.1MF		50V
R813 R815	1-249-417-11 1-247-843-11		1K 3.3K	5% 5%	1/4W 1/4W	C2462	1-165-319-11	CERAMIC CHIP	0 IME		50V
R816	1-249-418-11		1.2K	5%	1/4W	C2463		CERAMIC CHIP			50V
R817	1-249-418-11		1.2K	5%	1/4W	C2464		CERAMIC CHIP			50V
R818	1-249-418-11	CADDON	1.21	50%	1/4W	C2465 C2466		CERAMIC CHIP CERAMIC CHIP			50V 50V
R819	1-249-418-11		1.2K 1.2K	5% 5%	1/4W 1/4W	C2400	1-103-319-11	CERAINIC CHIP	A'TIAIL,		30 ₹
R820	1-249-422-11		2.7K	5%	1/4W	C2467		CERAMIC CHIP			50V
						C2468		CERAMIC CHIP			50V
						C2469 C2470		CERAMIC CHIP CERAMIC CHIP			50V 50V
*****	*****	******	******	*****	******	C24/0	1-103-319-11	CERAMIC CHIP	O'I MIL		30 ₹
		TERMINAL BO		I/O (A)			<connector></connector>			
		*********		*****	*	CNIZOC	1 564 506 11	DI LIC CONNEC	TOP 11P		
				((Q BOARD)	CN306 CN307		PLUG, CONNEC			
	2-990-241-02	HOLDER (A),	PLUG			CN308	1-564-519-11	PLUG, CONNEC			
	3-178-213-21	SCREW +P 3X	10			CN2401 d	L1-251-263-11	INLET, AC			
	7-685-135-19	SCREW +P 2.6	X10 TYPE2	SLIT		CN2402	1-565-167-12	TERMINAL, (S)	(WITH SW) 4P	
		CADACITOR						TERMINAL, S (V			
		<capacitor></capacitor>				CN2404	1-704-872-11	CONNECTOR, M	IULII 20P		
C2401		CERAMIC CHIE		5%	50V						
C2402 C2403	1-104-396-11		10MF	20%	16V						
C2403	1-104-396-11	ELECI	10 MF	20%	16V '						



REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION		REMARK
		<diode></diode>		JR41 JR43		CONDUCTOR, CHIP CONDUCTOR, CHIP		
D2402 D2404		DIODE 1SS352 DIODE 1SS226		JR46	1-216-295-91	CONDUCTOR, CHIP		
D2405 D2406	8-719-800-76	DIODE 1SS226 DIODE 1SS226		JR47 JR48		CONDUCTOR, CHIP CONDUCTOR, CHIP		
D2407		DIODE 1SS226		JR52 JR60		CONDUCTOR, CHIP CONDUCTOR, CHIP		
D2408 D2409		DIODE 1SS226 DIODE 1SS226						
D2410 D2411		DIODE 1SS226 DIODE 1SS226				<transistor></transistor>		
D2415		DIODE 1SS226		Q2401 Q2402	8-729-216-22	TRANSISTOR 2SC1623-L5L TRANSISTOR 2SA1162-G	. 6	
D2416 D2417	8-719-800-76	DIODE 1SS226 DIODE 1SS226		Q2403 Q2404	8-729-216-22	TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G		
D2418 D2420	8-719-037-53	DIODE 1SS226 DIODE RD27SB-T1		Q2405		TRANSISTOR 2SA1162-G	4	
D2421		DIODE RD27SB-T1		Q2408 Q2409	8-729-120-28	TRANSISTOR 2SC1623-L5L	_6	
D2422 D2423		DIODE RD27SB-T1 DIODE RD27SB-T1		Q2410 Q2411	8-729-120-28	TRANSISTOR 2SC1623-L5L TRANSISTOR 2SC1623-L5L TRANSISTOR 2SC1623-L5L	.6	
		40		Q2412 Q2414		TRANSISTOR 2SC1623-L5L		
IC2401	9 750 500 71	<ic> IC XRU4021BF-E2</ic>		Q2415 Q2416	8-729-120-28	TRANSISTOR 2SC1623-L5L TRANSISTOR 2SC1623-L5L TRANSISTOR 2SA1162-G		
IC2401 IC2402 IC2403	8-759-509-71	IC XRU4021BF-E2 IC MM1113XFF		Q2417		TRANSISTOR 2SC1623-L5L	-6	
IC2404 IC2405	8-759-084-76	IC MM1111XF IC MM1113XFF				<resistor></resistor>		
102405	0 105 201 05			R2401	1-216-073-00	METAL GLAZE 10K	5%	1/10W
		<jack></jack>		R2402 R2404	1-216-089-91	METAL GLAZE 560 METAL GLAZE 47K	5% 5%	1/10W 1/10W
J2401 J2402	1-766-738-11	CONNECTOR, COAXIAL (BNC) BNC (WITH SW)		R2405 R2406		METAL GLAZE 10K METAL GLAZE 47K	5% 5%	1/10W 1/10W
J2403 J2404	1-766-738-11	CONNECTOR, COAXIAL (BNC) BNC (WITH SW)		R2407		METAL GLAZE 10K	5%	1/10W
J2405		CONNECTOR, COAXIAL (BNC)		R2408 R2409	1-216-073-00	METAL GLAZE 47K METAL GLAZE 10K	5% 5%	1/10W 1/10W
J2406 J2407	1-562-261-71	BNC (WITH SW) CONNECTOR, COAXIAL (BNC)		R2410 R2411	1-216-089-91 1-216-073-00	METAL GLAZE 47K METAL GLAZE 10K	5% 5%	1/10W 1/10W
J2408 J2409	1-562-261-71	BNC (WITH SW) CONNECTOR, COAXIAL (BNC)		R2412 R2413		METAL GLAZE 47K METAL GLAZE 10K	5% 5%	1/10W 1/10W
J2410		BNC (WITH SW) CONNECTOR, COAXIAL (BNC)		R2414 R2415	1-216-089-91	METAL GLAZE 10K METAL GLAZE 47K METAL GLAZE 10K	5% 5%	1/10W 1/10W
J2411 J2412 J2413	1-766-738-11	BNC (WITH SW) JACK, PIN (MOUNT TYPE)		R2416		METAL GLAZE 47K	5%	1/10W
J2413 J2414 J2415	1-507-802-41	JACK, PIN (MOUNT TYPE) JACK, PIN (MOUNT TYPE)		R2417 R2418		METAL GLAZE 10K METAL GLAZE 47K	5% 5%	1/10W 1/10W
				R2419 R2420	1-216-073-00	METAL GLAZE 10K	5% 5%	1/10W 1/10W
J2416 J2417	1-507-802-41	JACK, PIN (MOUNT TYPE) JACK, PIN (MOUNT TYPE)		R2420 R2421		METAL GLAZE 47K	5%	1/10W
J2418 J2419		JACK, PIN (MOUNT TYPE) JACK, PIN (MOUNT TYPE)		R2422	1-216-089-91	METAL GLAZE 47K	5%	1/10W
J2420		JACK, PIN (MOUNT TYPE)		R2423 R2424		METAL GLAZE 10K METAL GLAZE 47K	5% 5%	1/10W 1/10W
		CHIP CONDUCTORS		R2425 R2426		METAL GLAZE 10K	5% 1%	1/10W 1/4W
		<chip conductor=""></chip>						
JR1 JR4		CONDUCTOR, CHIP CONDUCTOR, CHIP		R2427 R2428		METAL GLAZE 100K METAL GLAZE 220K	5% 5%	1/10W 1/10W
JR5	1-216-295-91	CONDUCTOR, CHIP		R2429 R2430		METAL GLAZE 100 METAL GLAZE 560K	5% 5%	1/10W 1/10W
JR7 JR12		CONDUCTOR, CHIP CONDUCTOR, CHIP		R2431		METAL GLAZE 15K	5%	1/10W
JR13		CONDUCTOR, CHIP CONDUCTOR, CHIP		R2432 R2433	1-214-775-00	METAL 82K METAL GLAZE 100K	19 59	1/4W 1/10W
JR14 JR15	1-216-295-91	CONDUCTOR, CHIP		R2434	1-216-105-91	METAL GLAZE 220K	5%	1/10W
JR16 JR17		CONDUCTOR, CHIP CONDUCTOR, CHIP		R2435 R2436		METAL GLAZE 100 METAL GLAZE 560K	5% 5%	1/10W 1/10W
JR19		CONDUCTOR, CHIP CONDUCTOR, CHIP		R2437 R2438		CONDUCTOR, CHIP METAL GLAZE 15K	59	1/10W
JR20 JR21	1-216-295-91	CONDUCTOR, CHIP		R2439	1-214-775-00	METAL 82K	19	1/4W
JR23 JR30		CONDUCTOR, CHIP CONDUCTOR, CHIP		R2440 R2441		METAL GLAZE 220K METAL GLAZE 100K	59 59	1/10W 1/10W
JR34		CONDUCTOR, CHIP		R2442		METAL GLAZE 100	59	1/10W
JR35 JR40		CONDUCTOR, CHIP CONDUCTOR, CHIP		R2443 R2444		METAL GLAZE 560K METAL GLAZE 15K	59 59	1/10W 1/10W

PVM-20M2U/20M4U PVM-20M2E/20M4E/20M4A



Les composants identifies par une trame et une marque \(\Delta\) sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The componants identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

						**				*********	
REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION			REMARK
		***************************************			*						KEWAKK
R2446	1-214-775-00		82K	1%	1/4W	R3421	1-216-689-11	METAL GLAZE	39K	5%	1/10W
R2447	1-210-105-91	METAL GLAZE	220K	5%	1/10W	D2422	1 216 040 01	METAL CLASS	1 77	-~	
R2448	1-216-097-91	METAL GLAZE	100K	5%	1/10W	R3422 R3423	1-216-049-91	METAL GLAZE METAL GLAZE	1K	5%	1/10W
R2449		METAL GLAZE		5%	1/10W	R3424		METAL GLAZE		5%	1/10W
R2450		METAL GLAZE		5%	1/10W	R3425		METAL GLAZE		5%	1/10W
R2451		METAL GLAZE		5%	1/10W	R3426		METAL GLAZE		5%	1/10W
R2452		METAL GLAZE		5%	1/10W	K5420	1-210-033-00	METAL GLAZE	120	5%	1/10W
						R3427	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R2453		METAL GLAZE		5%	1/10W	R3428		METAL GLAZE		5%	1/10W
R2455	2-216-113-00	METAL GLAZE	470K	5%	1/10W	R3429		METAL GLAZE		5%	1/10W
R2458		CONDUCTOR,				R3430		METAL GLAZE		5%	1/10W
R2463		METAL GLAZE		5%	1/10W	R3431		METAL GLAZE		5%	1/10W
R2465	1-216-073-00	METAL GLAZE	10K	5%	1/10W						
D0444	1 014 050 00		4.077			R3432		METAL GLAZE		5%	1/10W
R2466		METAL GLAZE		5%	1/10W	R3435		METAL GLAZE		5%	1/10W
R2467		METAL GLAZE		5%	1/10W	R3436		METAL GLAZE		5%	1/10W
R2470	1-214-702-00		75	1%	1/4W	R3437		METAL GLAZE		5%	1/10W
R2471 R2472		METAL GLAZE		5%	1/10W	R3438	1-216-045-91	METAL GLAZE	680	5%	1/10W
R2412	1-210-003-91	METAL GLAZE	3.9K	5%	1/10W	D2420	1 21/ 04/ 01	1 CT 4 CT			
R2473	1.216.027.00	METAL GLAZE	220	501	1/1037	R3439	1-216-045-91	METAL GLAZE	680	5%	1/10W
R2474		METAL GLAZE		5%	1/10W						
R2475		METAL GLAZE		5% 5%	1/10W 1/10W			OWNER			
R2476	1-214-702-00		75	10%	1/10W			<switch></switch>			
R2477		METAL GLAZE		5%	1/10W	S2401	1 570 500 11	CHITCH DID			
XX-77	1-210-091-00	METAL OLALE	JUK	370	1/10W	32401	1-570-598-11	SWITCH, DIP			
R2478	1-216-063-91	METAL GLAZE	3.9K	5%	1/10W						
R2479		METAL GLAZE		5%	1/10W	******	*****	*******	******	*****	*****
R2480		METAL GLAZE		5%	1/10W						
R2481		METAL GLAZE		5%	1/10W			MISCELLANEOU	IS		
R2482	1-214-702-00		75	1%	1/4W			********			
R2483		METAL GLAZE		5%	1/10W	Δ	1-223-417-12	RESISTOR ASSY	(HIGH-V	OLTAG	E)
R2484		METAL GLAZE		5%	1/10W					12	(M4U/E/A)
R2485		METAL GLAZE		5%	1/10W	Δ	.1-238-368-11	RESISTOR ASSY	, HIGH-VO	LTAG	É
R2486		METAL GLAZE		5%	1/10W	100000000000000000000000000000000000000					COM2U/E)
R2487	1-216-093-00	METAL GLAZE	68K	5%	1/10W	Δ	1-411-657-11	COIL, LANDING	CORRECT	MOI	
R2488	1-214-702-00	METAI	75	100	1/4337			CON		_ (2	OM4U/E/A)
R2489			75	1%	1/4W	40	1-426-305-11	COIL, DEMAGNE	TIZA HOI	V	
R2490		METAL GLAZE METAL GLAZE		5% 5%	1/10W 1/10W	Д	.1-431-349-11	DEFLECTION YO	JKE (¥20F	ZA) (2(J#2U/E)
R2491		METAL GLAZE		5%	1/10W		1 451 455 11	DEFLECTION YO	NETE EXPONE		
R2492		METAL GLAZE		5%	1/10W	74)	1-431-430-11	DEFLECTION IL	JKE (1 20N		OVERE TARRAN
	. 210 045 51	WILLIAM ODITUDE	116	5 70	1/1011		1-452-032-00	MAGNET,DISK ;	10mma		OM4U/E/A)
R2493	1-216-093-00	METAL GLAZE	68K	5%	1/10W			MAGNET, ROTAT		K - 15r	mna
R2494	1-214-702-00		75	1%	1/4W		1-544-063-12	SPEAKER	TOLL DI	, 151	THE STATE OF THE S
R2495	1-214-702-00	METAL	75	1%	1/4W	Δ		FUSE (H.B.C.) 4A	/250V		
R2496		METAL GLAZE		5%	1/10W				~~~~~	000000000000000000000000000000000000000	300000000000000000000000000000000000000
R2497	1-216-063-91	METAL GLAZE	3.9K	5%	1/10W	Δ	1-590-910-11	CORD SET, POW	ER (20M2E	20M4	EA)
D0400					1		1-765-268-11	CORD, CONNECT	ΓΙΟΝ		
R2498		METAL GLAZE		5%	1/10W	Δ	1-765-718-11	CORD SET, POWI	ER (20M2)	J/20M4	U)
R2499		METAL GLAZE		5%	1/10W			NA3012-M4 (20M			
R3400		METAL GLAZE		5%	1/10W	Δ.	8-736-135-05	PICTURE TUBE 2	OFZ5(DAF	UK) (20)	MU/E)
R3402		METAL GLAZE		5%	1/10W						00000000000000000000000000000000000000
R3404	1-210-005-91	METAL GLAZE	3.9K	5%	1/10W			PICTURE TUBE 2			
R3405	1-216-027-00	METAL OLATE	220	50%	1/1007	Δ	8-730-381-05	PICTURE TUBE 2	OMT3 (PV	M) (20)	MU)
R3406		METAL GLAZE		5%	1/10W						
R3408		METAL GLAZE		5% 5%	1/10W 1/10W	****	*****	*****			ت تا تا يا يو ميد بدريو
R3409	1-214-702-00		75	1%	1/4W	*********		****	***	***	****
		METAL GLAZE		5%	1/4W 1/10W		ACCESSODIES	S AND DACPING	MATERIA	10	
	. *************************************	THE OLIVE	JUIL	3 10	1/10#		**********	S AND PACKING	.wia.i.eki/	****	
R3411	1-216-063-91	METAL GLAZE	3.9K	5%	1/10W						
		METAL GLAZE		5%	1/10W		3-170-078-01	HOLDER (B), PLU	IG		
R3413		METAL GLAZE		5%	1/10W			MANUAL, INSTR			
D 4 4 4 4		METAL GLAZE		5%	1/10W		5 555-005-12 I	matore, mork		MOFIN	014E only)
		METAL GLAZE		5%	1/10W		3-859-663-22	MANUAL, INSTR		1414EH 21	mate omy)
								CUSHION (UPPER			
R3417	1-216-093-00	METAL GLAZE	68K	5%	1/10W	*	4-043-770-01	CUSHION (LOWE	Ŕ) (ASSY))	
	1-214-702-00	METAL	75	1%	1/4W						
	1-216-037-00	METAL GLAZE		5%	1/10W		4-044-040-03 I	ABEL, TALLY			
R3420	1-216-023-00	METAL GLAZE		5%	1/10W			NDIVIDUAL CAL	RTON		
								BAG, PROTECTIO			
									37		

Printed by: Schaltungsdienst Lange, Berlin (GERMANY)

Sony Corporation
Image & Sound Communication Company

En glish 97024**-1**30-1 41**9**-97. 4